



DAIKIN

Marine type

Container Refrigeration Unit

Service Manual

DAIKIN CONTAINER

LXE10E-A



DAIKIN INDUSTRIES, LTD.

TR 01-09C

Please read the contents of this manual prior to operation of the unit.

This booklet will provide you with the minimum necessary information required to operate the Daikin refrigerated unit LXE10E-A. It covers all of the unit's functions from basics such as the names for each mode of operation, how to turn on the power supply, or change a setting temperature, to describing functions of product and maintenance service.

In addition, refer to the manuals listed below:

- Parts List
- Operation Manual of Personal Computer Software

CONTENTS

SAFETY PRECAUTIONS

- Danger3
- Warning4
- Caution5

1. INTRODUCTION.....1-1

- 1.1 Operation range1-1
- 1.2 Basic names of components1-1
- 1.3 Basic operation of refrigeration unit1-2
 - 1.3.1 Starting operation1-2
 - 1.3.2 Checking during operation1-3
 - 1.3.3 Procedure after operation.....1-3
 - 1.3.4 Adjust the ventilation1-4

2. GENERAL DESCRIPTION.....2-1

- 2.1 Main specifications2-1
- 2.2 Names of components2-2
 - 2.2.1 Outside2-2
 - 2.2.2 Inside2-5
 - 2.2.3 Control box2-7
- 2.3 Set point of functional parts and protection devices.....2-12
- 2.4 Operating pressure and running current2-13
- 2.5 Operation modes and control.....2-17
 - 2.5.1 Frozen mode2-18
 - 2.5.2 Chilled and partial frozen mode.....2-20
 - 2.5.3 Defrosting mode2-22
 - 2.5.4 Dehumidification (Optional)2-25
 - 2.5.5 Common control2-26

3. ELECTRONIC CONTROLLER.....3-1

- 3.1 Function table.....3-1
- 3.2 Basic operation of electronic controller3-3
 - 3.2.1 Control panel3-3
- 3.3 Operation procedure3-6
 - 3.3.1 Operation procedure flow chart3-6
 - 3.3.2 Mode operation procedure3-9
 - 1. Current (Operation state) indication mode ...3-9
 - 2. Operation setting mode3-10
 - 3. Battery mode3-11
 - 4. Mode operation3-12
 - 5. LED display light-OFF mode3-14
 - 6. Sensor indication mode.....3-15
 - 7. Temperature record scroll mode3-18
 - 8. Alarm record scroll mode3-21
 - 9. PTI record scroll mode3-23
 - 3.3.3 Setting flow chart.....3-24
 - 10. Optional function setting mode.....3-26
 - 11. Basic function setting mode3-27
 - 12. Optional condition setting mode3-29
 - 13. Input data mode3-31
 - 14. Controller software download mode...3-32
- 3.4 Alarm display and back-up function3-33
 - 3.4.1 Alarm list.....3-33
 - 3.4.2 Back-up operation at sensor malfunction...3-34
- 3.5 Back up Battery3-36

- 3.5.1 Specifications3-36

- 3.5.2 Function.....3-36

- 3.5.3 Battery check
(When using optional rechargeable battery) ...3-36

- 3.5.4 Battery replacement
(Rechargeable battery)3-37

- 3.6 Information interchange with personal computer...3-38

- 3.6.1 Data logging3-39

- 3.6.2 Software configuration.....3-40

- 3.7 Inspection procedure for the electronic controller3-42

- 3.8 Controller replacement and the initial setting...3-43

- 3.8.1 Controller replacement3-43

- 3.8.2 Compatibility of controller DECOS III d with
III c and III b3-44

- 3.8.3 LXE10E-1, LXE10E-A & LXE10D Initial setting procedure
(for spare controller of DECOS III d,
DECOS III c & DECOS III b)3-46

- 3.8.4 LXE10E-1 & LXE10E-A Initial setting table
into spare controller DECOS III d3-47

- 3.8.5 LXE10E-A Initial setting table into spare
controller DECOS III c3-48

- 3.8.6 LXE10D Initial setting table into spare
controller DECOS III b3-49

- 3.9 PTI (Pre-Trip Inspection) and periodic inspection ...3-50

- 3.9.1 Inspection item3-51

- 3.9.2 Automatic PTI (Pre-Trip Inspection)3-54

- 3.9.2.1 PTI selection mode.....3-55

- 3.9.2.2 Short PTI (S.PTI)3-56

- 3.9.2.3 Full PTI (F.PTI)3-57

- 3.9.2.4 Alarm list during PTI
(Pre-Trip Inspection).....3-58

- 3.9.2.5 Manual check (M.CHECK)3-59

- 3.10 Chartless function3-61

- 3.10.1 Chart indication function.....3-61

- 3.10.2 P code (Pull down time indication)3-63

- 3.10.3 Chartless code display function.....3-64

- 3.10.3.1 List of chartless code.....3-64

- 3.10.3.2 H-code3-65

- 3.10.3.3 d-code:3-67

- 3.11 Communication modem3-68

4. SERVICE AND MAINTENANCE.....4-1

- 4.1 Maintenance service4-1

- 4.1.1 Collection of refrigerant4-1

- 4.1.2 Gauge manifold.....4-1

- 4.1.3 Automatic pump down.....4-3

- 4.1.4 Refrigerant recovery and charge.....4-5

- 4.2 Main components and maintenance4-8

- 4.2.1 Scroll compressor.....4-8

- 4.2.2 Fan and fan motor4-12

- 4.2.3 PT and CT board (EC9756)4-13

- 4.2.4 Electronic expansion valve4-15

CONTENTS

4.2.5 Suction modulation valve	4-16	7.10 Piping diagram	7-5
4.2.6 Drier.....	4-17	7.11 Electric wiring pilot lamps and monitoring circuit.....	7-6
4.2.7 Solenoid valve	4-18	7.12 Fuse protection table.....	7-7
4.2.8 Discharge pressure regulating valve	4-19	7.13 Schematic wiring diagram (Connector type terminal board and rechargeable battery) ...	7-9
4.2.9 Check valve	4-19	7.14 Stereoscopic wiring diagram (Connector type terminal board and rechargeable battery) ...	7-10
4.2.10 High-pressure switch (HPS)	4-20	7.15 Schematic wiring diagram (Connector type terminal board, temperature recorder and dry battery) ...	7-11
4.2.11 Low pressure transducer (LPT)	4-20	7.16 Stereoscopic wiring diagram (Connector type terminal board, temperature recorder and dry battery)	7-12
4.2.12 High pressure transducer (HPT)	4-21	7.17 Schematic wiring diagram (Screwed cramp type terminal board, temperature recorder and dry battery)	7-13
4.2.13 Air-cooled condenser and evaporator ...	4-21	7.18 Stereoscopic wiring diagram (Screwed cramp type terminal board, temperature recorder and dry battery)	7-14
4.2.14 Fusible plug	4-21	8. OPTIONAL FUNCTIONS MANUAL	8-1
4.2.15 Liquid/moisture indicator	4-22	8.1 Electronic temperature recorder.....	8-2
4.2.16 Evacuation and dehydrating	4-23	8.1.1 Standard type	8-2
5. OPTIONAL DEVICES.....	5-1	8.1.2 Rechargeable battery type	8-4
5.1 Electronic temperature recorder.....	5-1	8.2 Electronic controller.....	8-5
5.1.1 Standard type	5-1	8.2.1 Special operation 1.....	8-5
5.1.2 Rechargeable battery type	5-3	8.2.2 Special operation 2.....	8-9
5.2 USDA transportation	5-4	8.2.3 Special operation 3.....	8-22
5.2.1 Type of USDA sensor/receptacle	5-4	8.2.4 Special controller setting	8-26
5.2.2 Initial setting	5-4	8.2.5 Setting temperature and operation mode (with Partial frozen mode).....	8-30
5.2.3 USDA sensor calibration	5-4	8.2.6 Defrost interval	8-31
5.2.4 USDA transportation requirement	5-4	8.2.7 G-SET operation 1	8-32
5.2.5 USDA report required by USDA local officer.....	5-4	8.2.8 G-SET operation 2	8-32
5.3 TransFRESH.....	5-6	8.2.9 Valve mode	8-33
6. TROUBLESHOOTING.....	6-1	8.2.10 Dehumidification control	8-35
6.1 Refrigeration system and electrical system.....	6-1	8.2.11 Manual check selection mode	8-39
6.2 Alarm codes on electronic controller	6-13	8.2.12 F.PTI specification	8-40
6.3 Troubleshooting for automatic PTI (J-code).....	6-17	8.2.13 Rechargeable battery.....	8-42
6.4 Diagnosis based on the recording chart.....	6-19	8.3 Control box.....	8-43
6.5 Emergency operation	6-22	8.3.1 Installation of personal computer receptacle and spare fuse in the control box	8-43
6.5.1 Emergency operation of controller	6-22	8.3.2 Cable clamp bracket 1.....	8-44
6.5.2 Short circuit operation of controller.....	6-23	8.3.3 Cable clamp bracket 2.....	8-45
6.5.3 Opening adjustment of electronic expansion valve.....	6-25	8.4 USDA transportation.....	8-46
6.5.4 Opening adjustment of suction modulation valve:	6-26	8.4.1 Type of USDA sensor/receptacle	8-46
6.5.5 Automatic Back up for supply/ return air temperature sensors	6-27	8.4.2 Initial setting	8-46
7. APPENDIX.....	7-1	8.4.3 USDA sensor calibration	8-46
7.1 Standard tightening torques for bolts	7-1	8.4.4 USDA transportation requirement	8-46
7.2 Standard tightening torque for flare nut.....	7-1	8.4.5 USDA report required by USDA local officer.....	8-46
7.3 Resistance of motor coil and solenoid valve coil ...	7-1	8.5 TransFRESH.....	8-48
7.4 Standard tightening torque for electronic expansion valve coil(EV).....	7-1	8.6 Special service port	8-50
7.5 HFC134a, temperature-vapor pressure characteristics table	7-2	8.6.1 Collection of refrigerant	8-50
7.6 Temperature conversion table and temperature sensor (SS/RS/DSS/DRS/RSS/RRS/EIS/EOS/SGS/AMBS) characteristics table.....	7-3	8.6.2 Attaching and removing of manifold gauge ...	8-50
7.7 Temperature conversion table and temperature sensor (DCHS) characteristics table.....	7-4	8.7 Pressure gauge	8-52
7.8 High pressure transducer characteristics table ..	7-4		
7.9 Low pressure transducer characteristics table ...	7-4		

SAFETY PRECAUTIONS

Always observe the following points before operating or inspecting a unit.





DANGER

Always turn off the main power supply to the facility before disconnecting the power plug.



Always turn off the main power supply to the facility before inspecting the interior of the control box.

※ This is important because high voltage remains at the circuit breaker and the optionally provided modem even though the circuit breaker in the control box is turned off.



WARNING




Do not touch the condenser fan while power to the unit is ON.

Before removing the condenser fan cover, turn off the circuit breaker and disconnect the power plug.

During air-cooled operation : Condenser fan may start and stop automatically for the refrigerant high pressure control.




During water-cooled operation: Condenser fan may start and stop automatically for cooling of the control box.



CAUTION

Before starting the unit, run the generator.

Securely close the control box cover.
Otherwise, it will allow water entry.






CAUTION

Wash the refrigeration unit with fresh water at PTI.

Carefully flush the air-cooled condenser with fresh water to remove the salt that sticks to it.






CAUTION

Refrigerant and refrigerant oil

Be sure to only charge the unit with refrigerant HFC 134a.

Never attempt to use any other refrigerant (CFC12, HCFC22, etc) with the refrigeration unit.

If any other refrigerant not specified is charged, it may cause problems with the unit.



Use only Daikin specified oil (IDEMITSU, Daphne Hermetic Oil FVC46D) when replacing the refrigerant oil.


If any other refrigerating machine oil not specified is charged, it may cause problems with the unit.



Open the oil can, just before charging the oil, and use all the oil in the can once opened.

Do not leave the can open for 5 hours or longer to avoid moisture entry.

Using any refrigerant oil which has absorbed moisture may cause problems with the unit.




Use only exclusive tools for HFC134a. (gauge manifold, charging cylinder, etc)

Do not use any tools for CFC12 or HCFC22.

Service ports with exclusive quick joints for HFC134a are provided in the refrigeration unit to avoid improper refrigerant or refrigerant oil from entering into the refrigeration circuit. (Refer to clause 4.1.2)

The charging hose and gauge port are not interchangeable with those of previous models using other refrigerants.

If the system has been opened for any reason, the filter drier should be replaced.



**CLASS 1 SPECIFIED PRODUCT BY
THE HYDROFLUORIC REFRIGERANT RECOVERY LAW**

HFC IS USED FOR THIS PRODUCT AS A REFRIGERANT.

- (1) EMISSION OF HYDROFLUORIC SUBSTANCES INTO THE ATMOSPHERE WITHOUT PERMISSION IS PROHIBITED.
- (2) RECOVERY OF HYDROFLUORIC SUBSTANCES IS MANDATORY WHEN SCRAPPING THIS PRODUCT.
- (3) THE KIND OF HYDROFLUORIC SUBSTANCE AND ITS AMOUNT ARE STATED IN THE MANUFACTURER'S LABEL OR THE ADDITIONALLY CHARGED AMOUNT LABEL.


1. INTRODUCTION

1.1 Operation range

Use the units within the following range.

Item	Operation range
Ambient temperature range	-30°C to +50°C (-22°F to + 122°F)
Inside temperature range	-30°C to +30°C (-22°F to + 86°F)
Voltage	50Hz: 380V/400V/415V, 60Hz: 440V/460V Voltage fluctuation rate should be within ±10%
Vibration and shock	2G

1.2 Basic names of components



- ① Compressor
- ② Air-cooled condenser
- ③ Receiver
- ④ Evaporator
- ⑤ Control box

(Outside: switch, manual defrost switch, monitoring receptacle
Inside: circuit breaker)

- ⑥ Condenser fan
- ⑦ Drier

- ⑧ Access panel
- ⑨ Storage space for power cable
- ⑩ Ventilator
- ⑪ Thermometer check port (Return)

※ Thermometer check port is not fitted to some models.

- ⑫ Gas sampling port
Sampling port (Supply)

- ⑬ Liquid moisture indicator
- ⑭ Recorder (optional)

(Use this port to measure the
inside return air temperature.)

(This is used to measure the
inside supply air temperature
and inside CO₂ concentration.)

1.3 Basic operation of refrigeration unit


1.3.1 Starting operation

(1) Connect the power plug to the power supply.

Insert the plug ① suited to the power source voltage, and fasten the plug firmly.

(2) Turn on the main power switch of the power source facility (outside the unit)


(3) Turn on the circuit breaker ②.



(4) Close the control box cover fully.


If it is poorly closed, it will allow water entry. Check the contact around the packing, and firmly close the cover. (Refer to the "⚠ CAUTION " on page 6.)

(5) Press the UNIT ON/OFF key ③.



1.3.2 Checking during operation

Checking items(precautions)	Method of check
1. Check the compressor, fan, pipes, etc. for abnormal noise and vibration.	Visual and auditory
2. Check the refrigerant for shortage. Check the excessive charge.	Visual check by using the moisture indicator For the details, refer to clause 4.2.15.
3. Check the refrigerant for moisture inclusion.	Visual The moisture indicator colour; Green: normal Yellow: abnormal.
4. Check if the recorder is working according to the inside temperature.	Visual
5. Check operating conditions with the pilot lamps.	Visual




1.3.3 Procedure after operation

(1) Turn off the UNIT ON/OFF key ③, and turn off the circuit breaker ②.

(2) Close the control box cover tightly.

(3) Stow the power cable.

Disconnect the power plug ①, and stow the power cable directing the plug opening downward to prevent sea water or rain water from collecting in the power plug.



1.3.4 Adjust the ventilation

Adjust the opening of the ventilation ⑩ according to the cargo.





CAUTION

Keep the ventilation closed during transportation of the frozen cargo.

When ventilation is not required set the handle to "CLOSE".

When ventilation is required (chilled mode), slide the handle upward.

※Set the arrow mark of the ventilation at the graduation on the scale to adjust the ventilation as desired according to the cargo.



2. GENERAL DESCRIPTION


2.1 Main specifications

Item \ Model		LXE10E
Condenser cooling system		Air cooled type
Controller		DECOSⅢ d
Power supply		AC 3-phase 380V/400V/415V 50Hz, 440V/460V 60Hz
Compressor		Hermetic scroll type (Motor output: 5.5kW)
Evaporator		Cross fin coil type
Air-cooled condenser		Cross fin coil type
Evaporator fan		Propeller fan
Evaporator fan motor		Three-phase squirrel-cage induction motor
Condenser fan		Propeller fan
Condenser fan motor		Three-phase squirrel-cage induction motor
Defrosting	System	Hot-gas defrosting system
	Initiation	Dual timer, on-demand defrost and manual switch
	Termination	Detecting the temperature of evaporator outlet pipe and return air
Refrigerant flow control		Electronic expansion valve
Capacity control		Capacity control with hot gas bypass and suction modulating valve
Protective devices /Safety devices		Circuit breaker, PT/CT board (for over current protection). Compressor thermal protector Condenser fan-motor thermal protector Evaporator fan-motor thermal protector High-pressure switch, Fusible plug, Fuse (10A, 5A)
Refrigerant (charged amount)		R134a : 4.6 (kg)
Refrigerant oil (charged amount)		IDEMITSU, Daphne hermetic oil FVC 46D : 2.2(ℓ)
Weight		Note; Refer to each model's specification for detail weight of each model.

2.2 Names of components

2.2.1 Outside


●LXE10E




- | | |
|--|---|
| ① Access panel | ①⑥ Suction modulating valve (SMV) |
| ② Thermometer check port (Return air)
※Thermometer check port is not fitted to some models. | ①⑦ Discharge pressure regulating valve (DPR) |
| ③ Condenser fan motor (CFM) | ①⑧ Compressor suction pipe temperature sensor (SGS) |
| ④ Temperature recorder box (Option) | ①⑨ Ambient temperature sensor (AMBS) |
| ⑤ Hot-gas solenoid valve (HSV) | ②⑦ Thermometer check port (Supply air) |
| ⑥ Defrost solenoid valve (DSV) | ②⑧ Compressor (CM) |
| ⑦ Discharge gas by-pass solenoid valve (BSV) | ②⑨ Discharge pipe temperature sensor (DCHS) |
| ⑧ Electronic expansion valve (EV) | ②⑩ Storage space for power cable |
| ⑨ Economizer solenoid valve (ESV) | ②⑪ Low pressure transducer (LPT) |
| ⑩ Injection solenoid valve (ISV) | ②⑫ High pressure transducer (HPT) |
| ⑪ Air-cooled condenser | ②⑬ High pressure switch (HPS) |
| ⑫ Liquid/moisture indicator | ②⑭ Control box |
| ⑬ Liquid receiver | ②⑮ Ventilator |
| ⑭ Dryer | |
| ⑮ Liquid solenoid valve (LSV) | |

●LXE10E

- Detail of solenoid valves
- Models produced after Dec., 2004




- Models produced before Nov., 2004



[Valve]

BSV :Discharge gas bypass Solenoid Valve
 DSV :Defrost Solenoid Valve
 DPR :Discharge Pressure Regulator Valve
 EV :Electronic Expantion Valve
 ESV :Economizer Solenoid Valve
 HSV :Hot gas Solenoid Valve
 ISV :Injection Solenoid Valve
 RSV :Reheater Solenoid Valve (Option)
 for dehumidification control

· Detail of compressor and refrigerant control devices




[Sensor]

- AMBS: Ambient temperature sensor
- DCHS: Discharge Gas Temperature Sensor
- DPR : Discharge Pressure Regulator Valve
- HPS : High Pressure Switch
- HPT : High Pressure transducer
- LPT : Low pressure transducer
- LSV : Liquid solenoid valve
- SGS : Compressor suction pipe temperature sensor
- SMV : Suction modulating valve


2.2.2 Inside

●LXE10E



- ① Evaporator fan motor (EFM)
- ② Evaporator
- ③ Supply air temperature sensor (SS)
Data recorder supply air temperature sensor (DSS, optional)
Recorder supply air temperature sensor (RSS, optional)
- ④ Evaporator outlet pipe temperature sensor (EOS)
- ⑤ Evaporator inlet pipe temperature sensor (EIS)
- ⑥ Return air temperature sensor (RS)
Data recorder return air temperature sensor (DRS, optional)
Recorder return air temperature sensor (DRS, optional)
- ⑦ USDA receptacle (optional)

· Inside Detail



[Sensor]

DRS:Return Air Temperature Sensor for Datacorder (Optional)

DSS:Supply Air Temperature Sensor for Datacorder (Optional)

EIS :Evaporator Inlet Temperature Sensor

EOS:Evaporator Outlet Temperature Sensor

HuS :Humidity Sensor (Optional)

RS :Return Air Temperature Sensor


RRS:Return Air Temperature Sensor for Temperature Recorder (Optional)

SS :Supply Air Temperature Sensor


RSS:Supply Air Temperature Sensor for Temperature Recorder (Optional)

2.2.3 Control box

●Inside of the control box




●Operation panel (Outside of the control box)




- | | |
|--|--|
| ① Controller operation panel (EC3, 4) | ⑫ Fuse (Fu1-6) |
| ② MANUAL DEFROST key | ⑬ Battery (BAT) |
| ③ UNIT ON/OFF key | ⑭ Remote monitoring receptacle (RM) (optional) |
| ④ Phase correction contactor (PCC1,2) | ⑮ Personal computer receptacle |
| ⑤ Magnetic contactor for high speed evaporator fan (EFH) | ⑯ Circuit breaker (CB) |
| ⑥ Magnetic contactor for low speed evaporator fan (EFL) | ⑰ PT/CT board |
| ⑦ Magnetic contactor condenser fan (CFC) | ⑱ Transformer (TrC), control circuit |
| ⑧ Reverse phase protection device (RPP) | ⑲ Magnetic contactor for compressor (CC) |
| ⑨ SMV adapter board (EC6) | ⑳ P.C.B for humidity sensor (HUS, optional) |
| ⑩ Terminal block board (TB1) | ㉑ Modem (RCD, optional) |
| ⑪ Controller CPU / IO board (EC1, 2) | ㉒ Noise filter (NF, optional) |

· Control box Inside detail


· Dry battery type



· Rechargeable battery type



· Control box Inside detail



[Control Box]



BAT :Back-up Battery (9V)
 CC :Magnetic Contactor, Compressor
 CFC :Magnetic Contactor, Condensor Fan Motor
 C/B :Circuit Breaker
 EFH :Magnetic Contactor, Evaporator Fan Motor,
 High Speed
 EFL :Magnetic Contactor, Evaporator Fan Motor,
 Low Speed
 PCC1:Phase Correction Contactor 1
 PCC2:Phase Correction Contactor 2

PPR :PC Port Receptacle
 PTCT:PTCT Board
 RM :Remote Monitoring Receptacle
 RPP :Reverse Phase Protector
 TrC :Transformer



[Controller]

EC1 :CPU Board
 EC2 :I/O Board
 EC6 :SMV Adapter Board

- Produced After May 2006(Connector Type)
- Detail of Terminal Board and Short Circuit Connector



- Produced Before April, 2006(Screwed cramp type)
- Detail of Terminal Board & Short Circuit Connector



※Refer to Fuse protection table page 7-7.

2.3 Set point of functional parts and protection devices

	Device name			Actuation	Set point	Detection method	Symbol
Pressure switch	High-pressure switch			OFF ON	2400kPa (24.47kg/cm²) 1900kPa (19.37kg/cm²)	High-pressure switch	HPS
Electronic controller	Mode selection① ※1	Chilled mode		ON	-10.0°C to +30.0°C (+14.0°F to +86.0°F)	Set point temperature	EC
		Frozen mode			-30.0°C to -10.1°C (-22.0°F to +13.8°F)		
	Mode selection② ※1	Chilled mode		ON	-3.0°C to +30.0°C (+26.6°F to +86.0°F)	Set point temperature	EC
		Partial frozen mode			-10.0°C to -3.1°C (+14.0°F to +26.4°F)		
		Frozen mode			-30.0°C to -10.1°C (-22.0°F to +13.8°F)		
	Delay timer	Fan	Change-over for Hi/Lo	ON	10 seconds		
			After defrosting		60 seconds		
		Compressor	At starting		3 seconds		
	Defrosting timer	Initiation	Short	ON	4 hours ※2		
			Long		3, 6, 9, 12, 24 and 99 hours ※3		
		Back-up		OFF	90 minutes		
		In-range masking			90 minutes ※4		
		Out-range guard			ON		
		Defrosting termination set point			OFF Reset		
	15°C (59°F)					Return air temperature sensor	RS, DRS
	High-pressure control for Condenser fan			OFF ON	800kPa (8.2kg/cm²) 1000kPa (10.2kg/cm²) ※6	High-pressure transducer	HPT
	Discharge gas temperature protection set point	Pull down LPT>50kpa		OFF Reset	135°C (275°F) After 3 minutes elapsed	Discharge gas temperature sensor	DCHS
		LPT≤50kpa		OFF Reset	128°C (262°F) After 3 minutes elapsed		
	Overcurrent protection set point (Cutout)			OFF Reset	26.0A After 3 minutes elapsed	PT/CT board	CT2
	Current control			Control	50Hz : 16.1A 60Hz : 17.4A	PT/CT board	CT1
High pressure control			Control	2300 to 2350 kPa (23.5 to 24.0 kg/cm²)	High pressure sensor	HPT	
Current	Circuit breaker			OFF	30A		CB
	Fuse			OFF	5A, 10A ※7		Fu
Motor	Evaporator fan motor thermal protector			OFF	132°C (270°F)		
	Condenser fan motor thermal protector			OFF	135°C (275°F)		MTP
	Compressor motor thermal protector			OFF	140°C (284°F)		CTP
-	Fusible plug			-	95~100°C		

(※1) Mode selection ① or ② depends on the models.

(※2) When Return air (RS) is lower than -20°C, defrost starts every 6 hours.

(※3) When "99" hours is selected, refer to on demand defrost in clause 2.5.3.

(※4) When Inside set point is -20.0°C or Lower, In-range masking is 120min.

(※5) After the inside temperature falls to Inrange, if the temperature rises to Outrange, the defrost starts 30 minutes later.


Refer to Defrosting mode in clause 2.5.3

(※6) When dehumidification is ON in dehumidification mode, the setting figure may change between 900~2100kPa automatically (Refer to "High Pressure Control" Page 2-27)

(※7) Refer to "Fuse Protection table" in section 7.12.

2.4 Operating pressure and running current


●Chilled mode
 Inside : 0°C (32°F)
 Power supply :
 415V / 50Hz



●Fan motor current

Item	Amperage
Condenser fan motor running current	1.4 (415VAC)
Evaporator fan motor running current (2 motors)	3.2 (415VAC) Hi speed

●Chilled mode
 Inside : 0°C (32°F)
 Power supply :
 400V / 60Hz




●Fan motor current

Item	Amperage
Condenser fan motor running current	1.4 (400VAC)
Evaporator fan motor running current (2 motors)	3.2 (400VAC) Hi speed

●Frozen mode

Inside: -18°C (-0.4°F)

Power supply: 415V, 50Hz




●Fan motor current

Item	Amperage
Condenser fan motor running current	1.4 (415VAC)
Evaporator fan motor running current (2 motors)	0.9 (415VAC) Low speed

●Frozen mode

Inside: -18°C (-0.4°F)

Power supply: 400V, 60Hz



●Fan motor current

Item	Amperage
Condenser fan motor running current	1.4 (400VAC)
Evaporator fan motor running current (2 motors)	0.9 (400VAC) Low speed

2.5 Operation modes and control

There are two main types of operation modes: the cargo cooling control mode and the unit inspection mode.

The cargo cooling control mode is explained in this section.

※For the unit inspection mode, refer to section 3.9.

The relationship between the operation mode and setting temperature is as follows.

※For details, refer from clause 2.5.1 to 2.5.4


Mode selection	Operation mode	Setting temperature	Control sensor	Inside fan	Operation description
Mode selection① ※1	Chilled mode	−10.0°C to +30.0°C (−14.0°F to +86.0°F)	Supply air temperature sensor	High speed	Capacity control operation with suction modulating valve and hot-gas bypass control
	Frozen mode	−30.0°C to −10.1°C (−22.0°F to +13.8°F)	Return air temperature sensor	Low speed	Compressor ON/OFF control
Mode selection② ※1	Chilled mode	−3.0°C to +30.0°C (+26.6°F to +86.0°F)	Supply air temperature sensor	High speed	Capacity control operation with suction modulating valve and hot-gas bypass control
	Partial frozen mode	−10.0°C to −3.1°C (−14.0°F to +26.4°F)	Return air temperature sensor	High speed	Capacity control operation with suction modulating valve and hot-gas bypass control
	Frozen mode	−30.0°C to −10.1°C (−22.0°F to +13.8°F)	Return air temperature sensor	Low speed	Compressor ON/OFF control
Defrosting mode		-	-	OFF	Hot-gas defrosting with refrigerant metering control

※1 Mode selection ① or ② depends on the model.

To check the mode, see the LED after setting the temperature to "−9°C". If "SUPPLY" LED lights up, the current mode is ①, while it is ②, if "RETURN" LED lights up.

2.5.1 Frozen mode

Control state transition and common control



Operation of magnetic contactor and solenoid valve

Component name			Thermostat ON	Thermostat OFF
Magnetic contactor	Compressor	CC	ON	OFF
	Evaporator fan. High speed	EFH	OFF	OFF
	Evaporator fan. Low speed	EFL	ON	ON
	Condenser fan	CF	ON / OFF ※1	OFF
Solenoid valve	Liquid solenoid valve	LSV	ON	OFF
	Economizer solenoid valve	ESV	ON	OFF
	Injection solenoid valve	ISV	ON / OFF ※2	OFF
	Hot-gas solenoid valve	HSV	OFF	OFF
	Defrost solenoid valve	DSV	OFF	OFF
	Discharge gas by-pass solenoid valve	BSV	OFF	OFF
	Reheat solenoid valve	RSV	ON / OFF ※3	OFF
Suction modulating valve		SMV	100%	
Electronic expansion valve		EV	200~2000pls	

Note) ※1: High pressure control (Refer to Page 2-27)

※2: Injection control (Refer to Page 2-28)



※3: RSV : OFF $RS \leq 20^{\circ}\text{C}$ 、RSV : ON $RS \geq 25^{\circ}\text{C}$

(1) Set point temperature and control sensor

When the set point temperature (referred to as SP hereafter) is $-10.1^{\circ}\text{C}(+13.8^{\circ}\text{F})$ or lower, the compressor is operated ON and OFF, in response to return air temperature.

(2) Control

- ① When the control temperature reaches SP (point A), the compressor and condenser fan are turned off.
- ② When the control temperature exceeds $\text{SP}+1.0^{\circ}\text{C}$, the compressor, liquid solenoid valve and condenser fan are turned on. However, the compressor runs for at least 2 minutes every time once it is turned on. Even if the control temperature becomes SP or lower (point C) within 2 minutes after the compressor is turned on, the compressor, condenser fan and liquid solenoid valve are not turned off. (2 minutes compressor forced operation)




EV :Electronic Expansion Valve
 LSV :Liquid Solenoid Valve
 DSV:Defrost Solenoid Valve
 ESV:Economizer Solenoid Valve
 DPR:Discharge pressure regulator
 SMV:Suction Modulation Valve

HSV:Hot Gas Solenoid Valve
 ISV :Injection Solenoid Valve
 BSV :Discharge gas Bypass Solenoid Valve
 LPT :Low Pressure Transducer
 HPT:High Pressure Transducer
 HPS:High Pressure Switch

2.5.2 Chilled and partial frozen mode

Control state transition and common control



Operation of magnetic contactor and solenoid valve

Component name			Pull-down	Capacity control	Heat-up	Overcool protection
Magnetic contactor	Compressor	CC	ON	ON	ON	OFF
	Evaporator fan. High speed	EFH	ON	ON	ON	ON
	Evaporator fan. Low speed	EFL	OFF	OFF	OFF	OFF
	Condenser fan	CF	ON / OFF※1	ON	ON / OFF※4	OFF
Solenoid valve	Liquid solenoid valve	LSV	ON	ON	OFF	OFF
	Economizer solenoid valve	ESV	ON	OFF	OFF	OFF
	Injection solenoid valve	ISV	ON / OFF※2	ON / OFF※5	ON / OFF※3	OFF
	Hot-gas solenoid valve	HSV	OFF	ON / OFF※5	ON	OFF
	Defrost solenoid valve	DSV	OFF	ON / OFF※5	ON	OFF
	Discharge gas by-pass solenoid valve	BSV	OFF	ON / OFF※5	OFF	OFF
	Reheat solenoid valve	RSV	ON / OFF※6	OFF	OFF	OFF
Suction modulating valve		SMV	100%	3 to 100%	100%	100%
Electronic expansion valve		EV	200~2000pls	200~2000pls	0pls	1000pls

Note) ※1: High pressure control

※2: Injection control

※3: Charge control

※4: Release control

※5: Capacity control and hot gas by-pass

※6: RSV : OFF $RS \leq 20^{\circ}\text{C}$, RSV : ON $RS \geq 25^{\circ}\text{C}$

(1) Set point temperature and control sensor

- Chilled operation

When the set point temperature is -10.0°C (-140°F) or higher, or -3.0°C ($+26.6^{\circ}\text{F}$) or higher, the suction modulating valve (SMV) is controlled sensing the supply air temperature in order to adjust the cooling capacity.

- Partial frozen operation

When the set point temperature is -3.0 to -10.0°C ($+26.6$ to $+14.0^{\circ}\text{F}$), the suction modulating valve is controlled sensing the return air temperature in order to adjust the refrigerating capacity.

- Operation mode switching

Operation mode is automatically switched according to the set point of the electronic controller. Chilled and partial frozen operations are controlled in the same manner except the sensor for the temperature control.

(2) Control

- (a) Pull-down operation

Pull-down operation is carried out with fully opened suction modulating valve when the control temperature (SS) is higher than the set point temperature for 1.5°C or more (point ①).

- (b) Capacity control operation

When the control temperature (SS) reaches the point ② (set point temperature +1.5°C), the suction modulation valve is activated to conduct the capacity control operation.

The control temperature (SS) converges to the set point temperature (point ③) while repeats temperature increasing and decreasing.



During capacity control, hot gas by-pass (HSV, DSV, BSV) and liquid injection (ISV) are conducted in order to maintain the optimum operation condition of refrigerant system.

- (c) Heat-up operation


When the control temperature (SS) is lower than the set point temperature for 1.5°C or more (point ④), heat-up operation using hot gas is conducted in order to raise the equivalent return air temperature (RS) (point ④) to the set point temperature +1.5°C or more (point ⑤). Then the equivalent control temperature (SS) (point ⑤) is controlled to reach to the point ②.

- (d) Overcool protection operation

Although the unit's operation is in a stable state, if the control temperature lowers below set point temp -3°C (point ⑥), the compressor stops and only the evaporator fan continues to operate.



2.5.3 Defrosting mode



Operation of magnetic contactor and solenoid valve

Component name			Pump down	Defrosting
Magnetic contactor	Compressor	CC	ON	ON
	Evaporator fan. High speed	EFH	OFF	OFF
	Evaporator fan. Low speed	EFL		
	Condenser fan	CF	ON	ON/OFF ※2
Solenoid valve	Liquid solenoid valve	LSV	OFF	OFF
	Economizer solenoid valve	ESV	ON	OFF
	Injection solenoid valve	ISV	OFF	ON/OFF ※1
	Hot-gas solenoid valve	HSV	OFF	ON
	Defrost solenoid valve	DSV	OFF	ON
	Discharge gas by-pass solenoid valve	BSV	OFF	OFF
	Reheat solenoid valve	RSV	OFF	ON/OFF ※3
Suction modulating valve			SMV	100%
Electronic expansion valve			EV	200~2000pls

Note) ※1: Charging control

※2: Release control

※3: RSV:ON EOS>15°C

Defrosting operation

(1) Defrosting system

A hot-gas defrost system is adopted in the units; i.e. the high temperature and high pressure refrigerant (hot gas) from the compressor is sent to the evaporator and drain pan for defrosting. Since the evaporator is heated directly by the hot gas (refrigerant), defrosting can be performed effectively.

(2) Defrosting initiation

Defrosting is initiated by the timer or the manual defrost key.

However, defrosting is not initiated when frosting on the evaporator can not be detected.

- Evaporator inlet temperature : 5°C or higher
- Evaporator outlet temperature : 20°C or higher

① Initiation by timer (Timer is set at the electronic controller, refer to clause 3.3.2 for its operating method.)

Type of timer	Defrosting interval set	Function
Long timer	3, 6, 9, 12, 24 and 99 ^{※1} hours are selectable.	Regardless of the control temperature, defrosting is initiated according to the selected interval.
Short timer	4 hours ^{※2}	Defrosting is initiated every 4 hours until the control temperature comes within the in-range after pull-down. When the temperature is in-range, defrosting timer will change into the selected long timer.
Out-range timer	30 minutes	After the control temperature comes within in-range once, defrosting will be started 30 minutes later if the control temperature rises out of the in-range.

※1. On-demand defrost selection (12 hours for Frozen mode and 6 hours automatic for Chilled mode)

※2. 6 hours when the control temperature is -20°C or below.

② Starting by MANUAL DEFROST key (on the operation panel sheet key)

Press the MANUAL DEFROST key, then press the ENTER/ESC key while indicate "ON" on the LED display. The manual defrosting operation starts.

③ Initiation by frost detection

If the return air temperature does not drop at the speed of 0.2°C/1hr during frozen pull-down operation, defrosting will be initiated because it is judged that frost is formed on the evaporator. However, if the suction temperature is -20°C or lower, defrosting will not be initiated. (activated)

(3) On demand defrost

When "99" in long timer is selected, defrosting is activated upon the condition of frost on evaporator coil. This function is only for Frozen setting (SP < -10.1 deg C). and starting with 12 hours. (If this function is selected for chilled setting, defrost initiates every 6 hours automatically.)

Procedure:

Step 1: After defrost, the controller records compressor running time for 1st 1 hour. (T1)

Step 2: When 12 hours passed after defrost, controller records compressor running time for last 1 hour (T2). And the controller check whether the below condition is satisfied.

$$T2 > T1 \times 1.15$$

Step 3: If the above condition is satisfied, defrost is activated.

If above condition is not satisfied, defrost is postponed another one hour.

After counting up 13 hours, then repeat "Step 2".

Defrost will be postponed every one hour until the above condition (Step 2) is satisfied. (Max. 24 hours)

(4) Defrosting termination


Defrosting will be terminated when any one of the following three conditions is satisfied.

①The below figure is satisfied during defrost.

Status before defrost	Termination
INRANGE	$EOS \geq 30.0^{\circ}\text{C}$
Out of RANGE	$EOS \geq 30.0^{\circ}\text{C} + RS/DRS \geq 15^{\circ}\text{C}$

②90 minutes have elapsed.

③Any one of protective devices is activated.



2.5.4 Dehumidification (Optional)


The unit have dehumidification control by a reheat coil, which is fitted under the evaporator coil. To execute dehumidification, controller setting is required. (Refer to Page 3-12)

In dehumidification, the Reheat Solenoid Valve (RSV) opens to give high temperature and high pressurized refrigerant to reheat coil. The "DEHUMID" LED lamp will light up.

The following setting can be made:

- 1) Non humidification control
- 2) Humidification control (optional)

Dehumidification range: 60%RH–95%RH



2.5.5 Common control

The following are controlled in different operation modes. (For the details, refer to the following pages.)

	Control name	Control content	Operation mode			
			Frozen	Chilled	Partial frozen	Defrost
A	Compressor ON/OFF control	The compressor is operated on and off to adjust the inside temperature.	○			
B	Starting control	<ul style="list-style-type: none"> At the start of the operation with low ambient temperature, an oil temperature raising control is executed. When a protection device activates at the operation start, a high pressure/current control is executed. 	○	○	○	
C	Evaporator fan speed control	The evaporator fan is switched to the high or low speed according to the set point temperature.	○	○	○	
D	Superheat control	In order to keep the superheat of the evaporator optimum, the opening of the electronic expansion valve is controlled.	○			
E	High-pressure control	In order to keep the high pressure optimum, the opening of the electronic expansion valve is controlled.	○	○	○	
F	Injection	In order to prevent the refrigerant oil from deteriorating, the injection solenoid valve control or electronic expansion valve control is carried out.	○	○	○	
G	In-range control	When the control temperature is within $SP \pm 2^{\circ}\text{C}$, the in-range lamp is turned on.	○	○	○	
H	In-range masking control	After defrosting initiation, the in-range lamp is kept on for 90 minutes.	○	○	○	○
I	Capacity control	The circulating flow rate of refrigerant is proportionally controlled with suction modulating valve to keep the control temperature variation within $\pm 0.5^{\circ}\text{C}$.		○	○	
J	Charging and releasing control	These functions control the heating capacity for defrosting and heating operation.		○	○	○
K	Pump down control	The liquid refrigerant is collected into the liquid receiver (water cooled condenser).	○	○	○	○
L	Economizer control	The economizer circuit is controlled to enhance cooling capacity.	○	○	○	
M	Dehumidification (optional)	The unit can execute dehumidification by reheat coil and humidity sensor.		○		


Common control

A : Compressor ON/OFF control

When the control temperature reaches the set temperature or lower, the compressor is stopped.

When the control temperature rises and becomes higher than the [set point temperature +1.0°C], the compressor runs again.

When the compressor starts running it is forcibly run for 2 minutes. (2 minutes compressor forced operation) in order to prevent the compressor from deterioration due to shortage of lubricant.



B : Starting control

- Control when protective device activated

When the high pressure rapidly rises on starting or when the starting current is overcurrent, the compressor automatically stops to suppress high pressure and starting current.

- Temperature control of refrigerant oil

When ambient temperature is low, the temperature refrigerant oil for compressor is also low and the viscosity of the oil may be high.


On starting the unit, by-pass discharge gas to suction side of the compressor by opening the solenoid valve (BSV) to raise the oil temperature rapidly ensuring a stable feed of oil.

In order to control the oil temperature of refrigerating machine or in the event the high pressure is low, operate the compressor with the condenser fan stopped. If the high pressure reaches 1500 kPa or more, the fan will restart to operate.

The temperature control for refrigerant oil should be executed not with power ON/OFF in normal operation but with power ON under low ambient temperature.

An oil temperature raising control can be executed when all of the following conditions are met.

- The time turning power supply ON
- Ambient temperature $\leq 10^{\circ}\text{C}$
- (Discharge gas temperature – ambient temperature) $\leq 4^{\circ}\text{C}$



C : Evaporator fan speed control

The speed of the evaporator fan is switched in accordance with operation modes. A delay time of 10 sec. is provided to switch the high speed to low speed and vice versa.

Chilled mode : High speed
 Partial frozen mode : High speed
 Frozen mode : Low speed

D : Superheat control

The evaporator superheat is adjusted to be optimum by controlling the opening of the electronic expansion valve, based on the evaporator inlet and outlet refrigerant temperature, and the compressor suction gas temperature.

E : High-pressure control

- By electronic expansion valve

When the ambient temperature is high during the air-cooled operation, the condensing pressure (high pressure) will increase, and the high pressure switch may be activated.

In order to prevent this situation, the high pressure is controlled to be 2350kPa or lower by adjusting the opening of the electronic expansion valve.


- By condenser fan

When the ambient temperature is low during the air-cooled operation, the condenser pressure (high pressure) will decrease. Accordingly, the low pressure will decrease.

In order to prevent this situation, when the high pressure becomes set point or lower, the condenser fan stops to prevent the high pressure from excess dropping.

When the high pressure becomes set point or higher afterwards the operation will be restarted.

This control varies upon dehumidification setting.



F : Injection control

In order to decrease the discharge gas temperature, inject liquid refrigerant into the suction pipe.

- During normal compressor operation

The injection solenoid valve will be turned on or off to control the discharge gas temperature lower than set point.

The control is conducted properly by using detected discharge gas temperature and inside temperature.

Discharge gas temperature (DCHS) set value


	Frozen, chilled (pull-down)		Chilled, capacity control
	$RS \leq 0^\circ\text{C}$	$RS > 0^\circ\text{C}$	
ISV ON	120°C	128°C	113°C
ISV OFF	103°C	118°C	108°C

- Defrosting / Heat-up operation

Control the injection ON/OFF with charge control. For details, see the section of "charge control" on page 2-29.

G : In-range control

In order to observe at a glance whether the refrigeration unit properly controls the inside temperature or not, the orange lamp on the display panel will light up when the control temperature is near the set point temperature (SP).



H : In-range masking control

If the inside temperature is within the in-range when defrosting is started, the in-range lamp will be kept turned on forcibly for certain period as below regardless of the inside temperature thereafter.

This will avoid misunderstanding that there is a problem as the control temperature temporarily rises during defrosting.

Setpoint $\geq -20.0^\circ\text{C}$	90 minutes
Setpoint $\leq -20.1^\circ\text{C}$	120 minutes

I : Capacity control

In the chilled mode operation, adjusting cooling capacity makes the supply air temperature stable at the set point temperature (SP).

The capacity control is executed by adjusting the opening of suction modulating valve (SMV) between 3 to 100 %.

J : Charge and release control


Charge control or release control is executed to maintain the heating capacity optimum in defrosting and heating operation.

- Charge control

- ① The suction pressure (LPT) is detected and the injection solenoid valve (ISV) is turned on, then, liquid refrigerant is charged into the suction pipe.
- ② The discharge pressure (HPT) is detected and the injection solenoid valve (ISV) is turned on, then the liquid refrigerant is charged into the suction piping.

- Release control

The discharge pressure (HPT) is detected and the condenser fan (CFM) is turned on, then, the refrigerant is released into the condenser.



K : Pump down stop

Before the thermostat turns OFF and at the start of defrosting, close liquid solenoid valve (LSV) to conduct pump down operation and recover refrigerant in the receiver. When the low pressure reaches 0kPa or lower, the pump down is terminated.

L : Economizer control

The economizer circuit for which the intermittent injection to scroll compressor and the refrigerant heat exchanger are combined, is adopted in the unit.

The economizer circuit enables the liquid refrigerant to have wide range of subcooling resulting in a significant increase of cooling capacity.

- Economizer solenoid valve (ESV) control

Frozen mode: ON with return air temperature (RS) of 5°C or lower

Chilled & partial frozen mode: ON with return air temperature (RS) of 5°C or lower during pull-down operation

During capacity control, the control does not turn ON.

3. ELECTRONIC CONTROLLER

3.1 Function table

●DECOS III c/d (Daikin Electronic Controller Operation System)

(Note) [PC]: Functions using personal computer


No.	Function division	Function	DECOS III c/d
1	Control function	<ul style="list-style-type: none"> • Temperature control • Defrosting control • Humidity control 	✓ ✓ Optional
2	Initial setting	<ul style="list-style-type: none"> • With/without optional equipment (USDA, humidity) and horse power selection • Chartless function setting 	✓ ✓
3	Setting	<ul style="list-style-type: none"> • Temperature • Defrosting interval • Humidity • [PC] --- Header information set of data logger 	✓ ✓ ✓ ✓
4	Indication (Display panel)	<ul style="list-style-type: none"> • Operating mode (compressor running, defrosting, in-range temperature, dehumidifying) • Alarm • Return air temperature/set point temperature • Supply air temperature/set point temperature • Defrosting interval • Inside humidity/set point humidity • Ambient temperature • High pressure • Low pressure • Power supply voltage • Total operating current • Compressor operating current • Evaporator inlet temperature • Evaporator outlet temperature • Discharge gas temperature • Compressor suction gas temperature • Suction modulating valve opening • Electronic expansion valve opening • Return air temperature (during PTI only) • Supply air temperature (during PTI only) • Pulp temperature (USDA #1, #2, #3) • Cargo temperature 	✓ ✓ ✓ ✓ Optional ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ Optional Optional
5	Self-diagnosis and automatic back-up	<ul style="list-style-type: none"> • Sensor <ul style="list-style-type: none"> Return air temperature sensor Supply air temperature sensor Ambient temperature sensor High pressure sensor Low pressure sensor Voltage sensor Current sensor Evaporator inlet temperature sensor Evaporator outlet temperature sensor Discharge gas temperature sensor Compressor suction gas temperature sensor Humidity sensor Pulp temperature sensor Cargo temperature sensor Data recorder sensor • High pressure switch • Solenoid valve/hot gas modulating valve (leakage check) • Long defrosting • Over-voltage 	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ Optional Optional Optional Optional ✓ ✓ ✓ ✓

No.	Function division	Function	DECOS III c/d
5	Self-diagnosis and automatic back-up	<ul style="list-style-type: none"> • Open-phase running • Over current running • CPU and peripheral device (electronic controller) 	✓ ✓ ✓
6	Manual inspection	<ul style="list-style-type: none"> • Compressor running hour indication • Evaporator fan individual operation (high speed) • Evaporator fan individual operation (low speed) • Condenser fan individual operation • Indication of elapsed time since trip start/time resetting • Evaporator fan run-hour indication • Condenser fan run-hour indication • Controller software version indication • [PC] --- Pulp temperature sensor/cargo temperature sensor calibration • [PC] --- Header information set of data logger • [PC] --- All sensor data indication • [PC] --- Controller built-in relay output display/MV output (opening rate) indication/EV output (opening rate) indication 	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ Optional ✓ ✓ ✓
7	Automatic PTI	<ul style="list-style-type: none"> • Automatic PTI (SHORT) = Operation check of components • Automatic PTI (FULL) 	✓ ✓
8	Data logging	<ul style="list-style-type: none"> • Compressor total running hour • Evaporator fan motor total running hour • Condenser fan motor total running hour • Trip data • Pulp temperature data • Cargo temperature data • Alarm logging data • Automatic PTI data • Event data 	✓ ✓ ✓ ✓ Optional Optional ✓ ✓ ✓
9	Data retrieving (Data output)	<ul style="list-style-type: none"> • [PC] --- Alarm data • [PC] --- Trip data • [PC] --- Automatic PTI data • [PC] --- Pulp temperature data • [PC] --- Cargo temperature data • [PC] --- Event data 	✓ ✓ ✓ Optional Optional ✓
10	Communication	<ul style="list-style-type: none"> • Remote monitoring • Remote control 	Optional Optional
11	Power back-up	<p>※Even while the power is off, the following works are possible.</p> <ul style="list-style-type: none"> • Setting, Temperature setting Humidity setting Defrosting interval setting [PC] --- Container ID data setting • Saving the logger data record • Data retrieving (down loading) 	✓ Optional ✓ ✓ ✓ ✓
12	Chartless	<ul style="list-style-type: none"> • Alarm indication function (H code) • Operation history indication function (D code) • Pull-down time indication function (P code) • Temperature logging data indication on LCD in simple graphic chart 	✓ ✓ ✓ ✓
13	G-SET mode	<p>※To be used when power supply capacity is small.</p> <ul style="list-style-type: none"> • Energy saving operation 	✓
14	Data scroll	<ul style="list-style-type: none"> • Temperature log scroll indication function • Alarm log indication function 	✓ ✓
15	Data input	<p>※The following works are possible using the indication panel</p> <ul style="list-style-type: none"> • Container ID (No.) entering • Controller time setting 	✓ ✓
16	Automatic Pump down	<ul style="list-style-type: none"> • Refelgerant is collected into the receiver and condensor coil. 	✓

3.2 Basic operation of electronic controller

3.2.1 Control panel

Name and function of each components



- | | |
|---|---|
| ① SUPPLY LED (Lights when "supply air temperature" is indicated.) | ⑦ IN RANGE LED (Lights when the control temperature is in range.) |
| ② RETURN LED (Lights when "return air temperature" is indicated.) | ⑧ DE-HUMID.LED (Lights when the controller is the dehumidification control optional.) |
| ③ ALARM LED (Lights when alarm is generated.) | ⑨ Temperature base (Used for the graphic chart indication on the LCD.) |
| ④ R.H.LED (Lights when "relative humidity" is indicated.) | ⑩ Time base (Used for the graphic chart indication on the LCD.) |
| ⑤ COMP.LED (Lights when the compressor is running.) | |
| ⑥ DEFROST LED (Lights when the unit is under the defrosting operation.) | |

Function of operation key



●UNIT ON/OFF key

To start or to stop the unit operation.

The controller has a memory function.

If the power supply is cut off suddenly while the unit is on, and the power supply is then turned on again, the unit automatically starts the operation without pressing this key again. If the power supply is cut off while the unit is off, the unit does not start the operation unless this key is pressed.



●MODE key

To carry out the following control

- ① Generator set (=Power consumption control)
- ② Automatic pump down
- ③ Dehumidification set



●SET key

When the power supply is ON:

- ① Change operation mode from the CURRENT INDICATION MODE to the OPERATION SETTING MODE.
- ② Select the item to be set in the operation setting mode.

When the power supply is OFF:

- ① To change operation modes from the POWER OFF MODE to the BATTERY OPERATION MODE.



●SELECT key

This is not normally used in the basic operation procedure. (This is mainly used in the maintenance procedure.)



●UP key

To select the item to be set in the selected mode.



●DOWN key

To select the item to be set in the selected mode.



●ENTER/ESCAPE key

To determine the setting values or displayed contents in the selected mode.



●G-SET key

To carry out the following control

- ① Generator set (=Power consumption control)
- ② Automatic pump down






CHART key (DISPLAY SELECT key)





If CHARTLESS Function is "ON", this key is effective.

To display logged temperature data in a simple graphic chart on the LCD, press this key when the display reads "set point temperature" or other data. When this is pressed once again, the display returns to "set point temperature" or other data again.









- ① Indicate the temperature data required to be converted into "°F" on the LED or the LCD.
 - ② Press the  key, then the temperature data displayed in "°C" is converted into "°F" for one minute.
- ※ If any other key is pressed during the "°F" indication, the display switches to "°C".


	「°C」 display	「°F」 display
LED		
LCD		



- ① Press the MANUAL DEFROST  key.
 - ② Select "ON" indicated on the LED display using the  key or the  key, and press the  key to determine the setting, then the defrost operation starts.
- ※ Once defrosting operation starts, the operation mode is not changeable until the defrosting operation completes. If this key is pressed during the defrosting operation, it is ineffective.
- ※ Defrosting will not start when the evaporator outlet temperature is 20°C or higher or the inlet temperature is 5°C or higher.

3.3 Operation procedure

3.3.1 Operation procedure flow chart



Check on settings and operation conditions

※1. Current indication mode (indication of operation conditions)		
Indicates the unit operation conditions.	<ul style="list-style-type: none"> ●Supply air temperature (SS) ●Return air temperature (RS) ●Defrost interval ●Alarm ●Setting point humidity and humidity (OPTION) 	Page 3-9
※2. Operation setting mode		
Settings for cargo transportation	<ul style="list-style-type: none"> ●Temperature settings ●Defrost interval settings ●Humidity settings (optional) 	Page 3-10
※3. Battery mode (settings for operation conditions by using the battery)		
Setting can be executed when commercial power supply is not available.	<ul style="list-style-type: none"> ●Temperature settings ●Humidity settings ●Defrost interval settings ●Unit ON/OFF setting 	Page 3-11
※4. Mode operation		
① G-Set : The maximum power consumption can be set in case of operation by generation. ② Automatic pump down : The pump down can be executed automatically. ③ Mode Operation : Dehumidification mode can be set. (option)		Page 3-12
※5. LED display off mode		
LED display section on the controller can be turned off.	<ul style="list-style-type: none"> ●LED lights off 	Page 3-14


Indication of detailed data alarm and PTI

※6. Sensor indication mode	<p>Each sensor value can be indicated.</p> <ul style="list-style-type: none"> ●High pressure (HPT) ●Low pressure (LPT) ●Total current (CT1) ●Compressor current (CT2) ●Voltage (PT1) ●Ambient temperature (AMBS) ●Evaporator inlet temperature (EIS) ●Evaporator outlet temperature (EOS) ●Discharge gas temperature (DCHS) ●Suction gas temperature (SGS) ●Modulating valve opening ●Electronic expansion valve opening ●Supply air temperature (SS) ●Return air temperature (RS) ●Pulp temperature (USDA #1, #2, #3) ●Cargo temperature (CTS) ●Data recorder supply air temperature (DSS) ●Data recorder return air temperature (DRS) [optional] 	<p>Page 3-16</p>
※7. Temperature record scroll function	<p>Temperature record of the control sensor can be indicated in the order (scroll indication) from the latest data.</p> <ul style="list-style-type: none"> ●Chilled mode: Supply air temperature ●Partial frozen mode: Return air temperature ●Frozen mode: Return air temperature (up to 7 days) 	<p>Page 3-18</p>
※8. Alarm record scroll function	<p>Alarm record can be indicated in order (scroll indication) from the latest data.</p> <ul style="list-style-type: none"> ●Alarm indication (up to 7 days) 	<p>Page 3-21</p>
※9. PTI record scroll function	<p>Last 3 PTI results can be displayed.</p>	<p>Page 3-23</p>

3.3.2 Mode operation procedure

1. CURRENT (Operation state) INDICATION MODE

Supply air temperature (SS), return air temperature (RS), defrosting interval, currently existing alarm, set point humidity, and humidity are indicated.



Turn on the circuit breaker and the UNIT ON/OFF key after turning the power supply on, then the display panel switches to the CURRENT INDICATION MODE. (Key operation in the CURRENT INDICATION MODE is possible after approx. 21 seconds from turning on the UNIT ON/OFF key.)

In the CURRENT INDICATION MODE, supply air temperature, return air temperature, defrosting interval, current alarm and current humidity (optional) are shown.

Select an item using the or key. The value of the selected item is indicated on the LED lamp, LED display and LCD display.

Indication item	LED lamp to be lit on	LED display	LCD display
<div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> SUPPLY AIR TEMPERATURE (SS) </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> RETURN AIR TEMPERATURE (RS) </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> DEFROSTING INTERVAL (Def) </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> ALARM (Note 1) </div> <div style="border: 1px dashed black; padding: 5px; margin-top: 5px;"> HUMIDITY (optional, Note 2) (RH) </div>	SUPPLY	Supply air temperature	Set point temperature
	RETURN	Return air temperature	Set point temperature
	Chilled mode: SUPPLY Partial frozen mode: RETURN Frozen mode: RETURN	Chilled mode: SUPPLY air temperature Partial frozen mode: RETURN air temperature Frozen mode: RETURN air temperature	Current defrosting interval setting
	ALARM	All the detected alarms codes or ("Good" if there is no detected alarm)	The total number of detected alarms
	R.H.	Value of humidity sensor	Set point humidity

Note 1) ● Each pressing of the down key, scrolls through the detected alarm codes in sequence when two or more alarm codes are displayed.

After indicating the last alarm, display goes to the next item.


The numerator of the LCD display stands for the current alarm, while the denominator stands for the number of alarm codes existing.

● To erase the d code or H code alarm, depress the key for 3 seconds while the code is displayed.

Note 2) ● The value of the humidity sensor is displayed only when the "Dehumidification Control on/off Setting" is set to "ON", otherwise this item is skipped and the next item is shown.

2. OPERATION SETTING MODE

Control temperature, defrosting interval, and control humidity (optional) can be set.



To change to the OPERATION SETTING MODE, press the [S] key while the unit is in the CURRENT INDICATION MODE.

In the OPERATION SETTING MODE, Control temperature, Control humidity (optional) and Defrosting interval can be set.

Select an item using the [S] key. The value of the selected item is indicated on the LED and LCD display.

Item	LED display	LED display	Setting method
<pre>graph TD; A[CURRENT INDICATION MODE] -- "[S]" --> B[CONTROL TEMPERATURE SETTING]; B -- "[S]" --> C[CONTROL HUMIDITY SETTING (optional Note 1)]; C -- "[S]" --> D[DEFROST INTERVAL SETTING]; B -- "[J]" --> A; C -- "[J]" --> A; D -- "[J]" --> A;</pre>	—	—	—
Current setting temperature Note 2)	"SET-SPC" or "SET-SPF"	Change the value using the key or key. Press the key to determine the setting. Setting temperature range; -30 to 30°C.	
Current setting humidity	"SET-SHU"	Change the value using the key or key. Press the key to determine the setting. Setting humidity range: 60 to 95%RH	
Current defrosting interval	"SET-dEF"	Select a defrost interval 99h, 24h, 12h, 9h, 6h, or 3h using key or key. Press the key to determine the setting. "On demand defrosting" is conducted when "99h" has been selected. (See page 2-23.)	

Note 1) ●When the humidity control is not set, this indication does not appear.


Note 2) ●In case temperature is set in °C setting temperature can be set at interval of 0.1 °C.

In case temperature is set in °F, setting temperature should be the value converted into °F based on °C and rounded off the two decimal places.

3. BATTERY MODE

When commercial power is not available, the following functions are available by using the built-in wake up battery.

- Indication of inside supply air temperature (SS) and return air temperature (RS)
- Setting for control temperature, control humidity and defrost interval



To change to the BATTERY MODE, press the [S] key while the unit is in the POWER OFF STATUS.

In the BATTERY MODE, return air temperature/supply air temperature can be indicated, Control temperature, Control humidity (optional), Defrosting interval and Unit ON/OFF key can be set.

Select an item using the [S] key. The value of the selected item is indicated on the LCD screen.

When no key operation is performed for 30 seconds in the BATTERY MODE, the battery mode turns off automatically off.

Item	LED display	LCD display	Setting method
POWER OFF	—	—	—
RETURN AIR TEMPERATURE DISPLAY(RS)	(Light off)	RS※※※.※C Note 1)	—
SUPPLY AIR TEMPERATURE DISPLAY(SS)	(Light off)	SS※※※.※C	—
FRESH AIR QUANTITY DISPLAY	(Light off)	FA※※	When FA SEN is set to "L" or "H".
USDA1、USDA2 USDA3 (CTS) DISPLAY (optional)	(Light off)	Setting"3" Setting"4" "USDA1" "USDA1" "USDA2" "USDA2" "USDA3" or"USDA3" "CTS"	When USDA is set to "3" or "4".
CONTROL TEMPERATURE SETTING(SP)	(Light off)	"SP C"	Change the value using the key or key. Press the key to determine the setting. Setting temperature range; -30 to +30°C.
CONTROL HUMIDITY SETTING(RH)(optional)	(Light off)	"SHU "	Change the value using the key or key. Press the key to determine the setting. Setting humidity range: 60 to 95%RH
DEFROST (Def) INTERVAL SETTING	(Light off)	"dEF H"	Select a defrost interval 99h, 24h,12h,9h,6h or 3h using the key or key. Press the key to determine the setting. "On demand defrosting" is conducted when "99h" has been selected.
UNIT ON/OFF SETTING	(Light off)	"UNIT ON" or "UNIT OFF"	Change the value using the key or key. Press the key to determine the setting.



Note 1) The inside sensor temperature is indicated on the section of ※※※.※.




CAUTION

If no indication on the LCD panel is displayed by operating the key, it is supposed the wake-up battery is dead.
Replace the battery.

4. MODE OPERATION

Press the  key (or  key) in current indication mode to go to MODE operation.



In mode operation, the following settings/operations are available.

1. Generator setting

Total power consumption can be reduced to desired Max setting for the specific generators set or power facilities.

The selections are "off (No limit)", "15" "14" "13" "12" "11" KVA.

2. Automatic pump down

Pump down can be executed automatically.

(Refer to "Automatic pump down" in clause 4.1.3)

3. Dehumidification mode setting

Dehumidification mode can be executed in this mode (Refer to Dehumidification mode control in clause 2.5.4).

When "Dehumidification" is set to "on", it is possible to change the following set from default.

① Inside humidity : 95% (Default) ~60% RH

Setting item	LED panel	LCD panel	Setting method
<pre> graph TD A[Current indication mode] -- "MODE M" --> B[G-set operation Note 1)] B -- "MODE M" --> C[Automatic pump down operation] C -- "MODE M" --> D[Dehumidification] D -- "(OFF) MODE M" --> A D -- "(ON) MODE M" --> E[Humidity set] E -- "MODE M" --> A style E stroke-dasharray: 5 5 </pre>	—	—	—
	OFF, 11, 12, 13, 14, 15 unit: kVA	G-SET	Select the energy saving set point by using or key, and press the key to determine the setting.
	ON, OFF	P down	Select "ON" by using key and key, and press the key to determine the setting.
	ON/OFF	dHu	Select desired setting by or key, then press key.
	95% RH~60% RH	SET-SHU	Select desired setting by key or key, then press key to determine.

Note 1) If the power supply is turned off in the G-set mode, the mode is cancelled 30 minutes from when power was lost.


5. LED display LIGHT-OFF MODE


The controller LED display is turned off with this mode.

※ Activation of the panel (LED) lighting off mode.

To activate the panel (LED) lighting off mode, set the LED lighting off function "dISP" in "11. Basic setting mode" to ON. Refer to page 3-28.

<Operation procedure>




Push the  key twice during current indication mode to switch to the panel (LED) lighting off mode.

(When pushing the key once, the mode changes to chart indication mode.)

When the panel (LED) lighting off mode activates, the LED lighting is turned off and the LCD reads "dISPOFF".

※ Cancellation of panel (LED) lighting off mode.


When the  key is pushed again, it returns to current indication mode and LED turns ON.

6. SENSOR INDICATION MODE



Each sensor value, the suction modulating valve (SMV) opening, and the electronic expansion valve (EV) opening can be checked. The following items are displayed:


High pressure (HPT), low pressure (LPT), voltage (PT1), total current (CT1), compressor current (CT2), ambient temperature (AMBS), evaporator inlet temperature (EIS), evaporator outlet temperature (EOS), discharge gas temperature (DCHS), suction gas temperature (SGS), suction modulating valve opening, electronic expansion valve opening, supply air temperature (SS) (during PTI only), return air temperature (RS) (during PTI only), pulp temperature (USDA#1, UADA#2, USDA#3) (optional), cargo temperature (CTS) (optional), supply air temperature for data recorder (DSS) (optional), return air temperature for data recorder (DRS) (optional).

<Mode selection procedure>




<Operation procedure>

Whenever the  or  key is pressed, the display changes.



6. SENSOR INDICATION MODE (continued)



LED: The control temperature is displayed.
 LCD: The compressor running current is displayed.
 The display reads: "CT A".
 (In Ampere.)

LED: The control temperature is displayed.
 LCD: The ambient temperature is displayed.
 The display reads: "Ab C".
 (In °C or °F.)

LED: The control temperature is displayed.
 LCD: The evaporator inlet temperature is displayed.
 The display reads: "EI C".
 (In °C or °F.)

LED: The control temperature is displayed.
 LCD: The evaporator outlet temperature is displayed.
 The display reads: "EO C".
 (In °C or °F.)

LED: The control temperature is displayed.
 LCD: The discharge gas temperature is displayed.
 The display reads: "dC C".
 (In °C or °F.)

LED: The control temperature is displayed.
 LCD: The suction gas temperature is displayed.
 The display reads: "SG C".
 (In °C or °F.)


LED: The control opening is displayed.
 LCD: The suction modulating valve opening is displayed.
 The display reads: "SMV %".
 (In % : 0 to 100%)

LED: The control opening is displayed.
 LCD: The electronic expansion valve opening is displayed.
 The display reads: "EV %".
 (In % : 0 to 100%)

(During PTI only)
 LED: The PTI selection and the step No. are displayed.
 LCD: The supply air temperature is displayed.
 The display reads: "SS C".
 (In °C or °F.)

(During PTI only)
 LED: The PTI selection and the step No. are displayed.
 LCD: The return air temperature is displayed.
 The display reads: "RS C".
 (In °C or °F.)


6. SENSOR INDICATION MODE (continued)



7. TEMPERATURE RECORD SCROLL MODE

The control sensor value record is shown in sequence (scroll) starting with the latest data. The latest control temperatures for a maximum of 7 days are displayed.

<Mode selection procedure>



<Operation procedure>

The LED indicates the control temperature, and the LCD displays the data/time and the data record temperature in turn. (In the partial frozen mode and frozen mode, the return air temperature is the controlled temperature, and in the chilled mode, the supply air temperature is the control temperature.)

To pause the scrolling action, press the or key. To continue to the next temperature record manually, press the or key during the holding of indication, or to resume the automatically scroll function, do not press any key for 10 seconds. To see data beginning with start again, press and hold the key for 3 seconds.

To restore the current indication mode, press the key.

If key operation is not performed within 5 minutes, the current indication mode is resumed.






To go to the operation setting mode, press the key.


Temperature record scroll function

The control sensor value record for the last 7 days is displayed in sequence (scroll) beginning with the latest one and ending with oldest one, so that easy inspection of the previous operation data is enabled on board.

<Operation procedure>

The LED indicates the control temperature, and the LCD displays the data or time and the non-control temperature in turn. (In the partial frozen and frozen modes, return air temperature is the controlled temperature, and in the chilled mode, supply air temperature is the controlled temperature.)

To pause the scrolling action, press the  or  key. To advance to the next temperature record, press the  or  key again. If arrow key is not pressed for 10 seconds, the continuous scrolling action is resumed. To see data from the beginning, press and hold the  key for 3 seconds.

To restore the current indication mode screen, press the  key.

If key operation is not performed for 5 minutes, the current indication mode screen is resumed.

If the successive (scroll) screen is currently displayed, the current indication mode screen is resumed when 5 minutes elapses after indication ends.

To return to the operation setting mode, press the  key.



CAUTION


The displayed temperature is not the current instantaneous value but an average taken in a specific logging interval.

Therefore, the printed control temperature on the trip report (instantaneous value) printed with the aid of personal computer may differ from the sensor data of the chartless function.

This is not an error.

● Example of TEMPERATURE RECORD SCROLL INDICATION MODE

※ It is assumed that the control temperature is the supply air temperature (SS) and the logging interval is 1 hour, and the current date and time are June 27, 2002, 14:00.




Note: " " on the leftmost of the LED shows that the indication is of the temperature record scroll indication mode.

8. ALARM RECORD SCROLL MODE






The alarm record is shown in sequence (scroll) starting with the latest data. The latest alarms for a maximum of 7 days are displayed.

<Mode selection procedure>



<Operation procedure>

The LED indicates the alarm codes and the LCD displays date and time.

To pause the scrolling action, press the  or  key. To continue to the next alarm record, press the  or  key during the holding of indication, or to resume the automatically scroll function, do not press any key for 10 seconds. To see data beginning with start again, press and hold the  key for 3 seconds.

To restore the current indication mode, press the  key.

If key operation is not performed within 5 minutes, the current indication mode is resumed.






To go to the operation setting mode, press the  key.


Alarm record scroll function

The alarms detected over the last 7 days are displayed on the controller which scrolls through them at the rate of one sec/alarm.

< Operation procedure >

The LED indicates alarm codes, and the LCD displays date and time.

To pause the scrolling action, press the  or  key. To advance to the next alarm code detected, press the  or  key again. If arrow key is not pressed for 10 seconds, then the continuous scrolling action is resumed. To see data from the beginning, press and hold the  key for 3 seconds.

To return to the current indication mode screen, press the  key.


If key operation is not performed for 5 minutes, the current indication mode screen is resumed.

If the successive (scroll) screen is currently displayed, the current indication mode screen is resumed when 5 minutes elapses after the indication ends.

To return to the operation setting mode, press the  key.

● Example of ALARM RECORD SCROLL INDICATION MODE


※ It is assumed that the current date and time are June 27, 2002, 14:00.




9. PTI RECORD SCROLL MODE

The record is shown in sequence (scroll) starting with the latest data.

<Mode selection procedure>



PTI record scroll function



- ① When "normal" display is on LED/LCD, press
- ② Last PTI data is displayed as left
- ③ Latest 3 data can be displayed by or key

LED : E000 (PTI was good status.)

E001 (Alarm was detected in the PTI)

LCD : Date (Y/MM/DD/TT)


From Now to Past

(Ex. ① 1AM, 4th July, 2002


② 3PM, 23rd May, 2002

③ 9AM, 23rd May, 2002


② × 4 ①



③



③



3.3.3 Setting flow chart

This configuration setting flow shall be utilized, when


CASE 1) USDA transportation setting is required (※10 Optional Function Setting)

CASE 2) Container ID shall to be subjected to change from another container for emergency use.
(※13 Container ID & Time Setting)

CASE 3) Controller is replaced to new one. (All setting in ※10-13 should be set on page 3-25.)

NOTE 1 : All initial settings are pre-setted, when the unit is delivered.

2 : In case to complete the setting change, CIRCUIT BREAKER shall be turned off



Controller initial setting

※10. Optional function mode

- USDA sensor setting
- Dehumidification control on/off setting

Page 3-26

※11. Basic function setting mode

- | | |
|--------------------|---|
| ●Controller type | ●Logging interval |
| ●Compressor unload | ●Data recorder sensor on/off |
| ●Reheat coil | ●Power supply |
| | ●Compressor horse power |
| | ●Indication (LED section) light off function on/off |

Page 3-27

Page 3-28

※12. Optional condition setting mode

- | | | |
|-----------------------------|-------|-------|
| ●Chartless function setting | ●H001 | ●d1-- |
| ●Type of USDA sensor | ●H002 | ●d2-- |
| ●°C/°F set | ●H003 | ●d3-- |
| | ●H004 | ●d-1- |
| | ●H005 | ●d-2- |
| | ●H006 | |

Page 3-29

Page 3-30

Page 3-31

※13. Input data mode

- IContainer I.D. (No.)
- IController time

Page 3-31

Page 3-32

Personal computer and controller


※14. Controller software download mode

Data logged in a personal computer and controller is exchangeable.
For the details, refer to the "Operation manual for personal computer software".

Page 3-32

10. OPTIONAL FUNCTION SETTING MODE


<Key operation to enter/exit>



<Key operation in this mode>

Whenever the **[S]** key is pressed, the display changes.

Turn the power breaker OFF after the setting.



To set the USDA ON/OFF and CARGO TEMPERATURE SENSOR ON/OFF: Select "**OFF** (not in use)", "3 (3 USDA probes are in use)", or "4 (3 USDA probes and 1 cargo temperature sensor are in use)" on the LED while the LCD displays "USdA".

Whenever the **[△]** or **[▽]** key is pressed, the indication of "OFF" or "3" or "4" is changed.

Press the **[↵]** key to determine the setting.

Note: When two USDA probes are connected, the setting will be determined automatically to "3" (3 USDA probes are in use).

To set the DEHUMIDIFICATION CONTROL:

Select "ON" (conducting dehumidifying with humidity sensor), "ON-A" (conducting dehumidifying without humidity sensor) or "**OFF**" (conducting no dehumidifying) on the LED while the LCD indicates "dHU".


Whenever the **[△]** or **[▽]** key is pressed, the indication of "ON", "ON-A" or "OFF" is changed.

Press the **[↵]** key to determine the setting.

Note : This setting can be changed by **[M]** key. (Refer to page 3-12)

11. BASIC FUNCTION SETTING MODE


<Key operation to enter/exit>




<Key operation in this mode>

Whenever the **[S]** key is pressed, the display changes.




Turn the power breaker OFF after the setting.





To set the power input:




Select "Sing" or "dUAL" on the LED when the LCD displays "OC-SET" .

Whenever the  or  key is pressed, the indication of "Sing" or "dUAL" is changed. Press the  key to determine the setting.

For the unit, select "Sing", and press  key to determine the setting.




To set the horse power setting:

Select "5" or "10" on the LED when the LCD displays "HP" (Horse power).

Whenever the  or  key is pressed, the indication of "5" or "10" is changed. Press the  key to determine the setting.

To set the "panel (LED) lighting off" function ON/OFF:



Select "ON" (provided) or "OFF" (not provided) on the LED when the LCD displays "dISP" .

Whenever the  or  key is pressed, the indication of "ON" or "OFF" is changed. Press the  key to determine the setting.

Note: When the 0/CHART key is pressed twice when the "panel (LED) lighting off" function is ON, the lights on the LED panel are turned off.

To set the compressor unloading system:




Select "33 (provided)" or "100 (not provided)" on the LED when the LCD displays "COMP".

Whenever the  or  key is pressed, the indication of "33" or "100" is changed.

Note: This "33" setting is applicable for LXE10D type only.


To set the dehumidification coil ON/OFF:

Select "ON (provided)" or "OFF (not provided)" on the LED when the LCD displays "REHEAT".

Whenever the  or  key is pressed, the indication of "ON" or "OFF" is changed. Press the  key to determine the setting

12. OPTIONAL CONDITION SETTING MODE


<Key operation to enter/exit>




<Key operation in this mode>

Whenever the **[S]** key is pressed, the indication changes.


Turn the power breaker OFF after the setting.






12. OPTIONAL CONDITION SETTING MODE (continued)



12. OPTIONAL CONDITION SETTING MODE (continued)






"d2 --" message displays the total time in hours, that the temperature was above set point +2°C. The code will be displayed after the selected time which can be set to: "1"hour, "2"hours, "3"hours, "4"hours, "5"hours, or "10"hours. When the total time above set point +2°C reaches "1"hour, the code "d101" will be displayed.

Whenever the  or  key is pressed, the selection from "1"hour to "10"hours changes. Press the  key to determine the setting.




Refer to page 3-67.

"d3 -" message displays the total time in hours, that the temperature was above set point +3°C. The code will be displayed after the selected time which can be set to: "1"hour, "2"hours, "3"hours, "4"hours, "5"hours, or "10"hours. When the total time above set point +3°C reaches "1"hour, the code "d101" will be displayed.

Whenever the  or  key is pressed, the selection from "1"hour to "10"hours changes. Press the  key to determine the setting.




Refer to page 3-67.

"d – 1 –" message displays the total time in hours, that the temperature was below set point -1°C. The code will be displayed after the selected time which can be set to: "1"hour, "2"hours, "3"hours, "4"hours, "5"hours, or "10"hours. When the total time below set point -1°C reaches "1"hour, the code "d101" will be displayed.

Whenever the  or  key is pressed, the selection from "1"hour to "10"hours changes. Press the  key to determine the setting.

Refer to page 3-67.


"d - 2 -" message displays the total time in hours, that the temperature was below set point -2°C. The code will be displayed after the selected time which can be set to: "1"hour, "2"hours, "3"hours, "4"hours, "5"hours, or "10"hours. When the total time below set point -2°C reaches "1"hour, the code "d101" will be displayed.

Whenever the  or  key is pressed, the selection from "1"hour to "10"hours changes. Press the  key to determine the setting.

Refer to page 3-67.

13. INPUT DATA MODE


<Key operation to enter/exit>



<Key operation in this mode>

Whenever the **[S]** key is pressed, the indication changes.

Turn OFF the power breaker to confirm the setting.



To input the container I.D. (No.):

Press the **[↵]** key when the LCD displays "SET I.d", then display "i.d.-C" (name of shipping company input with alphabetical character) or "i.d.-n" (number input with numerical character) on the LED by using **[△]** or **[▽]** key.

To input the shipping company name (alphabet):

Press the **[↵]** key when the LED displays "i.d.-C", then the leftmost digit on LCD flashes. Select the alphabet to be input using the **[△]** or **[▽]** key, and press the **[↵]** key, then the flashing digit shifts to the right.

Carry on the same procedure until the 4 letters are input, then press the **[↵]** key to determine the input. Once determined, the input letters will flash.

To input the numbers (numeral):

Press the **[↵]** key when the LED displays "i.d.-n", then the leftmost digit on LCD flashes. Select the number to be input by using the **[△]** or **[▽]** key, and press the **[↵]** key, then the flashing digit shifts to the right.

Carry on the same procedure until the 7 numbers are input, then press the **[↵]** key to determine the input.

Once determined, the input numbers will flash.

To set the control time:

Press the **[↵]** key when the LCD displays "SET TIME", then the LCD displays "YEAR" and the LED shows the year currently set in the controller. Change the setting year by using the **[△]** or **[▽]** key, then press the **[↵]** key to determine the setting.

Then, the LCD displays "MONTH" and the LED displays the month currently set in the controller. Change the setting month by using the **[△]** or **[▽]** key, then press the key to determine the setting.

Set day, time and minute by the same procedure.

Enter the day, hour or minute when "DAY", "HOUR" or "MINUTE" is displayed on LCD respectively.

If the power circuit breaker (CB) is not turned off, the new setting will not be recognized.

14. CONTROLLER SOFTWARE DOWNLOAD MODE

The data on personal computer and a controller are interchanged in this mode.

For details, see the Operation Manual For Personal computer software.

Downloading is possible even in "3. BATTERY MODE". page 3-11.

3.4 Alarm display and back-up function

3.4.1 Alarm list

Alarm grouping		Alarm code	Alarm content	Action with alarm		
Permanent stop		F101	HPS activated within 2 seconds after operation start or protection device activated 5 times at start-up operation or Fuse 1 brown (Refer to Page 7-7).	Unit stops		
		F109	Low- pressure drops to-85kPa or lower within 2 seconds after operation start.	Unit stops		
		F111	HPS does not activate when it reaches to the set value.	Unit stops		
		F301	Temperature setting required (SRAM failure)	Unit stops		
		F401	Return/Supply air sensor malfunction (at chilled mode)	Unit stops		
		F403	Return/Supply air sensor malfunction (at partial frozen mode)	Unit stops		
		F603	Suction modulating valve (SMV) does not fully close contrary to the designation or initial setting of the controller is wrong.	Unit stops		
		F701	Abnormal high voltage (over 530V)	Unit stops		
		F705	S phase became open phase	Unit stops		
		F803	If E101, E103, E105, or E109 is counted for ten times or E107, E201 or E205 is counted for twice, the unit stops and enters the standby mode for four hours.	Unit stops		
Display alone or restartable alarm		Protection device activation		E101	High-pressure switch activated during normal operation.	Restart after 3-minute
				E103	CTP or electronic OC activated during normal operation.	Restart after 3-minute
				E105	Micro processor OC activated during normal operation.	Restart after 3-minute
				E107	The DCHS is excessively hot during operation.	Restart after 3-minute
				E109	The LPT exceeds 400 KPa within five minutes after startup, (when the amount of circulated refrigerant is small) Low pressure drops to-90kPa or lower for 2 seconds or longer successively during normal operaton.	Restart after 3-minute
		Control error		E201	Pump down is not completed within 120 seconds.	Only alarm display
				E203	Overcool protection activates in the chilled or partial frozen mode. (Control temperature \leq SP-3°C or for 3 minutes)	Restart after 3-minutes
				E205	Abnormal lock current at the evaporator fan motor is detected (E205 is displayed if a fan motor is faulty, and F803 is displayed if two fan motors are faulty)	
				E207	Defrosting is not completed within 90 minutes (120 minutes if the inside temperature is -20°C or lower)	Only alarm display
		Printed-circuit board failure		E303	Humidity setting required (SRAM failure)	Only alarm display
				E305	Defrost timer setting required (SRAM failure)	Only alarm display
				E307	Calendar setting required (SRAM failure)	Only alarm display
				E311	Trip-start setting required (SRAM failure)	Only alarm display
				E315	PT/CT board failure	Restart after 3-minutes
				Sensor alarm		E401
		E402	Data recorder supply air temperature sensor (DSS) malfunction			Back-up operation
		E403	Return air temperature sensor (RS) malfunction			Back-up operation
		E404	Data recorder return air temperature sensor (DRS) malfunction			Back-up operation
		E405	Discharge air temperature sensor (DCHS) malfunction			Only alarm display
		E406	Suction gas temperature sensor (SGS) malfunction			Back-up operation
		E407	Evaporator inlet temperature sensor (EIS) malfunction			Back-up operation
		E409	Evaporator outlet sensor (EOS) malfunction			Back-up operation
		E411	Ambient sensor (AMBS) malfunction			Only alarm display
		E413	Low pressure transducer (LPT) malfunction			Back-up operation
		E415	High pressure transducer (HPT) malfunction			Back-up operation
		E417	Voltage sensor (PT1) malfunction			Only alarm display
		E421	Current sensor (CT1) malfunction			Only alarm display
		E423	Current sensor (CT2) malfunction			Restart after 3-minutes
		E425	Pulp temperature sensor (USDA1) malfunction			Only alarm display
		E427	Pulp temperature sensor (USDA2) malfunction			Only alarm display
		E429	Pulp temperature sensor (USDA3) malfunction			Only alarm display
		E431	Humidity sensor (HuS) malfunction			Only alarm display
		E433	Cargo temperature sensor (CTS) or box temperature sensor (CBS) malfunction			Only alarm display
		E805	Ventilator opening detector error or intial setting "FA SEN" to the controller is wrong.			
Electronic functional part alarm		E603	Board of suction modulating valve (SMV) malfunction	Back-up operation		
		E607	MDS (sheet key) malfunction	Only alarm display		
		E707	Momentary power failure	Restart after 3-minutes		

Note 1) The alarm LED does not blink when E code alarm is generated.

To check if any alarm generates, use alarm indication function in the section "1. Current indication mode" of "3.3.2 Mode operation procedure."

2) In case of sensor malfunction, the judgment for sensor malfunction does not perform for 3 minutes before the pressure or temperature reaches to the specified value.

3.4.2 Back-up operation at sensor malfunction

PF : Partial Frozen

Sensor malfunction		Mode	Back-up content
SS	Supply air temperature sensor	Chilled	The same control is executed by using DSS (optional). In case of DSS malfunction, [RS-2.0°C] is used for control. When DSS and RS are faulty, the unit should be stopped.
		PF Frozen Defrost	No influence (continuous operation)
RS	Return air temperature sensor	Chilled Defrost	No influence (continuous operation)
		PF	The same control is executed by using DRS (optional). In case of DRS malfunction, [SS+2.0°C] is used for control. When DRS and SS are faulty, the unit should be stopped.
		DEFROST- ING	The same control is executed by using DRS (optional).
AMBS	Ambient temperature sensor	All modes	Continuous operation
DCHS	Discharge gas temperature sensor	Chilled	Continuous operation
		PF Frozen Defrosting	Continuous operation
EIS	Evaporator inlet temperature sensor	Chilled, PF	Continuous operation
		Frozen	See the next page
		Defrosting	No influence (continuous operation)
EOS	Evaporator outlet temperature sensor	Chilled, PF	Continuous operation
		Frozen	See the next page
		Defrosting	Defrosting start-up: Always permissible Defrosting termination: The 90 minute timer count-up or when EIS>90°C or RS>set point
SGS	Suction gas temperature sensor	Chilled, PF	Continuous operation
		Frozen	See the next page
		Defrosting	No influence (continuous operation)
HPT	High pressure transducer	Chilled PF, Frozen	Continuous operation
		Defrosting	Refrigerant charge: No influence Refrigerant release: LPT is used for releasing.
LPT	Low pressure transducer	Chilled PF, Frozen	Continuous operation
		Defrosting	Refrigerant charge: HPT is used for charging Pump down: Pump down operation is not conducted

●Back-up for temperature sensors (EIS, EOS, SGS) at frozen mode (superheat control)

No.	Evaporator inlet sensor EIS	Evaporator outlet sensor EOS	Compressor suction gas sensor SGS	Back-up operation
1	Normal	Normal	Normal	superheat control
2	Normal	Normal	Abnormal	superheat control
3	Normal	Abnormal	Normal	Liquid refrigerant back prevention to compressor by EIS and SGS
4	Normal	Abnormal	Abnormal	Expansion valve fixed opening rate control
5	Abnormal	Normal	Normal	Liquid refrigerant back prevention to compressor by EOS and SGS
6	Abnormal	Normal	Abnormal	Expansion valve fixed opening rate control
7	Abnormal	Abnormal	Normal	Expansion valve fixed opening rate control
8	Abnormal	Abnormal	Abnormal	Expansion valve fixed opening rate control

3.5 Back Up Battery

3.5.1 Specifications

DECOS III c/d controller can use two types of batteries; DRY or Rechargeable (Optional).

The battery is installed to the lid of the controller.

DRY Battery: 9V block battery. (This can be purchased locally.)

Rechargeable: DAIKIN original rechargeable battery

3.5.2 Function

This battery is used without main power supply for the following functions.

	1) Display wake up	2) USDA data log	3) Trip data log
DRY Battery (Purchased locally)	○	○	—
Rechargeable (Optional)	○	○	○

○ : Available — : Not available

1) Display wake up (Refer to clause 3.3.2) page 3-11.

Setting/Display the following items on the LCD display.

<Display>

Temperature on the return air sensor

Temperature on the supply air sensor

Ventilating volume of USDA1, USDA2, USDA3 (CTS)

<Setting change>

Inside temperature, defrosting interval, dehumidifying set (Optional), Unit ON/OFF

2) USDA data log

USDA sensors data log every 1 hour

3) Trip data log

Trip data log every 1 hour.


3.5.3 Battery check (When using optional rechargeable battery)

1) Rechargeable battery life

The rechargeable battery has a service life of about 2 years.


If the battery has been used for 2 years or longer, USDA data log or trip data log may not be available, even if LED is lit when the battery checked.

2) Battery check



3.5.4 Battery replacement (Rechargeable battery)

First, turn off the power supply to the refrigeration unit. Then, detach the cover of battery and replace the battery. At this time, be sure to use the specified type of battery.



CAUTION

- A Ni-Cd battery is used. Remove the used battery from the refrigeration unit, and then safely collect and dispose it.
- Before scrapping the refrigeration unit, be sure to remove the battery from the unit.


3.6 Information interchange with personal computer

The electronic controller DECOS III c/d has a internal memory function to record the set point temperature, inside temperature, operation mode, occurrence alarm and the report of automatic PTI during transportation in addition to the normal operation control.

Also users can retrieve the logging data and operations condition of the unit and save the information on a personal computer through the serial communication port (personal computer receptacle) provided on the controller front panel. The retrieved data are useful to analyze any problems that occurred during transportation and to prepare various kinds of reports.

Moreover, users can up-load the information such as the container No., cargo name, destination and other information from their personal computer to the controller.

Refer to the Operation Manual for Personal Computer Software for detail.



3.6.1 Data logging

The data logging function is to store operation data which is generated during navigation.

There are seven kinds of logging data.

As to Tripdata, its logging interval can select from 15, 30, 60 (default) and 120 minutes.

※When F. PTI is executed, the logging interval become default (Refer to clause 3.9.2.3)

※Controller has Max. 2 years capacity at 60 min log interval.

	Data name	Logging data	
1	ID data	<ul style="list-style-type: none"> ● Container No. ● Departure port ● Set point temperature ● Set point ventilation flow rate ● Set point humidity ● Comment 	<ul style="list-style-type: none"> ● Loading date ● Load ● Transit place ● Final destination ● Navigation No.
2	Trip data	<ul style="list-style-type: none"> ● Operation mode ● Supply air temperature (SS) ● Return air temperature (RS) ● Inside humidity (optional) ● Ambient temperature (AMBS) 	<ul style="list-style-type: none"> ● Set point temperature ● Set point humidity (optional) ● Data recorder sensor temperature (DSS/DRS) (optional)
3	Alarm	<ul style="list-style-type: none"> ● Alarm output date/time ● Alarm code 	
4	PTI	<ul style="list-style-type: none"> ● SHORT PTI ● FULL PTI 	
5	USDA (optional)	<ul style="list-style-type: none"> ● Pulp sensor temperature (USDA #1 to #3) ● Date/time ● Logging interval is 1 hour. 	
6	Event	<ul style="list-style-type: none"> ● Power ON/OFF ● H code ● D code 	<ul style="list-style-type: none"> ● Unit ON/OFF ● Date/time ● G-SET ON/OFF
7	USDA+CTS (optional)	<ul style="list-style-type: none"> ● Pulp sensor temperature (USDA #1 to #3) and cargo sensor temperature ● Date/time 	

Logged data can be retrieved with the aid of personal computer software.

Refer to the Operation Manual for Personal Computer Software for detail.

3.6.2 Software configuration

	MAIN MENU	SUB MENU	Explanation of functions	Remarks
FIELD JOB	LOGGER DATA DOWNLOAD	TRIP DATA	Data recorded in the logger is read from the controller onto the personal computer (disk or hard disk). (This operation is called the download).	No information appears on the screen at this time.
		USDA DATA		
		4-PULP SENSORS DATA		
		PTI DATA		
		ALL DATA AFTER TRIP-START		
	CONTAINER I.D. /HEADER	SET CONTAINER I.D. /HEADER -From DISK	The logger header (set point temperature, cargo name, destination and other information) is changed. ● Data previously saved on disk is transmitted to the controller.	Disk →Controller
		CHANGE CONTAINER I.D. -From Keyboard	The container No. (container ID) set in the controller is changed.	Input from keyboard
		CHANGE CONTAINER HEADER -From Keyboard	The logger header is changed.	Input from keyboard
		CHANGE CALENDAR	The internal clock on the controller is changed. ● The controller clock is based on GMT (Greenwich Mean Time)	Conversion from personal computer built-in clock
	MAINTENANCE & REPAIR	DISPLAY CURRENT OPERATING DATA	Controller sensor values, operation of internal relay and opening rates of SMV and EV are displayed on the screen.	Record on disk is enabled.
		DISPLAY CURRENT ALARM	Detected alarms are displayed.	
		DISPLAY ALARM LOG	Information of alarm recorded in the logger is displayed.	Record on disk is enabled.
		DISPLAY TEMPERATURE CHART	Fluctuation of control temperature which has been recorded in the logger is displayed in a graphic chart.	
		REPLACE BATTERY	The back-up battery replacement day is set and displayed.	Setting can be also made on the control panel.
	USDA (3-PULP SENSORS) COLD -TREATMENT	CALIBRATION USDA SENSORS	The pulp sensor (USDA sensor) to be used for low temperature transportation is calibrated.	The ice bath is used.
		DISPLAY TEMPERATURE CHART	Fluctuation of the pulp sensor (USDA sensor) temperature which has been recorded in the logger is displayed in a graphic chart. Summary report of trip data is indicated.	
	4-PULP SENSORS	CALIBRATION 4-PULP SENSORS	The pulp sensor (USDA sensor) to be used for low temperature transportation is calibrated.	The ice bath is used.
	COLD -TREATMENT	DISPLAY TEMPERATURE CHART	Fluctuation of the pulp sensor (USDA sensor) temperature which has been recorded in the logger is displayed in a graphic chart. Summary report of trip data is indicated.	

	MAIN MENU	SUB MENU	Explanation of functions	Remarks
OFFICE JOB	MAKE REPORT	TRIP REPORT	Reports are made based on record data read from the logger.	
		USDA REPORT		
		4-PULP SENSOR REPORT		
		PTI REPORT		
		ALARM REPORT		
		MONITOR REPORT		
		EVENT REPORT		
	MAKE CONTAINER I.D. /HEADER	SET CONTAINER I.D. /HEADER into DISK	Disk data to change LOGGER HEADER of controller is created.	
CONFIG SET	<ul style="list-style-type: none"> • CHART MARK • CRT MODEL • SET TIME ZONE • G.M.T-LOCAL TIME 		<ul style="list-style-type: none"> • SELECT JOB • TRIP REPORT Environment using personal computer software is set.	

3.7 Inspection procedure for the electronic controller

DECOS IIIc enables the internal data of the controller CPU (RAM data) to be displayed on the monitor of a personal computer by connecting the two with a communication cable. This makes it possible to preform an easy inspection of the controller and diagnose any defect.

(1) Inspection of sensors

The inspection is carried out by comparing the sensor readings on the controller display with the display on the personal computer. In case the sensor reading is abnormal, the sensor should be replaced with a new one, but **be sure to check the sensor for damage as well as the internal harness and its connectors before replacing.** (Refer to Appendix for the sensor characteristics.)
Page 7-3 and 7-4.

(2) Inspection of the internal relays of the electronic controller

The inspection is carried out by checking the display on the personal computer and the internal relay output (24VAC) on the terminals of terminal board, utilizing the electric tester or test lamp. In case the internal relay malfunctions, the power I/O board should be replaced with a new one, but **be sure to check the internal harness and its connectors for damage before replacing.**

(3) Inspection of the Suction modulation valve

Suction modulation valve is driven by the PCB adapter. If the Suction modulation valve does not function (i.e. if there is no clicking sound, ever though the control display shows the valve opening and closing), then the PCB adapter should be replaced, but be sure to check the internal harness and its connectors for damage before replacing.


(4) Inspection of the electronic expansion valve

If the electronic expansion valve does not operate (no clicking sound) when the valve opening is changed on the controller indication, the electronic expansion valve should be replaced. However, **check on damage of internal harness and poor contact of connector before the replacement.**

(5) Inspection of the cpu board

If the green light on the cpu board is flashing, then the cpu board is working normally.

●Basic internal wiring diagram of electronic controller




3.8 Controller replacement and the initial setting

3.8.1 Controller replacement

<Replacement procedure for the controller>


- (1) Remove speed bolts (2 pcs) on the controller body, then remove the connector.

Be sure to keep voltage indicator, the battery and the battery fixing plate for reinstallation.



- (2) Open the controller body, then disconnect the connectors ② through ⑧ on the terminal board ⑩.


- (3) Disengage clamps ⑨ fixing the harness.



- (4) Remove screws (2 pcs) fixing the controller, and replace the controller with a new one.

- (5) In the reverse procedure, set the connector, the terminal speed bolts and the mounting screws into the original setup.

Install the battery and the voltage indicator removed from the previous controller before replacement by using the battery fixing plate.



CAUTION

Make sure that the connector is firmly connected.

3.8.2 Compatibility of controller DECOSⅢd with Ⅲc and Ⅲb

Applicable model LXE10E-A, LXE10E-1, LXE10D

1. Compatibility, Controller DECOSⅢd to Ⅲc & Ⅲb

※1 Controller DECOSⅢd is standard for all LXE10E-1 and ※6 LXE10E-A manufactured from July 2005

※2 Controller DECOSⅢc is standard for ※7 LXE10E-A manufactured prior to July 2005


※3 Controller DECOSⅢb is applied for LXE10D.

※4 DECOSⅢd is compatible to DECOSⅢc applied for ※7 LXE10E-A.

※5 DECOSⅢd is compatible to DECOSⅢb applied for LXE10D.

For example

When spare parts controller DECOSⅢc is ordered for ※7 LXE10E-A, Daikin will deliver the compatible controller DECOSⅢd if no DECOSⅢc in stock.



How to recognize LXE10E-A with ※6 or LXE10E-A with ※7.

All model names of LXE10E-A with ※7 are listed below. Others are LXE10E-A with ※6.

Model names for ※7 LXE10E-A				
LXE10E-A4	LXE10E-A8	LXE10E-A15	LXE10E-A18A	LXE10E-A27
LXE10E-A5	LXE10E-A9	LXE10E-A15A	LXE10E-A19	LXE10E-A27A
LXE10E-A5A	LXE10E-A9R	LXE10E-A15AR	LXE10E-A20	LXE10E-A28
LXE10E-A5B	LXE10E-A11	LXE10E-A15B	LXE10E-A21	LXE10E-A29
LXE10E-A5BR	LXE10E-A12	LXE10E-A16	LXE10E-A21A	LXE10E-A30
LXE10E-A6	LXE10E-A12A	LXE10E-A17	LXE10E-A24R	LXE10E-A31
LXE10E-A6R	LXE10E-A12B	LXE10E-A17A	LXE10E-A26	
LXE10E-A7	LXE10E-A14	LXE10E-A18	LXE10E-A26A	

After replacing controller, the initial setting and software up-grade are required with following notes.

2. Initial setting to spare controller

Refer the initial setting work to attached [Initial setting procedure for spare controller DECOS III d, III c, III b].

- ※1 Set controller type DECOS III "d" and other items by referring to attached [Initial Setting Table for Spare Controller DECOS III d].
- ※2 Set controller type DECOS III "c" and other items by referring to attached [Initial Setting Table for Spare Controller DECOS III c].
- ※3 Set controller type DECOS III "b" and other items by referring to attached [Initial Setting Table for Spare Controller DECOS III b].
- ※4 Set controller type DECOS III "c", FA SEN "OFF" and other items by referring to attached [Initial Setting Table for Spare Controller DECOS III c].
- ※5 Set controller type DECOS III "b", FA SEN "OFF", REHEAT "OFF" and other items by referring to attached [Initial Setting Table for Spare Controller DECOS III b].


3. Up-grade to the latest software

After replacing controller with spare parts, install the latest software for up-grading.


Download the latest software from DAIKIN HOME PAGE as follows.

The unit can be operated with factory installed software loaded in the spare controller.

However Daikin requests to up-grade the software to the latest version for the best operation.



3.8.3 LXE10E-1, LXE10E-A & LXE10D Initial setting procedure (for spare controller of DECOSⅢ d, DECOSⅢ c & DECOSⅢ b)



3.8.4 LXE10E-1 & LXE10E-A Initial setting table into spare controller DECOSIII d

MODEL NAME Note 1	※10.Optional fun.			※11.Basic function mode							※12.Optional Condition mode												※13.Input Data				
	USdA	dHu	DECOS3	LOG INT	REC SEN	OC-SET	HP	diSP	COMP	REHEAT	FASEN	C/F	CHARTLS	USdA1/2	H001	H002	H003	H004	H005	H006	D1--	D2--	D3--	D4--	D5--	SET ID	SET TIME
LXE10E-1 LXE10E-1A to LXE10E-1E	AU	OFF	d	60	ON	Sing	10	OFF	100	ON	L	F	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A5C to LXE10E-A5E	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	OFF	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A9B LXE10E-A12C to LXE10E-A12F	OFF	OFF	d	30	ON	Sing	10	ON	100	OFF	OFF	C	OFF	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A15C to LXE10E-A15J	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A15BR LXE10E-A15GR	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A18B to LXE10E-A18D	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	OFF	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A19A	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	OFF	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A21B LXE10E-A21D	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	ON	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A23 LXE10E-A23A to LXE10E-A23C	OFF	OFF	d	60	ON	Sing	10	OFF	100	OFF	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT +8
LXE10E-A26B to LXE10E-A26D	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	OFF	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A27B	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A29A	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	ON	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A31A	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A31B	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A32A	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	H	C	OFF	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A32B	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	ON	C	OFF	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A33	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	ON	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A33A	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	ON	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A35	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	OFF	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A35A	OFF	OFF	d	60	ON	Sing	10	OFF	100	OFF	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A35B	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A36	OFF	OFF	d	60	ON	Sing	10	OFF	100	ON	OFF	C	ON	2	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A36A	OFF	OFF	d	30	ON	Sing	10	ON	100	OFF	OFF	C	ON	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A37	OFF	OFF	d	30	ON	Sing	10	ON	100	OFF	OFF	C	ON	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT
LXE10E-A40	OFF	OFF	d	30	ON	Sing	10	OFF	100	OFF	OFF	C	OFF	1	3	2	2	2	3	3	1	1	1	1	1	*	GMT

Note 1. Confirm MODEL NAME stamped in the name plate mounted on the reefer unit.

3.8.5 LXE10E-A Initial setting table into spare controller DECOSⅢc

MODEL NAME Note 1	※7.Optional function		※8.Basic function mode										※9.Optional Condition setting mode															※10.Input Data		
	USdA	dHu	DECOS-Ⅲ	LOG INT	REC SEN	OC-SET	HP	dISP	COMP	REHEAT	CHARTLS	USdA1/2	H001	H002	H003	H004	H005	H006	D1--	D2--	D3--	D-1-	D-2-	C/F	SET I_d	SET TIME				
LXE10E	USdA sensor	Dehumidification control	Controller setting	Logging interval	Data recorder sensor	Input power	Hose power	Panel lighting OFF	Comp. Unload setting	Reheat coil setting	D/H code indication	USdA sensor type												Temp. indication	Container I.D.	Controller set time				
—A4	OFF	OFF	C	30	ON	Single	10	OFF	100	OFF	ON	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A5																														
—A5A	OFF	OFF	C	30	ON	Single	10	OFF	100	OFF	OFF	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A5B																														
—A6																														
—A6R																														
—A12																														
—A12A	OFF	OFF	C	30	ON	Single	10	ON	100	OFF	OFF	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A12B																														
—A28																														
—A7																														
—A11																														
—A20	OFF	OFF	C	60	ON	Single	10	OFF	100	OFF	OFF	2	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A26																														
—A26A																														
—A8																														
—A9																														
—A9R	OFF	OFF	C	30	ON	Single	10	ON	100	OFF	OFF	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A19																														
—A5BR																														
—A14																														
—A15																														
—A15A	OFF	OFF	C	60	ON	Single	10	OFF	100	ON	ON	2	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A15B																														
—A5																														
—A16	OFF	OFF	C	30	ON	Single	10	OFF	100	OFF	ON	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A21																														
—A29																														
—A17	OFF	OFF	C	30	ON	Single	10	OFF	100	OFF	OFF	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A17A																														
—A18																														
—A18A	OFF	OFF	C	60	ON	Single	10	OFF	100	ON	OFF	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A30																														
—A21	OFF	OFF	C	30	ON	Single	10	OFF	100	OFF	ON	1	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A21A																														
—A24R	OFF	OFF	C	30	ON	Single	10	OFF	100	OFF	OFF	1	3	2	2	1	3	3	1	1	1	1	1	C	*	Jpn				
—A15AR																														
—A15B	OFF	OFF	C	60	ON	Single	10	OFF	100	ON	ON	2	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A27																														
—A27A	OFF	OFF	C	60	ON	Single	10	OFF	100	ON	ON	2	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				
—A31	OFF	OFF	C	60	ON	Single	10	OFF	100	ON	ON	2	3	2	2	1	3	3	1	1	1	1	1	C	*	GMT				

Note 1. Confirm MODEL NAME stamped in the name plate mounted on the reefer unit.

3.8.6 LXE10D Initial setting table into spare controller DECOSⅢb

MODEL NAME Note 1	※7.Optional function setting mode		※8.Basic function mode										※9.Optional Condition setting mode																※10.Input Data	
	USdA	dHu	DECOS-3	LOG INT	REC SEN	OC-SET	HP	dISP	COMP	CHARTLS	USdA1/2	H001	H002	H003	H004	H005	H006	D1--	D2--	D3--	D-1-	D-2-	C/F	SET	I d	SET TIME				
LXE10D	USdA sensor connection	Dehumidification control			Data recorder sensor	Input power	Hose power	Panel Lighting OFF	Compressor Unload setting	D/H code alarm indication	USdA sensor type	H code						D code				Temp. indication	Container I.D.	Controller set time						
	OFF	OFF	b	30	ON	Dual Single	10	ON	100	OFF	1	3	2	2	2	3	3	1	1	1	1				1	C	*			
	OFF	OFF	b	30	ON	Single	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*						
	OFF	OFF	b	30	ON	Dual	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*						
	OFF	OFF	b	30	ON	Single	10	OFF	100	ON	1	3	2	2	2	3	3	1	1	1	1	1	C	*	Taiwan					
	OFF	OFF	b	30	ON	Dual	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	GMT					
	OFF	OFF	b	30	ON	Single	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	Hawai					
	OFF	OFF	b	30	ON	Dual	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	GMT					
	OFF	OFF	b	30	ON	Dual	10	ON	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	GMT					
							Single																							
							Dual																							
		OFF	OFF	b	30	ON	Single	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	GMT				
		OFF	OFF	b	30	ON	Single	10	ON	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	GMT				
		OFF	OFF	b	30	ON	Single	10	OFF	100	OFF	1	3	2	2	2	3	3	1	1	1	1	1	C	*	GMT				
	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑					
Spare controller	blank	blank	blank	blank	blank	blank	blank	blank	blank	ON	1	3	2	2	2	3	3	1	1	1	1	1	C	blank		01/1/1				

Note 1. Confirm MODEL NAME mentioned in the name plate mounted on the reefer unit.

3.9 PTI (Pre-Trip Inspection) AND PERIODIC INSPECTION

The controller (DECOS III c) has the automatic PTI function, which consists of three process of SHORT PTI (referred to as S.PTI hereafter), FULL PTI (referred to as F.PTI hereafter) and MANUAL CHECK (referred to as M.CHECK hereafter)

Mode	Operation description
S.PTI	The components are inspected for abnormalities. Even if any abnormal components are found, all processes are executed.
F.PTI	S.PTI + unit cooling capacity inspection are executed. The cooling capacity check is executed only if any abnormal components are not found with S.PTI. If any abnormality is found during the cooling capacity inspection, F.PTI is terminated.
M.CHECK	The functional parts and the operation data can be inspected.

The abnormalities which occur during automatic PTI will be displayed on the controller when the automatic PTI is terminated.

- Refer to section 3.4 for the alarm code checking procedure.
- Refer to section 6.2 for the alarm code contents.

When automatic PTI is terminated, the result of the PTI can be output as a report with using a personal computer. (Refer to the Operation Manual for Personal Computer Software.)

3.9.1 Inspection item

The periodic inspection and adjustment of components (if required) is recommended to ensure continued successful operation.

The following table shows an example of the inspection plan.

	No.	Inspection item	Inspection content	PTI	2 nd year	4 th year	8 th year
General structure	1	Inspection for physical damage		○	○	○	○
	2	Loose mounting bolts	1) Casing frame	○			
			2) Compressor	○			
			3) Condenser fan motor	○			
			4) Evaporator fan motor	○			
			5) Control box	○			
			6) Temperature recorder box	○			
			7) Access panel	○			
			8) Others		○	○	○
	3	Conditions of panel, hinge and lock		○	○	○	○
	4	Drain pan and drain hose cleaning		○			
	5	Control box inspection	1) Cover packing inspection and replacement	○	○	○	○
			2) Loose cable gland		○	○	○
			3) Internal cleaning		○	○	○
Refrigerant system	6	Temperature recorder box inspection	1) Cover packing inspection and replacement	○	○	○	○
			2) Internal cleaning		○	○	○
	7	Sealing condition of holes through casing frame	Air leakage and clearance	○	○	○	○
	8	Packing inspection and replacement	Ventilator cover packing		○	○	○
	9	Painted area recondition	1) Compressor		○	○	○
			2) Water-cooled condenser/liquid receiver		○	○	○
			3) Solenoid valve (coil cap)		○	○	○
			4) Casing frame			○	○
	10	Repainting	1) Compressor				○
			2) Water-cooled condenser/liquid receiver				○
			3) Condenser fan motor				○
			4) Condenser fan				○
Refrigerant system	1	Gas leakage		○	○	○	○
	2	Refrigerant	Inspection of moisture in the refrigerant, and refrigerant charged amount	○			
	3	Inspection of high pressure switch operational pressure		○			
	4	Operation and leakage of solenoid valve	1) Liquid solenoid valve	○			
			2) Economizer solenoid valve	○			
			3) Injection solenoid valve	○			
			4) Hot gas solenoid valve	○			
			5) Defrosting solenoid valve	○			
			6) Discharge gas by-pass solenoid valve	○			
	5	Operation and leakage of suction modulating valve		○			
	6	Operation and leakage of electronic expansion valve		○			
	7	Compressor	Water entering to compressor terminal		○	○	○

	No.	Inspection item	Inspection content	PTI	2 nd year	4 th year	8 th year
Refrigeration system	8	Dryer replacement			○	○	○
	9	Function inspection and replacement of liquid moisture indicator		○			○
	10	Conditions of fasteners on the refrigerant pipes and gauge pipes		○	○	○	○
	11	Condition of thermal insulation of refrigerant pipe			○	○	○
	12	Evaporator coil cleaning (BY water)			○	○	○
	13	Condenser coil cleaning	1) Water-cleaning	○	○	○	○
			2) Steam-cleaning (after pumping down the refrigerant)			○	○
	14	Water-cooled condenser inspection	1) Water-leakage inspection		○	○	○
			2) Operation of water pressure switch		○	○	○
Electrical system	1	Damage of power cable and plug		○	○	○	○
	2	Inspection of conditions of internal wiring		○	○	○	○
	3	Terminal looseness inspection and retightening if necessary	1) Magnetic switch	○	○	○	○
			2) Electronic controller terminal block	○	○	○	○
			3) Terminal block	○	○	○	○
	4	Condition of monitoring receptacle cap		○	○	○	○
	5	Conditions of personal computer receptacle cap		○	○	○	○
	6	Fuse conditions	Burned out or not	○	○	○	○
	7	Magnetic switch contact point inspection and replacement	1) Contact point inspection	○	○	○	
			2) Replace the contact on compressor contactor				○
			3) Replace the contact on compressor fan motor				○
			4) Replace the contact on evaporator fan motor				○
	8	Electric insulation check	1) Power cable and plug	○	○	○	○
			2) Compressor	○	○	○	○
			3) Condenser fan motor	○	○	○	○
			4) Evaporator fan motor	○	○	○	○
	9	Starting procedure inspection		○			
	10	Thermosensor	1) Installation conditions of sensor	○	○	○	○
			2) Inspection of sensor and sensor lead for damage		○	○	○
			3) Indication error inspection and replacement	○	○	○	○
	11	Humidity sensor	Replacement		○	○	○
	12	PT/CT (voltage and current) indication error inspection		○	○	○	○
	13	Pressure sensor indication error inspection		○	○	○	○

	No.	Inspection item	Inspection content	PTI	2 nd year	4 th year	8 th year
Electrical system	14	Temperature recorder inspection	1) Sensor error inspection	○	○	○	○
			2) Chart drive inspection	○			
			3) Recording operation inspection	○			
			4) Loose terminal		○	○	○
			5) Chart drive dry battery inspection	○			
			6) Check of pen lifting battery	○			
	15	Electronic controller	1) Check of wake-up battery	○			
			2) LCD panel replacement			○	○
	16	Evaporator fan motor	1) Speed switchover	○			
			2) Revolution direction	○			
	17	Condenser fan motor	Rotating direction	○			
	18	Evaporator fan	Deformation and damage inspection	○	○	○	○
	19	Condenser fan	Deformation and damage inspection	○	○	○	○
Others	1	Check for abnormal noise and vibration during operation		○			
	2	Temperature control function	1) 0°C operation	○			
			2) -18°C operation	○			
	3	Defrosting function		○			
	4	Unit water-cleaning		○			

※ The service life of the wake-up battery is approx. one year (Dry battery). For USDA transportation, replace the battery with a new Dry battery when PTI is performed.

3.9.2 Automatic PTI (Pre-Trip Inspection)

- The automatic PTI function is provided so as to ensure correct inspection and to shorten inspection time. (Refer to section 3.2 for operation of controller)

(1) Appearance inspection of unit

- ① Physical damage
- ② Casing insulation through hole area
- ③ Drain hose (dust and clogging)
- ④ Power cable and plug damage
- ⑤ Condition of refrigerant piping fasteners.
- ⑥ Condition of each sensor installation
- ⑦ Loose mounting sections
 - Bolts and nuts ----- Casing frame, compressor, fan motor control box and temperature recorder box
 - Cable glands ----- Control box
- ⑧ Conditions of control box cover packing (water-proof) and temperature recorder box cover packing (water-proof)
- ⑨ Magnetic contactor contact point for burning out.

(2) Inspection before unit operation

- ① Gas leakage inspection

- | | |
|----------------------------|-----------------------|
| ② Power voltage inspection | (Automatic PTI range) |
|----------------------------|-----------------------|

(3) Operation inspection of safety device and control equipment

- | | |
|---------------------|--|
| ① Safety device | HPS ----- Measurement of the actuating pressure by stopping the condenser fan motor. |
| ② Control equipment | Solenoid valve ----- Inspection of operation (open and close) and leakage
EFM ----- Speed switchover and rotating direction
EV, SMV ----- Inspection of operation (open and close) and leakage |

(4) Operation in each mode

- | | | | |
|-------------------|-------|---|---|
| ① Pull-down → | 0°C | | Pull-down time, voltage and current |
| ② Chilled control | 0°C | Electronic temperature recorder calibration | Return, supply air temperature differential, voltage and current |
| ③ Defrosting | | | Defrosting time |
| ④ Pull-down → | -18°C | | Pull-down time, evaporator fan motor speed switchover (Temperature differential and rotating direction) |
| ⑤ Frozen control | -18°C | Electronic temperature recorder calibration | ON/OFF, voltage and current |


Remained frost inspection

(5) PTI report preparation



3.9.2.1 PTI selection mode


The test mode of FULL (F.PTI), SHORT PTI (S.PTI), and MANUAL CHECK (M.CHECK) can be selected.


<Mode selection procedure>




<Operation procedure>

Whenever the  or  key is pressed, the indication changes.



To start FULL PTI, press the  key while "F.PTI" is display on the LCD.

To start SHORT PTI, press the  key while "S.PTI" is display on the LCD.

● When the  key is pressed while "M-CHECK" is displayed on the LCD, the manual check selection mode is set.

The detail of the manual check selection mode is described in page 3-60.

● Automatic PTI enable conditions

	Water cooled operation	Air cooled operation	Ambient temperature condition
S. PTI	×	○	$-10^{\circ}\text{C} < \text{Ambient temperature} \leq 43^{\circ}\text{C}$ When the ambient temperature is above 43°C or below -10°C , the correct judgment may not be possible.
F. PTI	×	○	$-10^{\circ}\text{C} \leq \text{Ambient temperature} \leq 43^{\circ}\text{C}$ When the ambient temperature is above 43°C or below -10°C , the following alarm will be indicated. J501: Out of ambient temperature specified condition.
M. CHECK	○	○	

3.9.2.2 Short PTI (S.PTI)


● Step display and content

Step	Content
P00	Basic data record (container No., date, time, compressor integrated run-hour, ambient temperature)
P02	Alarm check on all sensors
P04	Power conditions (voltage and frequency) check
P05	Compressor start running check
P06	Actuating pressure check at OFF and ON of High pressure switch (HPS)
P08	Pump-down check
P10	Solenoid valve leakage check •Liquid solenoid valve (LSV) •Injection solenoid valve (ISV) •Hot gas solenoid valve (HSV) •Defrost solenoid valve (DSV) •Discharge gas by-pass (BSV) •Economizer solenoid valve (ESV)
P12	Supply and return air sensor (SS and RS) accuracy check
P14	Pressure sensor (HPT and LPT) accuracy check
P16	Evaporator fan high and low-speed operation check
P18	Start up
P20	Economizer solenoid valve (ESV) opening or closing check ※1 ※2
P22	Discharge gas by-pass solenoid valve (BSV) opening or closing check ※2
P24	Defrost solenoid valve (DSV) opening or closing check
P26	Standard pull-down operation
P28	Suction modulating valve (SMV) operation check
P29	Electronic expansion valve (EV) operation check
P30	Injection solenoid valve (ISV) opening or closing check ※2
P32	Hot-gas 3-way solenoid valve (HSV) and Reheat coil solenoid valve (RSV -optional) opening or closing check

※1 If the ambient temp is -10°C or lower, the function check of the solenoid valve cannot be preformed correctly, short circuit the terminals 121 and 102 on the terminal board, and check the operation of the solenoid valve.

※2 If the difference between ambient temperature and return air temperature is 15°C or higher, these steps will be skipped.

● S.PTI Flow chart operation




3.9.2.3 Full PTI (F.PTI)

F.PTI consists of S.PTI and operation tests.

●Step display and contents
(step P00 to P32 are as same as S.PTI)

Step	Content
P50	Check on pull-down to 0℃
P60	Check on controllability of chilled mode operation.
P70	Check on defrosting
P80	Check on pull-down from 0℃ through -18℃
P90	Check on controllability of frozen mode operation



3.9.2.4 Alarm list during PTI (Pre-Trip Inspection)

The alarm during automatic PTI are concerned with PTI inspection items in addition to those during normal operation.

The alarms at automatic PTI are indicated in J ※※※., being separated from those during normal operation.

There are some alarms which are not displayed on the control panel, however, they can be checked referring to the PTI report.

Check NO. (LED display)	Check content	Alarm Indication (LED display)	Alarm content	S.PTI	F.PTI	Remarks
P00	Basic data	No indication	Check basic-data	↑ ↓	↑ ↓	
P02	All sensor	Same as normal operation	Check basic-data			
P04	Power supply	No indication	Check basic-data			
P05	Starting	J051	Compressor malfunction			
P06	HPS	J061	Abnormal OFF value			
	”	J062	Not recovered (Not reset)			
	”	J064	High pressure does not rise.			
	”	J065	High pressure does not drop.			
P08	Pump-down	J081	Long pump-down			
P10	Liquid solenoid valve	J101	Valve leakage			
P12	RS, SS accuracy	J121	Sensor deterioration			
P14	HPT, LPT accuracy	J141	Sensor deterioration			
P16	Evaporator fan motor	J161	Evaporator fan motor malfunction			
P20	Economizer solenoid valve	J201	Economizer solenoid valve malfunction			
P22	Discharge gas by-pass solenoid valve	J221	Discharge gas by-pass solenoid valve malfunction			
P24	Defrost solenoid valve	J241	Defrost solenoid valve malfunction			
P26	Operation	No indication	Judged with P28			
P28	Suction modulating valve	J281	Suction modulating valve does not activate			
P29	Electronic expansion valve	J291	Long pump-down			
P30	Injection solenoid valve	J301	Injection solenoid valve malfunction			
P32	Hot-gas solenoid valve	J321	Hot-gas solenoid valve malfunction			
	Reheat coil solenoid valve	J322	Reheat coil solenoid valve malfunction			
P50	Pull-down cooling capacity	J501	Out of ambient temperature conditions		↓	
P50	0°C control	J502	Long pull-down time			
P60	0°C control	No indication				
P70	Defrosting	J701	Out of starting conditions			
		J702	Long defrosting time			
P80	Pull-down cooling capacity	J801	Long pull-down time			
P90	-18°C control	No indication				

Refer to section 6.3 for more information.

3.9.2.5 Manual check (M.CHECK)


Since the components are operated individually differing from S.PTI and F.PTI, the steps can be respectively selected and executed. However, any error occurring during execution of M.CHECK will not be included.

Turn the UNIT ON/OFF key off to terminate the M.CHECK.

● Step indication and contents

Step (indicated on the LCD)	Indication content (indicated on the LED)
CC X10H	Compressor integrated run-hour
EFH A	Running current value of evaporator fan motor high-speed running
EFL A	Running current value of evaporator fan motor low-speed running
CF A	Running current value of condenser fan motor running
TS H	Elapsed time after trip start
EF1 X 10H	Evaporator fan motor 1 run- hour
EF2 X 10H	Evaporator fan motor 2 run- hour
CF X 10H	Condenser fan run- hour
SOFTVER	Controller software version


● M.CHECK flow chart



MANUAL CHECK SELECTION MODE

The LED displays the values of following items:

Compressor operating time, Evaporator fan motor high-speed running current, Evaporator fan motor low-speed running current, Condenser fan motor running current, Battery life, Horse power, Elapsed time after trip start, Evaporator fan motor running time, Condenser fan motor running time, and Controller software version.



To display the compressor operating time:

Press the key when the LCD shows "CC X10H".

The operating time is [the value shown on the LED] X10 hours.

Pushing the key for 3 seconds sets compressor operating time to 0 (hour).

To display the current value of the evaporator fan motor high-speed:

Press the key when the LCD shows "EFH A", then the LED displays the current value. (Unit: Ampere)

To display the current value of the evaporator fan motor low-speed:

Press the key when the LCD shows "EFL A", then the LED displays the current value. (Unit: Ampere)

To display the current value of the condenser fan motor running current:

Press the key when the LCD shows "CF A", then the LED displays the current value. (Unit: Ampere)

To display the elapsed time after trip start:

Press the key when the LCD shows "TS H", then the LED displays the elapsed time. (Unit: Hours).

When the key is pressed and hold for 3 seconds while the elapsed time is displayed the TRIP START is set, and the elapsed time display is reset to "0" (hour).

To display the evaporator fan motor-1 operating time:

Press the key when the LCD shows "EF1 X10H".

The operating time is [the value displayed on the LED] X10 hours.

When the key is pressed and hold for 3 seconds while the evaporator fan motor-1 operating time is displayed, the evaporator fan motor-1 operating time is reset to "0" (hour).

("EF1" stands for the right hand side fan motor looking from the inside of the container.)

To display the evaporator fan motor-2 operating time:

Press the key when the LCD shows "EF2 X10H".

The operating time is [the value displayed on the LED] X10 hours.

If the key is pressed and hold for 3 seconds while the evaporator fan motor-2 operating time is displayed, the evaporator fan motor-2 operating time is reset to "0" (hour).

"EF2" stands for the left hand side fan motor looking from the inside of the container.

To display the condenser fan motor operating time:

Press the key when the LCD shows "CF X10H".

The operating time is [the value displayed on the LED] X10 hours.

If the key is pressed and hold for 3 seconds while the condenser fan motor operating time is displayed, the condenser fan motor operating time is reset to "0" (hour).

To display the controller software version:

Press the key when the LCD shows "SOFTVER".

The value on the LED is the software version.

3.10 Chartless function

The controller provides the temperature recorder function.

In the case of recorder-equipped units, checking for the temperature on the chart recorder will provide ease of monitoring the state of tripping.

Since recent controllers are available for long and accurate temperature recording, non-recorder-equipped units have been increasingly used. In this case, in place of the recorder, the following three "Chartless functions" are available.


- Chart Indication Function
- Pull Down Time Indication Function
- Chartless Code display Function

3.10.1 Chart indication function


The temperature record data is indicated in a graphic chart on the LCD panel in the chart indication mode.

- The displayed log period is selected from 12 hours ([1] HOURS on the time base) or 6 days ([2] DAYS on the time base).
- The displayed intervals are 2 hours for 12 hours log ([1] HOURS) and one day for 6 days log ([2] DAYS).
- The indication of the data during the defrosting is flickered, and the indication of the other chart data is lit on.

● LCD panel




● Example of chart indication




Ex.1

The arrow indicates the temperature change trend when all segments are in the same temperature range.



The graphic chart of the temperature change for 6 day log (time base : 2 (DAYS))




Ex.2



The graphic chart of the temperature change for 12 hours log (time base : 1 (HOURS))

●Displaying temperature change trend:


- The temperature change trend is shown in the leftmost LCD.
- However, this display is shown only when all segments are in the same temperature range.


Trend indication	Condition
	$\left(\begin{array}{c} \text{The latest} \\ \text{data on the} \\ \text{chart} \end{array} - \begin{array}{c} \text{the oldest} \\ \text{data on the} \\ \text{chart} \end{array} \right) > \text{※ set point of H001} \\ \text{(ALARM indication setting)}$
	$\left(\begin{array}{c} \text{The latest} \\ \text{data on the} \\ \text{chart} \end{array} - \begin{array}{c} \text{the oldest} \\ \text{data on the} \\ \text{chart} \end{array} \right) < \text{set point of H001}$ <p>or</p> $\left(\begin{array}{c} \text{the oldest} \\ \text{data on the} \\ \text{chart} \end{array} - \begin{array}{c} \text{The latest} \\ \text{data on the} \\ \text{chart} \end{array} \right) < \text{set point of H001}$
	$\left(\begin{array}{c} \text{the oldest} \\ \text{data on the} \\ \text{chart} \end{array} - \begin{array}{c} \text{The latest} \\ \text{data on the} \\ \text{chart} \end{array} \right) > \text{set point of H001}$

※ According to setting point of H001, trend indication changes.

Refer to page 3-29 optional condition setting mode for the H001 setting procedure.



< Operation procedure >




To shift to the chart indication mode, press the  key while the unit is in the current indication mode.

In the chart indication mode, the LCD displays a simple graphic chart. The ordinate at the left side of LCD screen for temperature base and the abscissa at the bottom of LCD for time base are indicated.

The No. indicated at the time base is the same as the No. on the left most of the LCD, which indicates the simple graphic chart is of 12 hours log or 6 days log indication.

Select the base to be uses using the  or  key.

When the  key is pressed, the unit goes back to the current indication mode.

3.10.2 P code (Pull down time indication)

The control temperature and pull-down time are indicated alternately during pull-down operation.
When the pull-down is completed, the P code will be deleted.
P001: Lasts the pull-down for 1 hour. /P002: 2 houes passed since pull-down started.




Figure1

3.10.3 Chartless code display function

The chartless code represents the coded inside air temperature.

Select "ON" of the chartless code setting to indicate the code on the LED.

For the chartless code setting, refer to the "OPTIONAL CONDITION SETTING MODE" on the page 3-29~3-31.


- P code: Indicates the pull-down time.
- H code: Indicates the abnormal temperature records.
- d code: Indicates the operation history.

3.10.3.1 List of chartless code

C: chilled mode, F: Frozen mode, PF: Partial frozen mode

	Code	Description	Operation mode	Figure
Abnormal temperature record	H001	The alarm is displayed when the control temperature does not decrease by <u>3°C</u> or more for every 4 hours during pull-down operation.	C, F, PF	2
	H002	The alarm is displayed when the total out-of- in-range reaches <u>2 hours</u> . (Count is not performed during defrosting.)	C, F, PF	3
	H003	The alarm is displayed when the integrated time of state "below SP-1°C" reaches <u>2 hours</u> .	C	4
	H004	The alarm is displayed when the integrated time of state "below SP-2°C" reaches <u>2 hours</u> .	C	4
	H005	The alarm is displayed when the control air temperature is Out-of -In-Range and defrosting was performed successively <u>three times</u> while the control air temperature does not return to in-range.	C, F, PF	5
	H006	The alarm is displayed when the integrated time of difference 2 °C or more between control sensor data and record sensor data reaches to <u>one hour</u> or more.	C, F, PF	6
Operation history	d3XX	When the total time above set point +3°C reaches <u>1 hour</u> , the code "d301" will be displayed.	C, F, PF	7
	d2XX	When the total time above set point +2°C reaches <u>1 hour</u> , the code "d201" will be displayed.	C, F, PF	7
	d1XX	When the total time above set point +1°C reaches <u>1 hour</u> , the code "d101" will be displayed.	C, F, PF	7
	d-1X	When the total time below set point -1°C reaches <u>1 hour</u> , the code "d-11" will be displayed.	C, F, PF	7
	d-2X	When the total time below set point -2°C reaches <u>1 hour</u> , the code "d-21" will be displayed.	C, F, PF	7
	PXXX	XXX: When the total pull-down time reaches one hour, an indication XXX=001 appears.	C, F, PF	1

Note 1) The encircled setting can be changed.

Note 2) To delete the H code or d code, press the  key for 3 seconds during the relevant code indicated.

Note 3) H code and d code are deleted when turn off the power supply for 3 days.

3.10.3.2 H-code

H001 =The alarm is displayed when the control temperature does not decrease by 3°C or more every 4 hours during pull-down operation.




Figure2

H002 =The alarm is displayed when the total time out of "in-range" reaches 2 hours. (Counting is not performed during defrosting).




Figure3

H003 =The alarm will be displayed when the total time below setpoint -1°C reaches 2 hours.

H004 =The alarm will be displayed when the total time below setpoint -2°C reaches 2 hours.




Figure4

H005 =The alarm is displayed when the control air temperature is out of "in-range" and defrosting was performed three times while the control air temperature does not return to in-range.





Figure5

H006 =Alarm is displayed when the temperature difference between the control sensor and record sensor is 2°C for 1 hour, or more.



$$|DSS - SS| > 2^{\circ}\text{C} \rightarrow \text{H006}$$

Figure6

3.10.3.3 d-code:


The d-code shows the current operation state of the unit.

Example d101:

- This code "d101" will be displayed when the total time above set point $+1^{\circ}\text{C}$ reaches 1 hour.
The code "d102" will then be displayed when the total time above set point $+1^{\circ}\text{C}$ reaches 2 hours.

Example d-21:

- This code "d-21" will be displayed when the total time below set point -2°C reaches 1 hour.
The code "d-22" will then be displayed when the total time below set point -2°C reaches 2 hours.



Example : If inside temperature was recorded above graph, controller shows the following "d code" when user check the code at "point A"

- d106 (above setpoint $+1^{\circ}\text{C}$ for 6 hours)
- d204 (above setpoint $+2^{\circ}\text{C}$ for 4 hours)
- d302 (above setpoint $+3^{\circ}\text{C}$ for 2 hours)
- d-22 (below setpoint -2°C for 2 hours)
- d-13 (below setpoint -1°C for 3 hours)
- d-11 (below setpoint -1°C for 1 hour)

Figure7

3.11 Communication modem

DECOS III d controller has function to transmit operation data through power line, if slave modem is provided in control box.

The slave modem shall be complied with ISO10368. The following items can be monitored and/or commanded via master modem: (*1)

	Item	Description	
1	Inquiries (Remote monitoring)	<ul style="list-style-type: none"> ● Inside temperature and humidity ● Set point temperature ● Defrosting interval ● Container No. ● Logger header information ● Alarm ● Operation mode 	<ul style="list-style-type: none"> ● Sensor data ● Trip data ● Alarm data
2	Commands (Remote control)	<ul style="list-style-type: none"> ● Set point temperature changing ● Defrosting interval changing ● Manual defrosting initiation 	<ul style="list-style-type: none"> ● Container No. changing ● Unit ON/OFF changing ● Header information changing

(*1) According to the relationship among slave modem, Master modem and controller, items which can monitor and/or command are different. Please contact DAIKIN sales office if you have a specific item to monitor/command.

4. SERVICE AND MAINTENANCE

4.1 Maintenance service


4.1.1 Collection of refrigerant

- ① When release the refrigerant from the refrigerant system, be sure to use a refrigerant recovery unit to protect the ozone layer around the earth from depletion.
- ② Observe strictly all the environmental laws relating with to the country where the repair service is conducted.

4.1.2 Gauge manifold

(1) Attaching the gauge manifold


Turn the valve handle of coupler counterclockwise (the push pin is pulled up). Slide the sleeve upward, and press it against the service port. Then, securely push the valve handle (section A) until a click sound is heard. After the coupler is inserted into the service port, release the sleeve. The coupler is fixed so that it is not detached from the service port. Next, turn the valve handle clockwise. Lower the push pin, and open the check valve at the service port.





CAUTION

1. Use the pressure indicating function of the controller to check the working pressure as much as possible instead of using the gauge manifold in order to prevent foreign particles or moisture from mixing into the refrigerant system.
2. Do not use any of the pressure gauge, gauge manifold, charge hose and charging cylinder which have been used for CFC12 in order to prevent refrigerant or refrigerant oil of a different kind from mixing. Use the exclusive tools for HFC 134a.
3. The service port of quick joint type is provided to make improved handling.



※ Quick joint system



HFC134a (SAE quick joints)	
Low pressure side	
High pressure side	


Be sure to use the gauge manifold with the quick joints shown above.

- Location of service ports on high pressure and low pressure sides
Service ports on high pressure and low pressure sides are located as shown below.




(2) Removal of gauge manifold

Turn the valve handle of coupler counterclockwise (the push pin is pulled up). Slide the sleeve upward while fixing the valve handle (section A) to disconnect the quick joint from the service port.




CAUTION

Be sure to attach the cap to the service port after the removal of the manifold.



Structure of gauge manifold




Open and closed states of gauge manifold

4.1.3 Automatic pump down

An automatic pump down system is applied to the unit to prevent the unit from extra decrease of low pressure due to pump down operation or burning of scroll compressor due to a close stop valve.

(1) Access to automatic pump down operation mode



(2) Use of automatic pumpdown

[1] Replacement of dryer

※After the automatic pumpdown operation is completed, pressure in the pipe in and out of the dryer is slightly higher than the atmospheric pressure.

Thus, although no ambient air will not be entered in the piping, even when the dryer is replaced, replace it quickly in a short period. (For details, see clause 4.2.6)

※Therefore, the system inside does not need to be dried with vacuum after the dryer is replaced.

[2] Recycling refrigerant

※Before recycling refrigerant, execute the automatic pump down operation.

(As for the details, see (2) of clause 4.1.4)





[3] Charging refrigerant (third step)

※ If the ambient temperature is low, and the refrigerant cannot be charged to the specified amount because of pressure balance, execute the automatic pump down operation. (As for the details, see (3) of clause 4.1.4)

(2) Automatic pump down operation

Once the automatic pump down is started, all of the service works from refrigerant collection into the receiver, to the equalizing in suction piping system, can be executed automatically.


When "Good" is displayed, service works such as replacing the dryer, etc. can be conducted without any other operation.

Step	①	②	③	④	⑤
	[Preparation] Turn on Automatic pump down.  Normal operation for 30 minute ※1	[Pump down] ※2 Pump down start  Compressor stop at $LP \leq -55\text{kPa}$	Compressor stop for 20 seconds.	[Pressure equalizing] All stop for 40 seconds.  Increase LPT to 0~300kPa	[Termination] EV full close  Termination "GOOD"
COMP	ON	ON	OFF	OFF	OFF
EFM	High speed	High speed	High speed	OFF	OFF
CFM	ON	ON	ON	OFF	OFF
LSV	ON				
ESV		ON			
ISV				ON (2nd) ※3	
HSV				ON (1st) ※3	
DSV					
BSV					
RSV					
SMV	100%	100%	100%	100%	100%
EV	400pls	800pls	800pls	800pls	0pls(fullclose)


※1. If HPT exceeds 1700 kPa, no operation is executed for thirty seconds.

※2. The pumpdown operation described in ② ⇒ ③ shown in the table above is repeated depending on the status 20 seconds after the compressor is stopped (three times, maximally).

※3. If LPT exceeds 0 kPa 40 seconds after the unit is stopped completely, next operation of shifting from "HSV ON" to "ISV ON" is not executed.



4.1.4 Refrigerant Recovery and Charge




Service work		Service port	Remarks
Pressure Check	High pressure	②	
	Low pressure	①	
Refrigerant recovery and charge (R134a: 4.6kg)	[1] Refrigerant Recovery	⑤	Recover refrigerant from port ⑤ after operating Automatic Pump-Down first.
		④ & ⑤	Recover completely the refrigerant left in the unit port ④ & ⑤.
	[2] Vacuum & Dehydration	④ & ⑤	After recovering, vacuum from port ④ & ⑤. *The connection at port ④ is same size at ① for low pressure.
	[3] Liquid charging	⑤→③※	After vacuuming, charge liquid refrigerant from ⑤ first and them from ③.
			If not reached to the specified amount 4.6 kg, go to next below.
		③※	1. Operate Automatic Pump-Down first and stop it using ON/OFF switch after the compressor stops during the Auto pump down operation. 2. Charge liquid refrigerant from port ③.

Note)※ Charging liquid refrigerant from ① causes malfunction of the compressor.

(1) Operation Pressure Check

Check high pressure from the service port ② on the compressor discharge. Check low pressure from the service port ① on the compressor suction.



(2) Recovery non-condensable gas

If air or other non-condensable gas exists in the refrigerant circuit, it is accumulated in the condenser, which raises pressure in the condenser abnormally high and reduces the heat transfer ratio of the condenser surface resulting in a decrease of the refrigerating capacity. It is, therefore, very important to remove non-condensable gas.


If the discharge pressure is abnormally high and does not return to the normal pressure, inspect if air or any other non-condensable gas exists by the following procedure.

●Conduct automatic pump down operation and stop the unit after collecting the refrigerant into the liquid receiver. Run the condenser fan by using the condenser fan check in the manual check functions, and wait until the condenser cooling air inlet/outlet temperatures become equal. If there is any difference between the saturated pressure corresponding to cooling air temperature and condensing pressure, then non-condensable gas exists. In this case, recover non-condensable gas as stated below.


- ①Conduct automatic pump down
- ②Then collect the gas from the service port ② on the compressor discharge side.
- ③Reading the pressure gauge, collect the non-condensable gas repeatedly until condensing pressure equals saturated pressure.

(3) Refrigerant Recovery

- ①Operate Automatic Pump Dwn.
- ②Recover refrigerant from port ⑤.



- ③Recover completely refrigerant left in the unit from ports ④ & ⑤.



(4) Vacuum-dehydrating, and refrigerant / charging


If all the refrigerant has leaked out and air is intermixed in the refrigeration circuit, remove the cause of trouble and carry out vacuum-dehydrating. Then charge the specified amount of refrigerant.

[Required tools]

1. Refrigerant cylinder (content of 20kg) equipped with joint for HFC134a
2. Gauge manifold with quick joints
3. Weighing scale (up to 50kg)
4. Vacuum pump

(a) Vacuum dehydrating

After recovering the refrigerant, replace the filter drier and connect the vacuum pump to the service ports ④ and ⑤ at the liquid receiver outlet piping and discharge pressure regulating valve inlet, and then vacuum up to 76cmHg. Disconnect the vacuum pump, holding the refrigerant circuit in the vacuum state. However, if air enters in the refrigerant circuit, vacuum up the circuit to 76cmHg and then vacuum the circuit for another 2 hours or more.



(b) Cylinder weight recording

Place a refrigerant cylinder on the weighing scale, and record the weight of the cylinder.

(c) Charging of liquid refrigerant

1. After vacuum & dehydration, charge the liquid refrigerant from port ⑤.
(Approx. 50% of the specified amount will be charged.)




Figure 1

2. Replace the manifold gauge hose to port ③ and add the liquid refrigerant. Then if it reached to the specified amount close the cock of the refrigerant cylinder.




Figure 2

If it is not reached to the specified amount due to the pressure valance, close the cock of the ref. cylinder and go to next 3 & 4.

3. Operate Automatic Pump Down first.
When the compressor stops (※) during the operation, end the Auto. P. D. operation using Unit ON/OFF switch.
(※ The compressor stops twice during the Auto. P. D. operation. It is possible to end either at 1st stop or at 2nd stop.)
4. Open the cock of the ref. cylinder and add the liquid refrigerant from port ③. Then if it reached to the specified amount close the cock of the ref. cylinder.




CAUTION

Carry out the operation check after the replacing and charging of refrigerant, then replace the drier.



4.2 Main components and maintenance

4.2.1 Scroll compressor


The compressor is of a hermetic scroll type with the built-in motor so that there are less places where refrigerant may leak. No refrigerant oil is required when the unit is new because it has been charged before delivery.



(1) Preparation of spare parts compressor



Note 1. Stick the auxiliary cable connection label onto the label stuck on the compressor body. This is only for LXE10E-1.



Note 2. Don't drop the precharged refrigerant oil out after removing the blind flanges.



CAUTION

The preparation of refrigerant oil is not required.
The compressor has been charged with the oil.

(2) Removal of compressor

Recover refrigerant


1. Recover the refrigerant from service port ④ on discharge line and ⑤ at receiver/water cooled condenser outlet.
(Refer to the clause 4.1.4 Refrigerant Recovery and charge)
2. Close the discharge and suction side stop valves on the compressor.

Disconnect cables and mounting bolts

3. Switch off the power.
4. Open the terminal box cover and disconnect the cables.
5. Remove the mounting bolts.

Disconnect pipings

6. Remove the flare nuts for the injection piping on the compressor head and gauge piping on the body.




7. Remove the insulation tape fixed on suction flange and discharge flange.
8. Remove the bolts for suction and discharge flange.

(3) Installation of compressor

Connect pipings and fix mounting bolts


1. Before connecting pipings, insert and screw in the mounting bolts slightly.
2. Tighten the flare nuts for the injection piping and gauge piping on the body.



3. Fix the suction and discharge flanges using with the auxiliary gaskets and the bolts.
4. Tighten the mounting bolts.

Connect cables

5. In case of LXE10E-1 : Check if auxiliary cable connection label for "LXE10E-1" is stuck on the cable connection label of the compressor body.



6. Connect the cables to the terminals.


Note 2. Don't drop the precharged refrigerant oil out after removing the blind flanges.

Attention ! Pay the attention to the cable connection.
Incorrect wiring may run the compressor
in wrong direction and may cause burn out.

**Charge
refrigerant**

7. Open the discharge and suction side stop valves.
8. Vacuum and dehydrate from service port ④ and ⑤.
9. Then charge the refrigerant from service port ⑤ and ③.
(Refer to the clause 4.1.4 Refrigerant Recovery and charge)
10. Check gas leakage especially at suction/discharge flanges and flare nuts for injection piping/gauge piping.

11. Fix the auxiliary insulation tape and fix the auxiliary packing tape using clamp band to the suction flanges.



The diagram shows the pump assembly with the suction and discharge pipes. The suction pipe is connected to a vertical pipe, and the discharge pipe is connected to a horizontal pipe. The pump body is shown with the suction and discharge flanges. The auxiliary insulation tape and auxiliary packing tape are shown being secured to the suction flanges using clamp bands.

12. Seal with silicon sealant around the flare nut for gauge piping.

11. Fix the auxiliary insulation tape

12. Seal with Silicon Sealant



CAUTION

The preparation of refrigerant oil is not required.
The compressor has been charge with the oil.




CAUTION

The unit does not have suction stop valve. Be sure to adhere packing tape at suction piping section to prevent moisture from entering.

(3) Removal of excess refrigerant oil after compressor replacement

The oil plug, oil level gauge and "Removing oil level" are fitted on the spare parts compressor.







○ When the compressor is replaced to spare parts compressor, remove the excess refrigerant oil in the following procedure.

1. First check again whether the discharge/suction side stop valves are opened and the cable connection at terminal is correct.


Preparation 2. Connect manifold to the discharge and suction ports.

3. Operate the unit for about 5 minutes. Stop the unit.

Return the oil to the compressor 4. Operate the S-PTI (Short PTI) and stop at step of "P10".


- (1) Set the ON/OFF switch to ON.
- (2) Push and hold the  key for 3 seconds to enter PTI selection mode.
- (3) Selecting the "S-PTI" mode using the   key and pushing the  key activates the short PTI.
- (4) When "P10" is displayed on the LED, stop the unit.

5. If the oil level can be seen on the oil level gauge, conduct the step 4 oil return operation again.




6. Bypass gas from high pressure side to low pressure side of gauge manifold, adjust the low pressure to 0kPa or more.


7. Loosen the oil drain plug and remove the excess oil.



8. Close the oil plug when no more oil comes out.



9. Take off "Removing oil level" stuck on compressor body.



<Function of step P06 & P08 before P10>
Operate the steps of "P06" and "P08" which are displayed on the LCD.

P06/HPS check:

When the high pressure rises, the circulation rate of refrigerant increases and the oil is expected to return to the compressor.

P08/Pump down check:

The refrigerant contained in the compressor oil is evaporated and separated from the oil.

REMOVING EXCESS COMPRESSOR OIL IS NOT COMPLETED.

REMOVE EXCESS COMPRESSOR OIL. THEN TAKE OFF THIS LABEL

4.2.2 Fan and fan motor


(1) Specification

		Evaporator	Condenser
Fan	Model	Propeller fan	
	Size	440mm	300mm
Motor	Model	3-phase squirrel-cage induction motor	
	Output (60Hz) (Number of poles)	700/90W (2P/4P)	670W (4P)
	Bearing	Shielded ball bearing with rubber seal 6203WNC	Shielded ball bearing with rubber seal 620400NC-X

(2) Installation structure

a. Condenser fan and fan motor


Condenser fan and fan motor



b. Evaporator fan and fan motor

When installing the fan, keep a clearance of 8 mm from the root of the shaft of the fan installing section.

Evaporator fan and motor




(3) Replacement procedure

1) Condenser fan

Remove the fan grille and the fan guide, and loosen the two hexagonal sets of screws on the boss of the fan, then pull the fan forward out.

※If the boss is stuck to the motor shaft, use the bearing drawing tool on the market to pull out the fan.

● How to use bearing drawing tool on the market.




2) Condenser fan motor

- ① Remove the condenser fan.
- ② Disconnect the fan motor cable from the magnetic switch in the control box.
- ③ Remove the fan motor mounting bolts, and replace the motor.
- ④ Install the fan and connect the cable.
- ⑤ After replacement, confirm that the fan is not in contact with the fan guide. (For checking, rotate the fan by hand.)

3) Evaporator fan

Loosen the two sets of screws on the boss portion of the fan, and pull the fan downward out.

※ If the boss is stuck to the motor shaft, use a large spanner as shown below.



4) Evaporator fan motor

- ① After removing the fan at item 3), disconnect the fool proof wire connection.
- ② Remove the motor mounting bolts. (Do not remove the motor mounting base.)
- ③ After replacing the motor, connect the wiring with fool proof wire connection.
- ④ Install the fan.
- ⑤ After replacement, make sure that the fan is not in contact with the fan guide. (To check, rotate the fan by hand.)



CAUTION


Apply the locking agent on the screws of the fan to prevent from loosening. Otherwise, fan may drop from the motor.

4.2.3 PT and CT board (EC9756)

Two function of the measuring device and protector are integrated on this printed-circuit board. This board works as an interface between the main circuit (high voltage) and the controller.


(1) Function

Name	Content
Current measurement (CT1, CT2)	AC 0 to 50A (50/60Hz)
Voltage measurement (PT1, PT2)	AC 150 to 600V (50/60Hz)
Compressor overcurrent protection	Unit with 400V only : 26.0A Unit with 200V and 400V: 15.0A
Phase sequence detection	The phase sequence is detected by sending the voltage waveform to the controller.




(2) Pre-assembly work

Before installing the PT/CT board (spare parts), cut jumpers and remove the mounting plate for the over current setting.



(2-1) Overcurrent setting

Cut jumpers at section A according to the following chart in order to make the over current setting.
Example: over current setting for 10Hp single power



(2-2) Indication of check marks

After cutting jumpers, indicate check marks on the table B.

CASE	Type	Jumper		
		J1	J2	J3
1	Dual 10	○	○	○
2	Dual 5	○	○	○
3	Single 10	○	○	○

Example of check mark indication

CASE	Check
1	
2	
3	✓

(2-3) Removal of mounting plate

Check the following table to see if the mounting plate should be removed. If the mounting plate must be removed, remove the four screws and dismount the mounting plate.

Over current setting and removal of mounting plate

Model		Spare parts	LXE5C	LXE10C	LXE10D	LXE10D LXE10E
Type		—	Dual 5HP	Dual 10HP		Single 10HP
Over current setting value		—	8.5A	15A		26A
Jumpers	J3	⊖—⊖	○ ○	○ ○		⊖—⊖
	J2	⊖—⊖	⊖—⊖	○ ○		○ ○
	J1	⊖—⊖	○ ○	⊖—⊖		○ ○
Mounting plate		Provided	Not to be removed	Not to be removed	To be removed	To be removed

○ ○ : Cut jumper

⊖—⊖ : Do not cut jumper

(3) Replacement procedure



CAUTION

Be sure that the main power is disconnected.

- ① Disconnect the wires routed via CT1 and CT2 from the terminals.
※At this time, take care to prevent CT1 and CT2 from being damaged.
- ② Disconnect the connector (CN1) for the controller and the connector (CN2) for the main circuit.
- ③ Remove four mounting nuts.
- ④ After replacing the PT and CT board, connect the lead wired in reverse order of the above removal procedure.
- ⑤ After checking the wiring once, test-run the system to verify that no trouble is found.


4.2.4 Electronic expansion valve

- Model Coil : EBM-MD12DM-1
Body : EDM-B804DM-1

This unit adopts an electronic expansion valve. The electronic expansion valve controls the optimum refrigerant flow rate automatically, using the temperature sensor at the evaporator inlet and outlet pipes. In case of emergency including controller malfunctions, refer to the chapter of troubleshooting, section 6.5, Emergency operation.


(1) Replacing the coil

- ① Cut the binding bands which fasten the coil and the lead wires.
- ② Disconnect the lead wire of the coil from the controller.
- ③ Remove the silicon sealant on the lock nut.
- ④ Loosen the lock nut, then remove the coil from the body.
- ⑤ Remove the remaining "Lock-tight" on the lock nut mounting threads of the body. Be sure the body inside is dry and clean. Then, apply new "lock-tight".
- ⑥ Install a new coil. Apply the small amount of "Lock-tight" to the threads of EV body (Don't apply too much "Lock-tight".) The tightening torque for installation is 7.0 to 15.0 N · m (73 to 156kgf · cm).
- ⑦ Seal the lead wire and connector with butyl rubber tape. Restore the binding bands and the lead wire connector into the original state.




(2) Replacing the body


- ① Loosen the lock nut, then remove the coil. (Put two wrenches onto the locknut and the unit to remove the coil.)



- ② Remove the hexagonal head bolts, and cut the pipe on the body, then remove remaining pipes from brazing parts.
- ③ Connect a new body to the pipes. Be sure to conduct brazing work while cooling the body below 120°C (248°F) by using wet cloths.
- ④ Fix the body to the mounting base.
- ⑤ Remove the cap, and attach the coil. Apply "Lock-tight" to the lock nut mounting threads, and mount the coil. The tightening torque for installation is 7.0 to 15.0 N · m (73 to 156kgf · cm).
- ⑥ After replacing, carry out refrigerant leakage check, and make sure that there are no leaks.



- ⑦ Apply a silicon sealant to the lock nut section.



4.2.5 Suction modulation valve

The flow rate of suction gas is controlled between 10 to 328pls (3 to 100%) by a stepping motor in order to conduct capacity control operation.

1. Replacing the coil

● Coil removing procedure

- (1) Disconnect the SMV lead wire connector ① from the inside of control box.
- (2) Cut the binding band ③ at the upper rubber cover ① and lower rubber cover ②, then remove the rubber cover ①.
- (3) Cut the tie wrap ⑤ located above the coil ④, then remove it.
- (4) Remove the coil ④ and the lower cover assembly ②.

● Reinstalling of coil

- (1) Mount the lower rubber cover assembly ② and the coil ④.

Note) Engage the dimple ⑧ of coil bracket ⑦ with the dimple (protrusion) ⑨ of coil ④, and adjust the angle as shown in the Fig. D.

Since the angle adjustment is important for control of suction modulating value, carry out the adjusting accurately.

- (2) Fix the coil ④ and coil bracket ⑦ with the tie wrap ⑤ so that the coil ④ and the position of the dimple of coil bracket ⑦ should not be displaced.

Note) Ensure that the tie wrap is not tilted.

- (3) Arrange the lead wires as shown in the Fig. A and Fig. D and fix them with the binding band so that the slack of lead wires should be prevented.

- (4) Replace the upper rubber cover ①.

Note) Set the engaging section of upper cover to fit with the rim of lower rubber cover ⑩.

- (5) Place the binding band ③ to fit the upper and lower covers

Note) Fix the lead wire carefully so that water does not enter into its protecting tube ⑪.
(Fix lead wire with binding band.)

- (6) Connect the connector of lead wire ① to the inside of control box.





Fig. B ② Lower rubber cover ass'y




Fig. C





Fig. D

2. Replacement of body

- (1) Remove the coil. Refer to the section 1.
"Replacing the coil" for removing procedure.
- (2) Remove the heat insulator ① for the SMV after cut the binding band ②.
- (3) Heat up the brazed joint on the piping of SMV body to disconnect the pipe at brazed section.
- (4) Assemble piping of the SMV body, and conduct brazing while keeping the temperature of lower body of SMV below 120°C (248°F) by covering the body with wet cloth.
Note) When brazing, to keep the temperature of body, including valve body, coil, lead wire, etc. below 120°C by supplying water.
In this work, be sure to prevent water from entering into the lead wire protection tube.
- (5) Install the heat insulator ① and fasten it with banding band ②.
- (6) Install the coil. Refer to the section 1.
"Replacing the coil" for removing procedure on the previous page.




4.2.6 Drier

The drier automatically absorbs moisture in the refrigerant while it is circulated. It also commonly works as a filter to remove dust in the refrigerant. Replace the drier if it does not absorb moisture, is blocked, or if the system has been opened to the atmosphere. When installing the new drier, follow the arrow and do not make any mistake about the installation direction of the drier

(1) Replacement procedure

- ① Conduct **the automatic pump down** to collect the refrigerant in the liquid receiver. Refer to page 4-3 and 4-4 for the automatic pump down.
- ② Then, quickly replace the drier with a new one after loosening the flare nuts on the inlet and outlet side of the drier.
- ③ After completing of the replacement of the drier, be sure to conduct refrigerant leakage test to confirm that no refrigerant leakage is occurring.
- ④ Check on the green colour of the liquid / moisture indicator after system operation has started.
- ⑤ Apply a silicon sealant to the flare nut section.
Adhere some anti-corrosion tape.




4.2.7 Solenoid valve

Two kinds of solenoid valves are employed for the unit.


Coil is common and replacement procedure is also almost the same for all types of valves.

Valve name	Symbol	Valve type	Type of coil
Economizer Solenoid valve.	ESV	NEV-202DXF	NEV-MOAB507C
Injection Solenoid valve.	ISV		
Liquid Solenoid valve.	LSV	VPV-803DQ	
Discharge gas by-pass Solenoid valve.	BSV		
Defrosting Solenoid valve.	DSV		
Hot gas Solenoid valve.	HSV		
Reheat Solenoid valve.	RSV		



VPV-803DQ

Fig. 1



NEV-202DXF



Fig. 2

(1) Replacing the coil

- ① Remove the lead wire connector from the inside of the control box, and cut and recover the binding band which fastens the lead wire.
- ② Remove the hexagonal head bolt on the top of the coil to pull the coil out.
- ③ Replace the coil with a new one and restore the hexagonal head bolt, the binding band and connector on the original position.
When reassembling the coil, the tightening torque should be 1.2 N · m (12.2 kg · cm).

(2) Replacement of valve body

- ① Remove the hexagonal head bolt on the top of the coil to pull the coil out.
- ② Remove the hexagonal head bolt of the fixing plate, and cut the two pipes at the side of the valve body.
Disconnect the remaining pipes at the brazed joint sections.
- ③ Insert the new valve body into the pipe and conduct brazing while keeping the temperature of the valve body below 120 °C (248 °F) by cooling.
- ④ Install the coil and restore the hexagonal head bolt of the fixing plate and the connector into their original position.




4.2.8 Discharge pressure regulating valve

- Model KVR15

(1) Replacing the valve

- ① Remove the protection cap to conduct brazing for the valve body.
Be sure not to turn the regulating screw inside the valve, since the pressure has been adjusted to 690 kPa (7.0 kg/cm²).
- ② When brazing, it is required to cool the valve body in order to keep the temperature of valve body below 140 °C by covering the body with wet cloth or the like.
- ③ After brazing work, set and tighten the protection cap.
The tightening torque should be 8 to 10 N·m.
Apply lock-tight, etc. on the screw section to avoid loosening of the cap.
- ④ After replacement, carry out refrigerant leakage check, and make sure there are no leaks.




4.2.9 Check valve

- Model LCV(B)5

(1) Replacement procedure

- ① Remove the pipe clamp which fixes the check valve, then heat up the valve to disconnect the brazed joint.
- ② Install the new check valve taking care to install it in the correct direction, which is the same direction as the arrow shown in the label.
- ③ Conduct brazing while cool the center part of valve with a wet cloth to keep the temperature of the valve body below 120 °C (248° F)
- ④ After replacing the valve, carry out refrigerant leakage check, and make sure that there are no leaks.




4.2.10 High-pressure switch (HPS)

- Model ACB-KB15
- Set point OFF : 2400kPa (24.47kg/cm²)
ON : 1900kPa (19.37kg/cm²)

When the refrigeration pressure of the unit rises abnormally, the compressor stops for safety. The HPS will be activated when the pressure exceeds the set point, as a result of trouble with the condenser fan.

(1) Replacement procedure

- ① Disconnect the lead wire from the control box.
- ② In order to prevent refrigerant from flowing out, disconnect the high-pressure gauge piping from the gauge joint (with check valve) **A** on the compressor side.
- ③ Remove the flare nut **B** and mounting screws of HPS on the casing at the left side of the compressor.
- ④ Replace the HPS. After tightening the flare nut **B**, tighten the flare nut **A**.
- ⑤ After tightening **A**, slightly loosen the flare nut **B**, remove air, and retighten **B**.
- ⑥ After replacing carry out the refrigerant leakage check, and make sure that there are no leaks.



4.2.11 Low pressure transducer (LPT)


Model		Produced before September, 2004	Produced after October, 2004
Transducer type		SPCL02	NSK-BC010F
Identification color	Transducer	Blue seal	Black body
	Connector	Blue tape	Nothing

The LPT is located in the refrigerant circuit.

The operating low pressure value is displayed on the controller indication panel.


(1) Replacing the transducer

- ① Disconnect the lead wire from the control box.
- ② In order to prevent refrigerant from flowing out, disconnect the low-pressure transducer piping from the gauge joint (with check valve) **C** on the compressor side.
- ③ Remove two screws on the clamp plate fixing low pressure transducer in place, and cut the binding bands.




- ④ Remove the heat shrinkage tube, and disconnect the connector from the low pressure transducer.


● SPCL02



● NSK-BC010F



- ⑤ Insert the pressure transducer cable through the heat shrinkage tube, and connect the union joint and connector to the new low pressure transducer. If paint on the low pressure transducer is peeled off, apply clear lacquer.




CAUTION


Do not expose the low pressure transducer to hot air of a dryer for excess time.

Otherwise, the transducer may be damaged.

- ⑥ Apply the heat shrinkage tube in the following position, then shrink it with hot air of a dryer.




- ⑦ Apply sealer between the heat shrinkage tube and the flare nut. (Sealer :KE4898)



- ⑧ Fix the low pressure transducer with the clamp plate, and fix the cable with the binding band.

Fix the shrinkage tube end of the cable side downward for prevention of water entering into the tube.



Fix the tube directing the end downward

4.2.12 High pressure transducer (HPT)

Model		Produced before September,2004	Produced after October,2004
Transducer type		SPCH01	NSK-BC030F
Identification color	Transducer	Red seal	Red & Brown body
	Connector	Red tape	Nothing

The HPT is located in the refrigerant circuit.
The operating high pressure value is displayed on the controller indication panel.



(1) Replacement procedure

The replacement procedure is the same as that for the low pressure transducer.
Make sure that the fixing position and the cable connection is correct.


4.2.13 Air-cooled condenser and evaporator

This finned coil is compact and has uniform heat exchanging performance and high heat exchanging efficiency due to the adoption of corrugated fins.

- Washing of air-cooled condenser
Carefully flush the air-cooled condenser with fresh water after trip, although this type of condenser employs thick fins and electrodeposition coating for high corrosion resistance.
- For the maintenance of the air-cooled condenser, remove the fan grille, fan guide and temperature recorder box. For the maintenance of the evaporator, remove the rear panel of the evaporator.



4.2.14 Fusible plug



● Replacement of fusible plug

If pressure rises abnormally in the refrigeration circuit, the fusible plug is automatically activated, so, thoroughly check the possible causes if the fusible plug melts.


If the fusible plug is activated, the fusible alloy (1) melts and refrigerant blow out (Melting point: 95°C ~100°C).

For replacement, (1)-(3) shall be replaced.





4.2.15 Liquid / Moisture indicator

Liquid/Moisture Indicator permits checking of the refrigerant flow rate and moisture content in the refrigerant.

(1) Moisture indicator



(2) Judgement for refrigerant flow rate (normal, shortage or overcharge)

Operation		Judgement	
Frozen operation	RS < approx. -10°C  Full	Normal	Refrigerant charge is normal if the indicator is full of liquid when RS is under approx. -10 deg. C.
	RS < approx. -10°C  Flashing	Shortage	Refrigerant charge is short if the indicator shows flashing of refrigerant when RS is under approx -10 deg. C.
	RS > approx. -10°C  Flashing	Normal in most cases	Refrigerant charge is normal with flashing in the indicator in most cases, when RS is above approx -10 deg. C.
Chilled operation	 Flashing	Normal in most cases	Refrigerant charge is normal with flashing in the indicator in most cases, during chilled operation with capacity control.

ATTENTION 2 !!
As flashing here does not mean gas shortage, do not charge with additional refrigerant.
Possibly caused by overcharging

ATTENTION 3 !!

In the case of overcharge or shortage of refrigerant, recover all refrigerant from the unit and charge with new refrigerant R134a with rated charged amount of 4.6 Kg (LXE10E-A) or 5.4 Kg (LXE10E-1).

Refrigerant overcharge may cause scroll compressor damage.


4.2.16 Evacuation and dehydrating

After repairing the refrigerant system, vacuum-dehydrate the system before charging the refrigerant.

Vacuum-dehydrating is the process to make the circuit dry by purging the moisture (liquid) in the circuit to outside in state of vapor (gas) using the vacuum pump.

As the pressure lowers below normal atmosphere (760mmHg), the boiling point of water rapidly drops. If the boiling point drops beyond the atmospheric temperature, water will be vaporized.

Example: If the atmospheric temperature is 7.2 °C (45 °F), vacuum-dehydrating will be impossible unless the vacuum degree is lower than -752mmHg. For vacuum-dehydrating, it is important to select and maintain the vacuum pump.



(1) Vacuum pump selection

Select a vacuum pump considering the following two points.

- ① Select a vacuum pump whose vacuum achievability is excellent.
(A vacuum degree of -755mmHg or lower can be achieved.)
- ② The displacement must be relatively large (approx. 40 ℓ /min. or more).
Before vacuum-dehydrating work, be sure to confirm that the pump achieves the vacuum degree of -755mmHg or lower by using the vacuum gauge.

Boiling point of water (°C)	Atmospheric pressure(mmHg)	Vacuum degree(mmHg)
40	55	-705
30	36	-724
26.7	25	-735
24.4	23	-737
22.2	20	-740
20.6	18	-742
17.8	15	-745
15.0	13	-747
11.7	10	-750
7.2	8	-752
0	5	-755

(Reference) Kinds of vacuum pumps and achievable vacuum degree

Type	Achievable vacuum degree Displacement	Application	
		For vacuum-dehydrating	For air exhausting
Oil rotary type (oil-necessary type)	-759.98mmHg 100 ℓ /min.	Applicable	Applicable
Oilless rotary type (oil-unnecessary type)	-750mmHg 50 ℓ /min.	Inapplicable	Inapplicable
	-759.98mmHg 40 ℓ /min.	Applicable	Applicable

Take care that this type is often used as the most convenient type.

With the pump of an oil rotary type, it is important to replace the oil and check the achievability every 1 to 2 months.

(2) Vacuum-dehydrating method

There are two method of vacuum-dehydrating of normal vacuum-dehydrating and special vacuum-dehydrating. In general, the normal vacuum-dehydrating is applied. If any moisture is enters the circuit, apply the special vacuum-dehydrating method.

[normal vacuum-dehydrating]

① Vacuum-dehydrating(first time)

Connect the gauge manifold to the service ports of the liquid line and the outlet of discharge pressure regulator. Run the vacuum pump for 2 hours or longer. (The achievable vacuum degree must be -755 mmHg or lower)

If a pressure of -755mmHg or lower can not be achieved even after pump operation of 2 hours, moisture or leakage may exist in the system. In this case, run the pump another hour or more. If a pressure of -755mmHg or lower can not be achieved even after operation of 3 hours or more, check for leakage.


Note: Evacuate the system from the service ports ④ of both liquid and outlet of the check valve ⑤, because the system is blocked on the way since the liquid solenoid valve is provided on the way of the system.

② Vacuum holding test

Hold the system at a pressure of -755mmHg or lower for 1 hour or longer, and confirm that the vacuum reading does not rise on the vacuum gauge. If it rises, moisture or leakage may exist in the system. However, take care not to leak air from the gauge manifold. If air enters, it is recommended to use the copper tube directly instead of gauge manifold.

③ Charging of refrigerant

After the vacuum-holding test, make the circuit vacuum again for approx. 10 minutes. Then, charge the specified amount of refrigerant through the service port on the liquid line using the charging cylinder.



[Special vacuum-dehydrating]

This method is that the vacuum-breaking process with nitrogen gas is integrated one time or more in the same way as the normal vacuum-dehydrating process.

① Vacuum-dehydrating (first time)

..... 2 hours

② Vacuum-breaking (first time)

Nitrogen gas is pressurized to 0.5kg/cm^2 from the service port on suction pipe. Since nitrogen gas breaks the vacuum, the effect of the vacuum-dehydrating is enhanced. However, if there is much moisture, it can not be removed by this method. Therefore, do not allow water entry or produce water during the refrigerant piping work.


③ Vacuum-dehydrating (second time)

Run the vacuum pump one hour or longer. (The achievable vacuum must be -755mmHg or lower.)

If pressure of -755mmHg or lower can not be achieved even after vacuuming of 2 hours, repeat step ② vacuum-breaking and ③ vacuum-dehydrating.

- ④ Vacuum holding test 1 hour } Same as normal vacuum-dehydrating
 ⑤ Additional charge of refrigerant }

Note: Make sure to use nitrogen gas for vacuum-breaking. (If any oxygen gas is used, it may explode.)



$$(1\text{mmHg}=0.0013\text{kg/cm}^2=0.133\text{Kpa})$$



5. OPTIONAL DEVICES

The following optional devices are available for some models. As for other options, see Chapter 8 in the SUPPLEMENTARY MANUAL.

5.1 Electronic temperature recorder

5.1.1 Standard type

This recorder automatically records the control temperature (either return air temperature or supply air temperature) with the chilled/partial frozen and frozen switching signals from the controller. The faulty sensor detection function and calibration function are integrated for maintenance and inspection.



(1) Specifications

- Model DER9601A
- Power supply AC13V 50/60Hz
- Recording temperature range -30.0 to $+25.0$ °C (-22 to $+77$ °F)
- Chart paper Round type 8-inch pressure-sensitive paper [PARTLOW PSD-217C (REV.A) or equivalent] (31days/rev.)

● Battery

Use	Type	Specification	Standard
Chart drive	R14P (SUM-2)	DC1.5 V U2 (C size) type	JISC8501 IEC60086
Recording pen goes to upper end of the chart	6LR61	DC9V	JISC8511 IEC60086

Battery life

Approx. 1 year (Check with the residual voltage indicator)

- Residual voltage indicator (optional)
 - Green zone : Operable
 - Silver zone : Usable for 7 days
 - Red zone : Replace battery
- Recording pen driving system
 - Pulse motor drive
- Sensor (Thermistor)

Model	Use
ST9503-4	RSS: For supply air temperature recording
ST9503-2	RRS: For return air temperature recording

Note : Recording accuracy

The accuracy of the recorder and the sensor are shown in the following table.

The adjustment with calibration is applicable only on the recorder.


Recording temperature range	Accuracy °C		
	Recorder	Sensor	Total
25°C to 10°C	± 1.0	± 1.0	± 2.0
10°C to -15°C	± 0.5	± 0.3	± 0.8
-15°C to -29.9°C	± 1.0	± 1.0	± 2.0

(2) Devices and schematic wiring diagram

1) Devices

Device	Location
Temperature recorder board	In the temperature recorder box
Recorder return air sensor (RRS)	Evaporator suction area
Recorder supply air sensor (RSS)	Evaporator discharge area

2) Schematic wiring diagram



(3) Checking (Calibration) of the indicated value on the recorder (optional)

This recorder can be checked for its switching function for recording sensors and temperature indication function regardless of inside temperature, and can be adjusted.


1) Switching function for recording sensors

By operating the set temperature on the controller, the temperature recorder automatically switches the recording sensors, return air sensor (for frozen and partial frozen modes) and supply air sensor (for chilled mode)


Set temperature (°C)	Recording sensor
-30.0 to -3.0	Return air sensor
-2.9 to 25.0	Supply air sensor

① Calibration switch

② Battery check button



2) Calibration function



INC : To increase temperature figure
DEC : To decrease temperature figure



CAUTION

During the indoor temperature is stable, recording temperature is adjustable by changing the pen position using the calibration switch. Do not move the temperature recording pen manually.

Notes: 1. The pen is adjusted to suit to the PSD-217C (REV.A) recording chart paper or its equivalent.

Do not use the recording charts other than ones mentioned above.

2. Do not change the position of pen during transportation.


3. When the power is supplied, the pen vibrates momentarily and will return to its original position due to the recording characteristics, but this is not a sign of trouble.

(4) Replacement of temperature recorder

① Turn off the circuit breaker.

② Remove the wiring connector and sensors from the back of the temperature recorder.

③ Remove the hinge on the bottom and the speed bolts on the top.




④ Replace the temperature recorder board.

⑤ After replacement, be sure to check the wiring and operation.

5.1.2 Rechargeable battery type

● Temperature record with power supply turned off

When the power supply is turned off, the pen will move to the outer circumference of recording sheet simultaneously.



● Rechargeable battery

The rechargeable battery is equipped on the electronic temperature recorder.

(Application of rechargeable battery)

- ① Drive of chart
- ② Pen swings up when the main power is turned off (+25°C is recorded.)

(Specifications of rechargeable battery)

- Charge type nickel cadmium battery (7.2V, 600mA)
- Model: 6N-600AA-2

(Replacement reference)

- As reference, 2 to 4 years have elapsed.
- Replace the battery if the pen does not swing up to +25°C when the breaker is turned off.
- Confirm the life of rechargeable battery and make sure the internal gear rotating properly through the rotation check window when the battery was replaced.

5.2 USDA transportation

If USDA receptacles and sensors (Optional) are provided to the unit, the unit can take USDA transportation. (Refer to arrangement of main component in clause 2.2.2.)

5.2.1 Type of USDA sensor/receptacle

Two types of sensors can be installed, according to the type of receptacles.

User should confirm the type of receptacles and select proper sensor in below table.

According to the model, the quantity of receptacle is different. (3 or 4)

Type	Receptacle	Sensor
1	T3107003	ST9702-1
2	HD10-3-96P	NTC type probe

*3 receptacles : USDA 1, USDA 2, USDA 3

4 receptacles : USDA 1, USDA 2, USDA 3, CTS (Cargo temperature sensor)

5.2.2 Initial setting

User should confirm initial setting of controller as below.

- 1) USDA transportation ; Initial setting mode at page 3-29.
Quantity of receptacles should be set
- 2) Type of USDA sensor
Type of USDA sensor should be set.

5.2.3 USDA sensor calibration

USDA requires sensor calibration every transportation and report each offset figure. Free-supply downloading software enable to assist this. Please refer to "Operation manual for Daikin Container Communication Software".


5.2.4 USDA transportation requirement

Cargo and refrigeration unit shall be required pre-cooling before cargo loading. As to position of USDA sensors and operation, please refer to the guidance of USDA.


5.2.5 USDA report required by USDA local officer

Free supply downloading software enables you to make document easily, which USDA local officer requires. In detail, please refer to "Operation manual for Daikin Container Communication Software".

●An example of installation of USDA receptacle inside



●USDA sensor




5.3 TransFRESH

Attachment for the TransFRESH CA devices are provided to control the internal atmosphere (quantity of O₂ and CO₂).


Use the CA devices according to the Operation Manual supplied by TransFRESH. The controller and sensor included in the CA devices are installed by the TransFRESH's agents before each transportation.

- An example of installation of CA devices, outside.



- ① TransFRESH SECURITY ENCLOSURE
- ② TransFRESH COMMUNICATION BRACKET
- ③ TransFRESH Single purge port

●An example of installation of CA devices, inside



① TransFRESH ASS'Y A4&A5 CABLES W/MOUNTING BOX

6. TROUBLESHOOTING

6.1 Refrigeration system and electrical system

If the unit does not work properly, refer to the following table to find causes of trouble and provide appropriate measures.


	Symptom	Cause	Checkpoint	Remedy
I Unit does not operate	A. Neither evaporator fan, condenser fan nor compressor runs.	Faulty power supply	Voltage on primary side of circuit breaker It should be within the voltage range shown in page 1-1.	Check the power supply Check the power supply plug Check for disconnection of cable
		Failure in running of evaporator fan	Ensure that the condenser fan is stopped while high pressure is under control. (Increase the high pressure compulsorily, and make sure that the evaporator fan stops when the HPT is 1000 kPa or more.)	The unit is normal if the condenser fan is stopped while the HPT is 1000 kPa or more
			Megger check on secondary side of electromagnetic contactor (Evaporator fan motor, condenser fan motor, compressor)	Replace faulty equipment
		Controller	Unit switch ON/OFF check	Turn the switch ON
			Alarm presence (F code)	See the instructions for alarm code of electronic controller in section 6.2
		Secondary side of power supply transformer	Check for disconnection of Fu1 (fuse) Check for malfunction in object models shown in section 7.12	Replace the Fu Replace faulty equipment
			Check for disconnection on secondary side of transformer (Tr) Screwed crimp type terminal board: Check of 24V at CN5 Connector type terminal board: Check of 24V between lead wires 103 and 108	Replace the transformer
	B. Evaporator fan runs, but condenser fan and compressor do not run.	Not malfunction (thermo-OFF status)	Display of controller (ALARM display)	See the alarm code when ALARM is issued
	C. Evaporator fan and compressor run, but condenser fan does not run.	Not malfunction (high pressure control)	Check of operation of HPT (E101) by controller display	See section 6.2
		External factor	Visual check for foreign matters caught in and deformation (including relevant parts such as controllers)	Remove foreign matters
	D. Condenser fan and compressor run, but evaporator fan does not run.	Faulty electrical system of evaporator fan · CTP running · Motor seizure (disconnection) · Disconnected coil of electromagnetic contactor	Controller display E205 (Faulty 1 unit of EFM) E803 (Faulty 2 units of EFM) ↓ · Motor coil resistance · Ensure that the electromagnetic contactor is turned ON · Voltage on secondary side of electromagnetic contactor (three-phase)	· Replace the fan motor · Replace the electromagnetic contactor
		External factor	Visual check for foreign matters caught in and deformation (including relevant parts such as controllers)	Remove foreign matters
	E. Compressor runs, but evaporator fan and condenser fan do not run.	Not malfunction (defrost)	Check the lighting status of LED (red) of DEF on control panel	

Symptom	Cause	Checkpoint	Remedy
I Unit does not operate F. Evaporator fan and condenser fan run, but compressor does not run (throbs)	Faulty power supply of compressor system Burnt-out of compressor motor (disconnection) Faulty connection of terminal board of compressor (disconnection, entering of water) Disconnection of magnetic contactor coil Faulty controller (Ry) Faulty RPP (reverse phase protector)	<p>Is the magnetic contactor for compressor turned ON?</p> <p>YES → Check for disconnection of compressor motor coil Check the terminals Check the voltage</p> <p>NO → Is the voltage between the wiring 134 and 155 24V AC?</p> <p>YES → Faulty coil of magnetic contactor for compressor</p> <p>NO → Is the voltage between the wiring 133 and 134 (1-2 of CN37) 24V AC? ※1※2</p> <p>YES → Faulty RPP operation</p> <p>Normal phase?</p> <p>YES (Normal phase) → Replace RPP</p> <p>NO (Reverse phase) → Check the controller and compressor</p> <p>NO → Faulty controller Ry</p> <p>※ 1. Screwed clamp type terminal board</p> <p>※ 2. Connector type terminal board</p> <p>※ Refer to Schematic wiring diagram</p>	
	Stopped if the main power supply voltage drops and E103 or E105 occurs to the compressor	All the three phases should be AC 300 V or higher	

Symptom		Cause	Checkpoint	Remedy
I	Unit does not operate	Disconnection of fuse Fu1 circuit Faulty controller Faulty PT/CT board	<pre> graph TD Q1{Is the fuse Fu1 circuit disconnected?} -- YES --> R1[Replace the fuse Fu1] Q1 -- NO --> R2[Replace the controller or PT/CT board] </pre>	
	Power supply of the controller cannot be turned on	R or T-phase is open Faulty power supply (voltage drop) Disconnection of power cable Faulty power plug Disconnection of fuse Fu5 circuit Faulty transformer	<pre> graph TD Q1{Is the voltage of three-phase power supply on the primary side of the circuit breaker 300 V or less?} -- YES --> R1["* R or T-phase is open * Faulty power supply (voltage drop) * Disconnection of power cable * Faulty power plug"] Q1 -- NO --> Q2{Is the fuse Fu5 circuit disconnected?} Q2 -- YES --> R2[Replace the fuse Fu5] Q2 -- NO --> Q3{Is the voltage at CN5 of TB1 20 V or less?} Q3 -- YES --> R3[Replace the transformer TrC] Q3 -- NO --> R4[Replace the controller] </pre>	
II	A. Unit operates but soon stops (full stop) E101, F101, E103, E105, E107, E109, F109	See the Alarm Code table	_____	_____
	B. Evaporator fan runs, but condenser fan and compressor do not run.	Thermo OFF (normal)	_____	_____
	C. Compressor runs, but condenser fan and evaporator fan do not run.	Defrost (normal)	_____	_____

Symptom	Cause	Checkpoint	Remedy
III Inside temperature does not drop The high pressure is excessively high The low pressure is excessively low The low pressure is excessively high Frosted compressor body or suction pipe	Refrigerant shortage Blocked pipe (parts) (including solenoid valves) Trap of air in refrigerant system	Gas leak check YES → Gas leaks ⇒ Restore the gas leaking portion NO →	
	Faulty discharge pressure control valve DPR	Is the difference in pressure between the ports ② and ⑤ 1000 kPa or more? YES → Clogged section between the ports ② and ⑤ or DPR operation is faulty ⇒ Replace the DPR NO →	
	Faulty liquid solenoid valve LSV	Is the difference in pressure between the ports ⑤ and ③ 100 kPa or more? YES → Blocked section between the ports ⑤ and ③ or blocked LSV ⇒ Replace the LSV NO →	
	Blocked dryer	Is the difference in temperature of the pipe in front of and that back of dryer filter 5°C or more? YES → Check for clog in a dryer ⇒ Replace the dryer NO →	
	Entering of air	Check for entering of air referring to clause 4.1.4 (2) YES → Air is entering ⇒ Replace refrigerant NO →	Note: Recover refrigerant when replacing it
	Faulty high pressure transducer HPT	Is the difference in pressure between the pressure gauge and HPT 100 kPa or more? YES → Faulty HPT ⇒ Replace the HPT NO → Gas shortage ⇒ Replace the refrigerant	

Symptom	Cause	Checkpoint	Remedy
III Inside temperature does not drop The high pressure is excessively high	Solenoid valve internal leak	Check for leak from solenoid valve during pull-down. Is the temperature in the piping on the BSV, HSV, and DSV outlet side high? YES → Leak from solenoid valve ⇒ Replace the solenoid valve NO →	BSV: Discharged gas bypass solenoid valve HSV: Hot gas solenoid valve DSV: Defrost solenoid valve
	Reverse rotation of condenser fan	Does the condenser fan rotate reverse? YES (Reverse rotation) → Check the wiring on secondary side of solenoid contactor for condenser fan NO (Normal rotation) →	
	Ambient temperature is high Short circuit	Is the discharge air temperature at condenser 50°C or higher? YES → Out of operation range Restore short circuit at discharge air NO →	
	Is the condenser water-cooled? Low water level Water temperature is high	Is the condenser water-cooled? YES → Is the water piping valve fully open? YES → Low water level ⇒ Check the facility NO → Fully open the valve NO → Visually check for clog and dirt at the fin of air cooled condenser YES → Clogged ⇒ cleaning NO →	
	Clogged heat exchanger of condenser		
	Entering air Overcharge Wrong refrigerant type	Check for entering of air referring to clause 4.1.4 (2) YES → Is the HPS operated? YES → Overcharge Entering of air, wrong refrigerant type ⇒ Replace the refrigerant NO → Trap of air, wrong refrigerant type ⇒ Replace the refrigerant NO →	
	Compressor internal leak	Check for leak from the solenoid valve S-PTI alarm J101? (P10) YES → Faulty compressor ⇒ Replace the compressor NO →	
		Overcharge ⇒ Replace the refrigerant Water cooling: Water temperature is high, water cooled condenser is dirty ⇒ Check the facility, or clean or replace the water cooled condenser	

	Symptom	Cause	Checkpoint	Remedy
III Inside temperature does not drop	The low pressure is excessively low		<p>Continue from previous page</p> <p>Remove the electronic expansion valve coil</p> <p>Blow air into the electronic expansion valve and heat the valve by a dryer</p> <p>NO</p> <p>Is pull-down possible?</p> <p>YES</p> <p>Replace the valve</p> <p>Replace the dryer</p>	<p>Restore the electronic expansion valve (see the pictures below)</p> <ol style="list-style-type: none"> (1) Apply Lock-tight sealant to the threads (2) Apply Lock-tight sealant to the metal touch section (3) Apply silicone sealant to the flare nut (4) Fix the cable at two positions 
	The low pressure is excessively high	Solenoid valve internal leak(BSV, DSV, HSV) Solenoid valve internal leak(ISV) Faulty compression by compressor	<p>Normal operation</p> <p>Is HSV, DSV, BSV outlet pipe hot?</p> <p>YES (Hot)</p> <p>NO (Cold)</p> <p>Is the ISV outlet pipe hot?</p> <p>YES (Hot)</p> <p>NO (Cold)</p> <p>Circuit breaker OFF→ON</p> <p>Is pull-down possible?</p> <p>YES</p> <p>NO</p>	<p>Leak from solenoid valve ⇒Replace</p> <p>*HSV: Hot gas solenoid valve *DSV: Defrost solenoid valve *BSV: Discharge gas bypass solenoid valve</p> <p>Leak from solenoid valve ⇒Replace</p> <p>*ISV: Injection solenoid valve</p> <p>Finish</p> <p>Replace the compressor</p>

Symptom	Cause	Checkpoint	Remedy
IV Inside temperature does not rise (during heating operation) The high pressure is excessively low The discharge gas temperature is low The low pressure is excessively high	Faulty operation of valve (HSV or DSV) Faulty operation of high pressure transducer HPT (charging is impossible) Faulty operation of low pressure transducer LPT (charging is impossible) Displacement of HPT, DCHS (Stop of evaporator fan) Stop of evaporator fan Reduced heating air volume (stop or drop of evaporator fan) Pressure leak to condenser due to leak from discharge pressure control valve (DPR) Leak from ISV⇒ Charge control is unavailable	<pre> graph TD Start[Heating operation] --> D1{Is the outlet piping of HSV, DSV cold?} D1 -- YES --> R1[Faulty operation of HSV, DSV⇒Replace] D1 -- NO --> D2{Is the difference in pressure between the pressure gauge and HPT 100 kPa or more?} D2 -- YES --> R2[Faulty HPT⇒Replace] D2 -- NO --> D3{Is the difference in pressure between the pressure gauge and LPT 30 kPa or more?} D3 -- YES --> R3[Faulty LPT⇒Replace] D3 -- NO --> D4{Is the DCHS or heat insulator installed inappropriately?} D4 -- YES --> R4[Correct installation of DCHS] D4 -- NO --> D5{Is the magnetic contactor (high speed) for evaporator fan motor turned OFF?} D5 -- YES --> R5[Faulty DCHS temperature detection⇒Replace] D5 -- NO --> D6{Is the evaporator fan motor stopped?} D6 -- YES --> R6[Faulty motor⇒Replace] D6 -- NO --> D7{HPT < 700kPa ?} D7 -- YES --> R7[Leak from DPR⇒Replace the DPR] D7 -- NO --> R8[Leak from ISV⇒Replace the ISV] </pre> <p>※ DCHS: Discharge pipe temperature sensor</p>	

Symptom	Cause	Checkpoint	Remedy
V Control is unstable (during chilled proportional control operation)	The control temperature is unstable	<div> <div>Operating temperature is hunting</div> <div> <div>Is the difference in pressure between the pressure gauge and LPT 30 kPa or more?</div> <div> <div>YES</div> <div>Replace the LPT</div> </div> <div>NO</div> </div> <div> <div>Is the DCHS or heat insulator installed inappropriately?</div> <div> <div>YES</div> <div>Correct installation of DCHS</div> </div> <div>NO</div> </div> <div> <div>The SMV opening is fixed to approx. 24%</div> <div> <div>YES</div> <div>Reset the opening of SMV (Circuit breaker ON)</div> </div> <div>NO</div> </div> <div> <div>Check the BSV connector or lead wire</div> <div>※ BSV: Discharge gas bypass solenoid valve</div> </div> </div>	
	Faulty low pressure transducer LPT		
	Faulty discharge pipe temperature sensor DCHS		
	Faulty opening of suction modulating valve SMV		
	Faulty contact of solenoid valve (BSV)		

Symptom		Cause	Checkpoint	Remedy
V	Control is unstable (during chilled proportional control operation)			
	Temperature continues to decrease	<ul style="list-style-type: none"> Disconnection of fuse (Fu2) circuit Faulty operation of defrost solenoid valve DSV Stop of evaporator fan Faulty operation of suction modulating valve SMV 	<pre> graph TD Start[Temperature continues to decrease] --> D1{Check for disconnection in the Fu2 circuit} D1 -- YES --> R1[Replace the Fu2] D1 -- NO --> D2{Is the DSV outlet pipe cold?} D2 -- YES --> R2[Check operation of the DSV => Replace the DSV] D2 -- NO --> D3{The evaporator fan stops} D3 -- YES --> R3[Check the fan motor] D3 -- NO --> R4[Check the SMV] </pre>	
	Temperature continues to increase	<ul style="list-style-type: none"> Excessive frost on evaporator Opened discharge gas bypass solenoid valve BSV (dusts caught in) Excessive frost on evaporator 	<pre> graph TD Start[Temperature continues to increase] --> D1{Is the opening of the SMV 36% or more?} D1 -- NO --> Start D1 -- YES --> D2{Is the BSV outlet pipe hot?} D2 -- YES --> R1[Check operation of the BSV => Replace the BSV] D2 -- NO --> R2[Manual defrost] </pre> <p>※ As for the manual defrost, refer to page 2-23.</p>	
VI	Abnormal noise or vibration	Malfunction of compressor inside	Auditory check	Replace
		Fan motor of evaporator, condenser	Auditory check	Replace the unit
		<ul style="list-style-type: none"> Worn bearing Interference with fan guide 	Auditory check Visual check	Replace the faulty parts
	Abnormal vibration	Compressor, fan motor	Auditory check Visual check	Tighten bolts
		Piping <ul style="list-style-type: none"> Removed or loosen cramp 	Auditory check Visual check	Correct the cramp

Symptom	Cause	Checkpoint	Remedy
VII Abnormal frosting on compressor	<p>Abnormal frosting on compressor</p> <ul style="list-style-type: none"> · Frosting on terminal cover · Frosting on compressor head 	<p>Dusts caught in injection solenoid valve ISV</p> <pre> graph TD A[Manual defrost] --> B{Defrost completed} B -- NO --> A B -- YES --> C{Is the ISV outlet pipe frosted? (Leak from ISV)} C -- NO --> D[Correct wiring] C -- YES --> E{ISV wiring check} E -- NO --> D E -- YES --> F{Is there any frost on the compressor?} F -- YES --> G[Replace the ISV valve] F -- NO --> H[Circuit breaker OFF⇒ON] D --> H G --> H H --> I{Is there any frost on the compressor?} I -- YES --> J[Replace the EV] I -- NO --> K[Finish] </pre> <p>Faulty operation of electronic expansion valve (EV)</p>	<p>※ As for the manual defrost, refer to P.2-23.</p>

Symptom		Cause	Checkpoint	Remedy
VII	Abnormal frosting on compressor	<p>The air cooling evaporator fan continues rotating</p> <p>Water pressure switch WPS will not operate</p> <ul style="list-style-type: none"> Water pressure is low Water temperature is excessively high Water flow rate is low 	<p>The condenser fan continues rotating</p> <pre> graph TD A[The condenser fan continues rotating] --> B{The high pressure is excessively high} B -- YES --> C[Check the water pressure, water temperature, and water level] B -- NO --> D{Is the condenser fan stopped when the CBS is cooled?} D -- YES --> E[CBS OK] D -- NO --> F{WPS has continuity} F -- YES --> G[Faulty WPS] F -- NO --> H[Faulty CBS] </pre> <p>*CBS: Control box temperature sensor</p>	
		<p>Temperature in the control box is high</p> <p>Water pressure switch WPS is short-circuited</p>		
IX	Others	<p>The remote monitoring RM is not output.</p> <p>Disconnection of Fu6</p>	<pre> graph TD A{Is the fuse Fu6 circuit disconnected?} -- YES --> B[Replace the Fu6] A -- NO --> C{Is there any short circuit or disconnection on the secondary side of RM junction port (on ship)?} C -- YES --> D[Check the wiring on ship ⇒Correct it] C -- NO --> E{Is there any short circuit or disconnection on the primary side of RM connection port (on unit)?} E -- YES --> F[Check the wiring ⇒Correct] E -- NO --> G[Check the controller⇒Replace] </pre> <p>Check for short circuit or disconnection at round crimp type terminal board: from No.23, 24, 25, 26 to RM connection port or connector type terminal board: from CN26 to RM connection port</p>	
		<p>Short-circuit of RM circuit</p> <p>Faulty controller</p> <p>Short-circ of RM circuit on ship</p>		

6.2 Alarm codes on electronic controller

If any alarm occurs, search its cause and repair it referring to the following table.

Be sure to check the connectors in the electronic controller as the poor contact of them may cause the controller alarm codes.

Alarm code	Content	Possible cause/checkpoint
F101	The high-pressure switch (HPS) contact is open	HPS circuit check <ul style="list-style-type: none"> · Broken lead wire · Faulty contact · Blown fuse Fu1
	The HPS activates within 20 seconds after the compressor starts	Condenser fan motor operation check Discharge piping refrigerant circuit check <ul style="list-style-type: none"> · Discharge stop valve · Discharge filter · Discharge check valve · Discharge pressure regulating valve
	The fuse Fu1 is blown	Fuse Fu1 circuit check
	Faulty controller	Faulty controller
F109	The LPT is decreased to -85 KPA or less within 2 seconds after the compressor starts	Refrigerant circuit check <ul style="list-style-type: none"> · Suction stop valve · SMV (Suction modularizing valve) · EV (Electronic expansion valve) · LSV (Liquid solenoid valve) · Dryer · Clogged EV, LSV inlet filter
		Low pressure transducer LPT circuit check <ul style="list-style-type: none"> · Fu3, LPT fault, broken lead wire disconnection, short circuit
		Shortage of refrigerant
		Faulty controller
F111	The high pressure switch does not activate at set value	Disconnection of high pressure switch Disconnection of high pressure transducer
F301	Temperature setting request	Set temperature has not been set up yet (Set up the temperature when the controller is replaced) Faulty controller (SRAM fault)
F401 F403	Supply air temperature sensor SS fault Return air temperature sensor RS fault	Faulty SS and RS <ul style="list-style-type: none"> · Broken or short-circuited lead wire · Faulty wiring (incomplete connection of connector) · Faulty sensor Faulty sensor (faulty CPU PCB)
F603	Faulty operation of suction modulating valve	Faulty SMV body <ul style="list-style-type: none"> · Broken coil
		Faulty driving circuit <ul style="list-style-type: none"> · Disconnection of connector · blown Fu7, 4 · Faulty PCB for suction modulating valve (EC6)
	Wrong controller model setting	Decos III "c" or "d" for LXE10E Decos III "b" for LXE10D
F701	Abnormal power supply voltage	Abnormal power supply voltage <ul style="list-style-type: none"> · 530 V or more
		Faulty voltage detection <ul style="list-style-type: none"> · Faulty PT of PC/CT board (other than disconnection and short-circuit) · Faulty contact of connector · S phase is open phase
F705	S phase is open phase	Abnormal power supply voltage <ul style="list-style-type: none"> · S phase is open phase · Faulty contact of power supply facility
		Faulty power supply equipment <ul style="list-style-type: none"> · Faulty contact of power plug · Faulty contact of power cable · Faulty PT/CT board (EC5)
F803	Any of following alarm codes are displayed twice or more: E101, 103, 105, 107, 109, 203, 205	Find the cause of the alarm for each of the issued alarm codes
E101	High-pressure switch (HPS) activates during operation	Refer to the "The inside temperature does not decrease" and "The high pressure is excessively high" in "6.Troubleshooting"

Alarm code	Content	Possible cause/checkpoint
E103 (Electronic type OC)	Operating current of the compressor is great	Single phase operation due to faulty contact · Magnetic contactor for compressor · Compressor cable · Compressor terminal
		Malfunctioned equipment · Compressor lock · Actuation of thermal protector CTP for compressor · Faulty PT/CT board (EC5) · Faulty controller (CPU, I/O board)
		Wrong initial setup of PT/CT board (jumper wire) (Single or Dual power supply, 10HP or 5HP)
E105 (Micro-computer type OC)	Operating current of the compressor is high	Single phase operation due to incomplete contact · Magnetic contactor for compressor · Compressor cable · Compressor terminal
		Malfunctioned equipment · Compressor lock · Faulty CT of PT/CT board · Abnormal controller (CPU board)
		Wrong initial setup of controller (Single or Dual power supply, 10HP or 5HP)
E107	The discharge gas temperature is excessively high	Clogged refrigerant system · Dryer · Filter
		Shortage of refrigerant
		Malfunctioned equipment · Faulty operation of ISV · Clogged capillary at ESV outlet
	Shortage of refrigerant is detected	Clogged refrigerant system · Dryer · Filter Shortage of refrigerant
E109	Low pressure is decreased during operation	Refer to the "Unit operates but soon stops" and "Low pressure is excessively low" in "6. Troubleshooting"
		Malfunctioned equipment · Faulty low pressure transducer LPT · Faulty controller (CPU board) · Blown fuse Fu3
E201	Pumpdown is not completed within 120 seconds	The solenoid valve cannot be closed (dusts caught in) · LSV (liquid solenoid valve) · HSV (hot gas solenoid valve) · DSV (defrost solenoid valve) · BSV (discharge gas bypass solenoid valve)
		Faulty operation of compressor
		Malfunctioned equipment · Controller · Low pressure transducer LPT
E203	Overcooling prevention (control sensor≤SP-3.0) continues for three minutes or longer in the chilled or partial frozen mode	Refer to the "Control is unstable" and "Temperature continues to decrease" in "6. Troubleshooting"
E205	The inside fan motor stops	Faulty operation of evaporator fan motor · Motor lock · Burned-out motor coil · Operation of thermal protector CTP for compressor · Disconnection on the secondary side of electromagnetic contactor for evaporator fan
		Faulty evaporator fan propeller · Propeller ice lock · Foreign matters caught in propeller
E207	Defrost cannot be completed within 90 minutes	Malfunctioned equipment · Faulty sensor (EOS, RS, HPT, LPT, DCHS) · Faulty controller · Faulty operation of HSV, DSV, ISV · Faulty operation of discharge pressure regulating valve
		Abnormal refrigerant system · Shortage of refrigerant · Heavy frosting

Alarm	Content	Possible cause/checkpoint
E303	Humidity setting request	System malfunctioned
E305	Defrost timer setting request	· Faulty controller
E307	Calendar setting request	Faulty operation
E311	Trip start setting request	· Wrong initial setting of controller
E401	Supply air temperature sensor (SS) fault	System malfunction
E402	Data recorder supply air temperature sensor (DSS) fault	· Faulty sensor
E403	Return air temperature sensor (RS) fault	· Faulty controller
E404	Data recorder return air temperature sensor (DRS) fault	· Broken or short-circuited lead wire
E405	Discharge pipe temperature sensor (DCHS) fault	· Wrong wiring
E406	Suction gas temperature sensor (SGS) fault	· Disconnection of connector
E407	Evaporator inlet pipe temperature sensor (EIS) fault	
E409	Evaporator outlet pipe temperature sensor (EOS) fault	
E411	Ambient temperature sensor (AMBS) fault	
E413	Low pressure transducer (LPT) fault	
E415	High pressure transducer (HPT) fault	
E419	Voltage sensor (PT2) fault	
E425	Pulp temperature sensor (USDA1) fault	
E427	Pulp temperature sensor (USDA2) fault	
E429	Pulp temperature sensor (USDA3) fault	
E431	Humidity sensor (Hus) fault	
E433	Carge temperature sensor (STS) fault	
E417	Voltage sensor (PT1) fault	Malfunctioned equipment
E421	Current sensor (CT1) fault	· Faulty sensor
E423	Current sensor (CT2) fault	· Faulty controller
		· Broken or short-circuited lead wire
		· Wrong wiring
		· Disconnection of connector
E603	Disconnection of suction modulating valve (SMV) or faulty driving circuit or wrong setting of controller	Malfunctioned equipment
		· Faulty controller
		· Faulty SMV coil
		· Faulty PCB for SMV
		· Broken wire of harness (disconnection of connector)
		Faulty operation
		· Wrong initial setup of controller
E607	Faulty contact point of manual defrost key (sheet key)	Faulty short-circuit of switch
		Faulty short-circuit of CPU
E707	Momentary power failure	The power is not supplied for 40 to 300 mm sec.
E805	Ventilator opening detector error	
	Initial setting "FA SEN" of the controller is wrong.	Don't set "H" or "L" for the unit not equiped ventilator opening detector.
E807	Opened lower ventilator	The lower ventilator is opened during frozen operation

LXE10E

Malfunction and Alarm

when the connector is disconnected or loosened.

Location	Socket No.	Malfunction or Alarm when the connector is disconnected or loosened.	Applicable to LXE10D
SMV Board (EC6)	CN81 (White)	No Alarm.....No power supply to Controller	—
	CN82 (Red)	No Alarm.....No power supply to Controller	—
	CN83 (Yellow)	F803	—
	CN84 (Blue)	F603	—
PT/CT Board (EC6)	CN1	F705	Yes
	CN2	F705 E315 E417 E421 E423	Yes
I/O Board (EC2)	CN26	No Alarm.....No power supply to recorder	Yes
CPU Board (CN1)	CN13	No Alarm.....No power supply to Controller	Yes
	CN15	No Alarm.....No communication to computer for data down loading	Yes
	CN16	No Alarm.....No power supply to MODEM	Yes
	CN18	No Alarm.....No "signal" power supply to EV	Yes
Terminal Board (TB1)	CN1	E109 → F109 (F803)	Yes
	CN2	F101	Yes
	CN3	No Alarm.....No power to PCC (No operation)	Yes
	CN4	No Alarm.....No power supply to Controller	Yes
Terminal Board (TB1)	CN6	F803, E401, E403, E409, E411, E413, E415 ("E" displayed in SS, RS temperature indication for E401, E403)	Yes
	CN7	F406 E407 E402 E404 ("E" displayed in DRS, DSS, EIS, SGS temperature indication)	Yes

Location	Fuse No.	Malfunction or Alarm when the fuse is broken.	Applicable to LXE10D
Terminal Board (TB1)	Fu1	F101	Yes
	Fu2	BSV	—
	Fu3	E109 → F109 (F803).....No power to LSV (LSV close)	Yes
	Fu4	F603, E315, E417, E421, E423	Yes
	Fu5	No Alarm.....No power supply to Controller	Yes
	Fu6	No Alarm.....No power supply to Monitoring Cirt	—


6.3 Troubleshooting for automatic PTI (J-code)

Step	Content	Alarm code	Conclusion	Possible cause	Check method
P00	Basic data record	No indication	No judgment		
P02	Alarm check on all sensor	Same as normal operation	Same as normal operation	Same as normal operation	Same as normal operation
P04	Power supply check	No indication	Same as normal operation	Same as normal operation	Same as normal operation
P05	Compressor start running check	J051	Same as normal operation	Same as normal operation	Same as normal operation
P06	HPS check	J061	Abnormal OFF point	(1) HPS malfunction	(1) Check HPS (2) Compare to Gauge manifold (3) Remove Gauge manifold.
		J062	Not return	(2) High pressure transducer (HPT) malfunction	
		J064	High pressure does not rise.	(3) Gas leak from Gauge manifold	
		J065	High pressure does not drop.	(No unit malfunction)	
P08	Pump down check	J081	Pump down requires too long time.	Blocked with contamination of liquid solenoid valve	Try again S-PTI
				Leakage of hot gas by-pass solenoid valve	Touch the outlet pipe of the solenoid valve.
				Leakage of defrosting solenoid valve	Touch the outlet pipe of the solenoid valve.
				Leakage of discharge gas by-pass solenoid valve	Touch the outlet pipe of the solenoid valve.
P10	Solenoid valve check	J101	Excessive leakage of solenoid valve	Liquid solenoid valve malfunction	Check Liquid solenoid valve
				Suction modulating valve malfunction	Check Suction modulating valve
				Injection valve malfunction	Check Injection valve
P12	RS, SS accuracy check	J121	Excessively large temperature difference between RS and DRS Excessively large temperature difference between SS and DSS	SS malfunction	Compare the SS with the DSS on the controller panel.
				RS malfunction	Compare the RS with the DS on the controller panel.
P14	HPT, LPT accuracy check	J141	Excessively large pressure difference between HPT and LPT	HPT malfunction	Compare the high pressure valve with the gauge manifold of HPT (on the controller panel).
				LPT malfunction	Compare the low pressure valve with the gauge manifold of LPT (on the controller panel)
P16	Evaporator fan Hi/Lo speed operation check	J161	Abnormal operation of evaporator fan speed	Evaporator fan and motor malfunction. Magnetic contactor (EFH/L) and wiring malfunction.	Check Evaporator fan and motor. Check magnetic contactor (EFH/L) and wiring.
P20	Check on economizer solenoid valve (ESV)	J201	ESV does not open.	ESV coil malfunction	Check on ESV coil, wiring and terminals.
				ESV malfunction	Check on capillary tube temperature on ESV outlet.


Step	Content	Alarm code	Conclusion	Possible cause	Check method
P22	Check on discharge gas by-pass solenoid valve (BSV)	J221	BSV does not open.	BSV coil malfunction	Check on BSV coil, wiring and terminals.
				BSV malfunction	Check on outlet piping temperature of BSV
P24	Check on defrosting solenoid valve (DSV)	J241	DSV does not open.	DSV coil failure	Check on DSV coil, wiring and terminals.
				DSV malfunction	Check on outlet piping temperature of DSV
P26	Standard Pull down operation	No indication			
P28	Check on suction modulating valve (SMV) (Open SMV to 3%)	J281	(LPT : decrease 20kPa)	SMV coil malfunction	Refer to section 4.2.5. Check appearance. (Replace coil bracket)
P29	Electronic expansion valve check	J291	Pump down time is too long.	Electronic expansion valve wiring malfunction	Check knocking sound of the coil Disconnect and connect the connector of the coil.
				Electronic expansion valve coil burn out.	Check on knocking sound of coil.
				Leakage of hot gas by-pass solenoid valve	Touch the outlet pipe of the solenoid valve.
				Leakage of defrosting solenoid valve	Touch the outlet pipe of the solenoid valve.
				Leakage of discharge gas by-pass solenoid valve	Touch the outlet pipe of the solenoid valve.
P30	ISV opening or closing check	J301	ISV does not open.	ISV coil malfunction	Check on ISV coil, wiring and terminals.
				ISV malfunction	Check on capillary tube temperature on ISV outlet.
P32	HSV opening or closing check	J321	HSV does not open.	HSV coil malfunction	Check on HSV coil, wiring and terminals.
	RSV opening or closing check	J322	RSV does not open.	RSV coil malfunction	Check on outlet piping temperature of RSV
P50	Pull-down cooling capacity	J501	Out of ambient temperature condition	No unit malfunction Ambient temperature is lower than -10°C Ambient temperature is higher than 43°C	Check ambient temperature.
		J502	Pull down time is too long.	Same as normal operation ※	Same as normal operation ※
P60	0°C control	No indication	No judgement		
P70	Defrosting operation check	J701	Out of starting condition. (EOS is 20°C or more.)	Wrong installation of EOS.	Check the installation of EOS.
				Leakage of hot gas solenoid valve	Touch the outlet pipe of the solenoid valve.
		J702	Defrost time is too long.	Wrong installation of EOS.	Check the installation of EOS.
				EOS malfunction.	Check EOS.
P80	Pull-down cooling capacity	J801	Pull down time is too long.	Same as normal operation ※	Same as normal operation ※
P90	-18°C control	No indication	No judgement		

Note :※"Same as normal operation" means that it is same as judgement, countermeasure and check method at normal operation. (Refer to from Page 6-1 to 6-17)


6.4 Diagnosis based on the recording chart




Set temperature	0°C
Occurrence read out from the recording chart Defrosting is periodically executed by the timer	
Abnormal content and abnormal point Normal	



Set temperature	0°C
Occurrence read out from the recording chart The recording paper is not properly fed because the chart nut which retains the recording chart is loose.	
(left side)	
Abnormal content and abnormal point Tighten the chart nut, then it will return to normal.	
(Right side)	



Set point temperature	5°C
Occurrence read out from the recording chart When the moisture in the cargo is excessive, the cooling capacity becomes insufficient during pull-down operation since frosting occurs excessively. Since the temperature rises before reaching the set point temperature, defrosting is repeated at outside of the in-range temperature.	
Abnormal content and abnormal point The operation is not abnormal. Until the amount of the frost on the evaporator is to be reduced, defrosting with the frost detection is repeated. In 2 to 3 days, defrosting interval will return to normal.	



Set temperature


0°C

Occurrence read out from the recording chart

Though the temperature record is normal, the temperature rapidly rises.

Abnormal content and abnormal point

The compressor stops due to malfunction or the fusible safety plug is molten.



Set point temperature

- 18°C


Occurrence read out from the recording chart

Though defrosting is periodically executed, the inside temperature gradually rises.

Abnormal content and abnormal point

Due to the insufficient cooling capacity, the inside temperature rises.

- Refrigerant amount is short due to leakage.
- Compressor valve is broken.
- Expansion valve or liquid solenoid valve are clogged.
- High pressure rises due to shortage of air flow rate of the condenser, etc.



Set temperature


- 18°C

Occurrence read out from the recording chart

The recorder temperature suddenly varies.

Abnormal content and abnormal point

The connector in the temperature recorder is in poor contact.



Set point temperature **0°C**

Occurrence read out from the recording chart

When defrosting, the inside temperature temporarily drops.

Abnormal content and abnormal point

Since the liquid solenoid valve is not closed, pump-down operation before defrost starts is not performed, and cooling operation continues with the evaporator fan stopped. The normal operation starts 2 min. after defrosting has been terminated forcibly, but the evaporator is still cold.

6.5 Emergency operation

6.5.1 Emergency operation of controller

In case of the controller malfunction, emergency operation can be executed by using emergency operation kit.

(1) Components to be prepared (emergency operation kit)

- Short circuit connector --- Stored on the back of CPU/IO board case in the control box.
- Electronic expansion valve emergency cap --- (parts no. 1080263)
- Suction modulating valve emergency magnet --- (parts no. 1270530)

(2) On-site work

The on-site work is requested as follows for Emergency Operation

- ① Wiring change for short circuit operation
 - 1) Wiring change for cutting off the power to CPU board
 - 2) Wiring change for making the forced running of Compressor, Condenser Fan and Evaporator Fans.
 - * Connect the short circuit connector stored on the back of controller.
 - * For the details, refer to the clause 6.5.2 "Short Circuit Operation"
- ② Electronic Expansion Valve opening adjustment for 1/4 opening.
 - * Use Emergency Cap for the for 1/4 opening.
 - * For the details, refer to the clause 6.5.3 "Opening Adjustment"
- ③ Suction Modulation Valve opening adjustment for full opening.
 - * Use Emergency Magnet for full the opening.
 - * For the details, refer to the clause 6.5.4 "Opening Adjustment"





(3) Operating condition at emergency

Temperature can not be controlled. Turn the circuit breaker on or off to maintain the target temperature.





Mode	Available function of protection devices	Operating condition of unit
Cooling operation	RPP : Reverse phase protection device HPS : High pressure switch CTP : Compressor thermal protector	<ul style="list-style-type: none">○ Compressor runs continuously.○ Evaporator fan runs at low speed continuously.○ Condenser fan runs continuously.○ Electronic expansion valve operates with fixed opening.○ Suction modulating valve operates with full opening.
Heat operation	_____	<ul style="list-style-type: none">○ Compressor stops.○ Evaporator fan runs at high speed continuously.○ Condenser fan stops.

6.5.2 Short circuit operation of controller

● Models produced after May,2006 (Connector type terminal board)

	Cooling Operation	Heating Operation
For cutting off the power to CPU board	<p>① Turn the circuit breaker OFF.</p> <p>② Disconnect the power supply connector CN82(White) on SMV adapter board.</p>	<p>Disconnect CN82 (White)</p>  <p>SMV adapter</p> <p>Open cover</p>
For making the forced running of COMP., CFM and EFM.	<p>③ Remove Short Circuit Connector SCC1-1(Blue), SCC1-2(Red) and SCC2(Blue) stored on back of controller.</p>	 <p>SCC1-1(Blue)</p> <p>SCC1-2(Red)</p> <p>SCC2(Blue)</p>
	<p>④ Connect Short Circuit Connector SCC1-1(Blue) to CN8 and SCC2 (Blue) to CN9 on terminal board.</p>	<p>④ Connect Short Circuit Connector SCC1-2(Red) to CN8 and SCC2 (Blue) to CN10 on terminal board.</p>
	<p>CN-C1 & CN-C2 : Reverse phase correction connector (Refer to next step ⑥)</p>  <p>SCC1-1(Blue)</p> <p>SCC2(Blue)</p> <p>SCC1-2(Red)</p> <p>Terminal Board</p>	
For checking reverse phase power	<p>⑤ Turn the circuit breaker ON.</p> <p>If the power is in reverse phase, COMP. can not be run and CFM runs reversely.</p>	<p>⑤ Turn the circuit breaker ON.</p> <p>If the power is in reverse phase, EFM runs reversely with high speed. Then fresh air is sucked to Outlet Hole and discharged from Inlet Hole at the ventilator.</p>  <p>Air Inlet</p> <p>Air Outlet</p> <p>Correct</p> <p>Reverse</p>
For correcting reverse phase power	<p>⑥ If it is in reverse phase, turn the circuit breaker OFF and replace the reverse phase correction socket to opposite side. ("Lower socket CN-C1 to Upper CN-C2" or "Upper CN-C2 to Lower CN-C1")</p>	

● Models produced before April,2006 (Screw type terminal board)

	Cooling Operation	Heating Operation
For cutting off the power to CPU board	<p>① Turn the circuit breaker OFF.</p> <p>② Disconnect the power supply connector CN82(White) on SMV adapter board.</p>	<p>Disconnect CN82 (White)</p> <p>SMV adapter</p> <p>Open cover</p> 
For making the forced running of COMP., CFM and EFM.	<p>③ Remove Short Circuit Connector SCC1-1(Blue), SCC1-2(Red) and SCC2(Blue) stored on back of controller.</p>	 <p>SCC1-1(Blue)</p> <p>SCC1-2(Red)</p> <p>SCC2(Blue)</p>
	<p>④ Connect Short Circuit Connector SCC1-1(Blue) to CN8 and SCC2 (Blue) to CN9 on terminal board.</p>	<p>④ Connect Short Circuit Connector SCC1-2(Red) to CN8 and SCC2 (Blue) to CN10 on terminal board.</p>
	<p>CN-C1 & CN-C2 : Reverse phase correction socket (Refer to next step ⑥)</p> 	
For checking reverse phase power	<p>⑤ Turn the circuit breaker ON.</p> <p>If the power is in reverse phase, COMP. can not be run and CFM runs reversely.</p>	<p>⑤ Turn the circuit breaker ON.</p> <p>If the power is in reverse phase, EFM runs reversely with high speed. Then fresh air is sucked to Outlet Hole and discharged from Inlet Hole at the ventilator.</p>  <p>Air Inlet</p> <p>Air Outlet</p> <p>Correct</p> <p>Reverse</p>
For correcting reverse phase power	<p>⑥ If it is in reverse phase, turn the circuit breaker OFF and replace the reverse phase correction socket to opposite side.</p> <p>("Lower socket CN-C1 to Upper CN-C2" or "Upper CN-C2 to Lower CN-C1")</p>	

6.5.3 Opening adjustment of electronic expansion valve

In case of the controller malfunction or faulty electronic expansion valve coil, electronic expansion valve can be operated with fixed valve opening by using emergency cap.

Caution

If the electronic expansion valve is energized while the coil is removed from valve body, the coil driver with which the valve needle is pushed protrude excessively. In this state, when the valve is restored from emergency operation, the needle may be caught with the driver resulting the valve fully closed. Therefore, be sure not to energize the coil before emergency operation.


[Disenergizing of coil]

○ When controller malfunction

Disconnect the red power supply connector (red : CN5) on the terminal board when removing of controller short circuit connector (SCC1-1 or SCC1-2) to disenergize the electronic expansion valve.(described in the section 6.5.2)


○ When only electronic expansion valve is conducted emergency operation.

Disconnect CN18 on the controller CPU board to disenergize the electronic expansion valve.




- ① Remove the coil.
- ② Set the emergency cap on the electronic expansion valve body.
- ③ Fully close the electronic expansion valve by turning the minus recessed screw of emergency cap clockwise with miniature driver.
(Tightening torque: approx. 1 kgf · cm. The torque is required to tighten the valve softly until the driver stops turning)
- ④ Then slightly open the electronic expansion valve by turning the minus recessed screw of emergency cap counter clockwise for 60°
- ⑤ Apply a loose-free adhesive on the screw.


① Remove the coil.




② Set the emergency coil cap.
Emergency coil cap
(Parts no. 1080263)



③ Fully close.




④ Slightly open.



Recommendation

*EV opening adjustment during pull-down operation

To shorten the operation hours, it is recommended that the opening be adjusted up to max. 50%. However if the frost is observed around the comp. body or the super heat is insufficient due to wet operation, close slightly the opening.




6.5.4 Opening adjustment of suction modulation valve:

In case of emergency, there are two ways to open the suction modulating valve manually.

It is important to follow these steps in this sequence. Use step 1 first. If this is not working, then use step 2.

Step 1. Fully open the valve by using the dip switch on the adopter PCB.

In case of controller malfunction while the suction modulating valve and adopter PCB are normal, turn the No. 1 dip switch ON to open the valve automatically. At the same time the dip switch is switched, a clicking sound can be heard that the valve fully opens. If nothing will be heard, continue to step 2.




Step 2. Fully open the valve by using an emergency magnet.

If the method of step 1 was not working, use this step to open the valve.

In case of the suction modulating valve or adopter PCB malfunction, the valve can be opened by using an emergency magnet.

- ① Prepare Emergency Magnet.
- ② Remove the coil of the modulating valve.
- ③ Contact the emergency magnet to the coil mounting section of the valve with the "UPSIDE" up. (the emergency magnet is attracted to the coil installing section by magnetic force of the inside driving magnet)
- ④ Rotate the emergency magnet counter clockwise to open the valve fully. (when the valve is fully opened, the inside driving magnet will be inactive and the emergency magnet can be removed)



6.5.5 Automatic Back up for supply / return air temperature sensors

When the unit is equipped with the data recorder sensors, the following emergency operations are available.

When the DRS and DSS are used for the emergency operation, DATA RECORDER SENSOR ON/OFF SETTING to be set OFF. (Refer to page 3-27, basic function setting mode.)

RS: Return air temperature sensor DRS: Data recorder return air temperature sensor

RRS: Recorder return air temperature sensor

SS: Supply air temperature sensor DSS: Data recorder supply air temperature sensor

RSS: Recorder supply air temperature sensor

Malfunction code	Abnormal point	Unit back-up operation	Check method	Emergency operations
E401	SS Supply air temperature sensor (SS) for control malfunction	Chilled mode: Back-up operation with DSS Frozen mode: only malfunction code indication	Check for looseness of the connector and crimp terminal.	Replace the SS and DSS.
E402	DSS Data recorder supply air temperature sensor (DSS) malfunction	Only malfunction code indication	Check for looseness of the connector and crimp terminal.	_____
E401 E402	Both SS and DSS malfunction	Chilled mode: Back-up operation with RS -2°C. Frozen mode: only malfunction code indication	Check for looseness of the connector and crimp terminal.	_____
E403	RS Return air temperature sensor (RS) for control malfunction	Chilled mode: only malfunction code indication Frozen mode: Back-up operation with DRS	Check for looseness of the connector and crimp terminal.	Replace the RS and DRS.
E404	DRS Data recorder supply air temperature sensor (DRS) malfunction	Only malfunction code indication	Check for looseness of the connector and crimp terminal.	_____
E403 E404	Both RS and DRS malfunction	Chilled mode: only malfunction code indication Frozen mode: Back-up operation with SS +5°C	Check for looseness of the connector and crimp terminal.	_____
H006	Chilled mode: Temperature difference is 2 °C or more between SS and DSS or more than one hour.	Only malfunction code indication	Compare with records by a recorder, and decide which sensor is faulty.	Replace the SS and DSS only when the SS is faulty.
	Frozen mode: Temperature difference is 2 °C or more between RS and DRS or more than one hour.	Only malfunction code indication	Compare with records by a recorder, and decide which sensor is faulty.	Replace the RS and DRS only when the RS is faulty.

7. APPENDIX

7.1 Standard tightening torques for bolts

	Bolt size	Main part	Tightening torque		
			N · m	kgf · cm	lbf · ft
Stainless steel	M4	Small parts	1.6	16	1.2
	M5	Solenoid valve	1.2	12.2	0.9
	M6	Access panel	5.2	53	3.8
	M8	Evaporator fan motor Condenser fan motor Control box Service door	12.3	125	9.1
	M10	Evaporator fan motor mounting base Compressor suction flange Compressor discharge flange	25.2	257	18.6
	M12	Compressor	42.7	435	31.5

Note: Tolerance of tightening torque is within $\pm 10\%$.

7.2 Standard tightening torque for flare nut

Pipe size		Main part	Tighten torque		
mm	in.		N · m	kgf · cm	lbf · ft
$\phi 6.4$	2/8	Compressor pressure port	15.7	160	11.3
$\phi 9.5$	3/8	—	36.3	370	26.8
$\phi 12.7$	4/8	Dryer	54.9	500	40.5

Note: Tolerance of tightening torque is within $\pm 10\%$.

7.3 Resistance of motor coil and solenoid valve coil

Symbol	Parts name	Value of resistance Ω	Remarks
CM	Compressor motor coil	1.780 Ω (@ 75°C)	
CFM	Condenser fan motor coil	57.2 Ω	
EFM	Evaporator fan motor coil	19.4 Ω	
LSV	Liquid solenoid valve coil	15.2 \pm 1.1 Ω (common)	
HSV	Hot gas solenoid valve coil		
DSV	Defrosting solenoid valve coil		
ISV	Injection solenoid valve coil		
ESV	Economizer solenoid valve coil		
BSV	Hot gas by-pass solenoid valve coil		
RSV	Reheater solenoid valve		
EV	Electronic expansion valve coil	White - Red : 150 Ω Orange - Red : 150 Ω Yellow - Brown : 150 Ω Blue - Brown : 150 Ω	
SMV	Suction modulation valve coil	Blue - Yellow : 113 Ω Black - White : 113 Ω	

※The values of resistance are at room temperature excluding those of compressor.

7.4 Standard tightening torque for electronic expansion valve coil(EV)

N · m	kgf · cm	lbf · ft
7.0 to 15.0	73 to 156	5.1 to 11.0

7.5 HFC134a, temperature - vapor pressure characteristics table

Temperature		Vapor pressure			Temperature		Vapor pressure		
°C	°F	kPa	kg/cm ² ·G	PSIG	°C	°F	kPa	kg/cm ² ·G	PSIG
-40	-40	-49	-0.50	-7.1	20	68	470	4.79	68.1
-39	-38.7	-46	-0.47	-6.6	21	69.8	488	4.97	70.7
-38	-36.4	-44	-0.44	-6.3	22	71.6	507	5.16	73.5
-37	-34.6	-41	-0.41	-5.9	23	73.4	525	5.35	76.1
-36	-32.8	-37	-0.38	-5.3	24	75.2	544	5.55	78.8
-35	-31	-34	-0.34	-4.9	25	77	564	5.75	81.7
-34	-29.2	-31	-0.31	-4.4	26	78.8	584	5.95	84.6
-33	-27.4	-27	-0.27	-3.9	27	80.6	604	6.16	87.5
-32	-25.6	-24	-0.24	-3.4	28	82.4	625	6.37	90.6
-31	-23.8	-20	-0.20	-2.9	29	84.2	647	6.59	93.8
-30	-22	-16	-0.16	-2.3	30	86	668	6.81	96.8
-29	-20.2	-12	-0.12	-1.7	31	87.8	691	7.04	100.1
-28	-18.4	8	-0.07	-1.1	32	89.6	713	7.27	103.3
-27	-16.6	3	-0.03	-0.4	33	91.4	737	7.51	106.8
-26	-14.8	1	0.01	0.1	34	93.2	760	7.75	110.2
-25	-13	6	0.06	0.8	35	95	785	8.00	113.8
-24	-11.2	11	0.11	1.5	36	96.8	810	8.25	117.4
-23	9.4	16	0.16	2.3	37	98.6	835	8.51	121.0
-22	7.6	21	0.21	3.0	38	100.4	861	8.77	124.8
-21	5.8	27	0.27	3.9	39	102.2	887	9.04	128.6
-20	4	32	0.33	4.6	40	104	914	9.31	132.5
-19	2.2	38	0.39	5.5	41	105.8	941	9.59	136.4
-18	0.4	44	0.45	6.3	42	107.6	969	9.88	140.5
-17	1.4	51	0.51	7.3	43	109.4	998	10.17	144.7
-16	3.2	57	0.58	8.2	44	111.2	1027	10.47	148.9
-15	5	64	0.64	9.2	45	113	1057	10.77	153.2
-14	6.8	71	0.71	10.2	46	114.8	1087	11.08	157.6
-13	8.6	78	0.79	11.3	47	116.6	1118	11.39	162.1
-12	10.4	85	0.86	12.3	48	118.4	1149	11.72	166.6
-11	12.2	93	0.94	13.4	49	120.2	1182	12.04	171.3
-10	14	100	1.02	14.5	50	122	1214	12.38	176.0
-9	15.8	108	1.10	15.6	51	123.8	1248	12.72	180.9
-8	17.6	117	1.18	16.9	52	125.6	1281	13.06	185.7
-7	19.4	125	1.27	18.1	53	127.4	1316	13.42	190.8
-6	21.2	134	1.36	19.4	54	129.2	1351	13.77	195.8
-5	23	143	1.45	20.7	55	131	1387	14.14	201.1
-4	24.8	152	1.55	22.0	56	132.8	1424	14.51	206.4
-3	26.6	162	1.65	23.4	57	134.6	1461	14.89	211.8
-2	28.4	172	1.75	24.9	58	136.4	1499	15.28	217.3
-1	30.2	182	1.85	26.3	59	138.2	1538	15.67	223.0
0	32	192	1.96	27.8	60	140	1577	16.07	228.6
1	33.8	203	2.07	29.4	61	141.8	1617	16.48	234.4
2	35.6	214	2.18	31.0	62	143.6	1658	16.90	240.4
3	37.4	225	2.29	32.6	63	145.4	1699	17.32	246.3
4	39.2	237	2.41	34.3	64	147.2	1741	17.75	252.4
5	41	249	2.53	36.1	65	149	1784	18.19	258.6
6	42.8	261	2.66	37.8	66	150.8	1828	18.63	265.0
7	44.6	274	2.79	39.7	67	152.6	1872	19.09	271.4
8	46.4	287	2.92	41.6	68	154.4	1918	19.55	278.1
9	48.2	300	3.06	43.5	69	156.2	1964	20.02	284.7
10	50	314	3.20	45.5	70	158	2010	20.50	291.4
11	51.8	328	3.34	47.5	71	159.8	2058	20.98	298.4
12	53.6	342	3.48	49.5	72	161.6	2107	21.48	305.5
13	55.4	357	3.63	51.7	73	163.4	2156	21.98	312.6
14	57.2	372	3.79	53.9	74	165.2	2206	22.49	319.8
15	59	387	3.95	56.1	75	167	2257	23.01	327.2
16	60.8	403	4.11	58.4	76	168.8	2309	23.54	334.8
17	62.6	419	4.27	60.7	77	170.6	2362	24.08	342.4
18	64.4	436	4.44	63.2	78	172.4	2415	24.62	350.1
19	66.2	453	4.62	65.6	79	174.2	2470	25.18	358.1
					80	176	2525	25.74	366.1

Conversion rate : 1kgf/cm² · G=98.0665kPa

1kPa = 0.145PSIG

7.6 Temperature conversion table and temperature sensor (SS/RS/DSS/DRS/RSS/RRS/EIS/EOS/SGS/AMBS) characteristics table

Temperature(°C)	Temperature(°F)	Resistance(kΩ)	Temperature(°C)	Temperature(°F)	Resistance(kΩ)
+ 50	+ 122	0.985	+ 0	+ 32	6.860
+ 49	+ 120.2	1.018	− 1	+ 30.2	7.176
+ 48	+ 118.4	1.054	− 2	+ 28.4	7.508
+ 47	+ 116.6	1.090	− 3	+ 26.6	7.857
+ 46	+ 114.8	1.128	− 4	+ 24.8	8.226
+ 45	+ 113	1.167	− 5	+ 23	8.614
+ 44	+ 111.2	1.208	− 6	+ 21.2	9.023
+ 43	+ 109.4	1.251	− 7	+ 19.4	9.454
+ 42	+ 107.6	1.296	− 8	+ 17.6	9.909
+ 41	+ 105.8	1.342	− 9	+ 15.8	10.39
+ 40	+ 104	1.390	− 10	+ 14	10.89
+ 39	+ 102.2	1.441	− 11	+ 12.2	11.43
+ 38	+ 100.4	1.493	− 12	+ 10.4	11.99
+ 37	+ 98.6	1.548	− 13	+ 8.6	12.59
+ 36	+ 97	1.605	− 14	+ 6.8	13.22
+ 35	+ 95	1.665	− 15	+ 5	13.88
+ 34	+ 93.2	1.727	− 16	+ 3.2	14.59
+ 33	+ 91.4	1.791	− 17	+ 1.4	15.33
+ 32	+ 89.6	1.859	− 18	− 0.4	16.12
+ 31	+ 87.8	1.929	− 19	− 2.2	16.95
+ 30	+ 86	2.003	− 20	− 4	17.83
+ 29	+ 84.2	2.080	− 21	− 5.8	18.76
+ 28	+ 82.4	2.160	− 22	− 7.6	19.75
+ 27	+ 80.6	2.244	− 23	− 9.4	20.80
+ 26	+ 78.8	2.331	− 24	− 11.2	21.91
+ 25	+ 77	2.423	− 25	− 13	23.08
+ 24	+ 75.2	2.519	− 26	− 14.8	24.33
+ 23	+ 73.4	2.619	− 27	− 16.6	25.66
+ 22	+ 71.6	2.724	− 28	− 18.4	27.06
+ 21	+ 69.8	2.833	− 29	− 20.2	28.56
+ 20	+ 68	2.948	− 30	− 22	30.15
+ 19	+ 66.2	3.068	− 31	− 23.8	31.83
+ 18	+ 64.4	3.193	− 32	− 25.6	33.63
+ 17	+ 62.6	3.325	− 33	− 27.4	35.53
+ 16	+ 60.8	3.463	− 34	− 29.2	37.56
+ 15	+ 59	3.607	− 35	− 31.0	39.72
+ 14	+ 57.2	3.758	− 36	− 32.8	42.02
+ 13	+ 55.4	3.917	− 37	− 34.6	44.46
+ 12	+ 53.6	4.083	− 38	− 36.4	47.07
+ 11	+ 51.8	4.258	− 39	− 38.2	49.85
+ 10	+ 50	4.441	− 40	− 40	52.81
+ 9	+ 48.2	4.633			
+ 8	+ 46.4	4.834			
+ 7	+ 44.6	5.046			
+ 6	+ 42.8	5.268			
+ 5	+ 41	5.501			
+ 4	+ 39.2	5.747			
+ 3	+ 37.4	6.004			
+ 2	+ 35.6	6.275			
+ 1	+ 33.8	6.560			

7.7 Temperature conversion table and temperature sensor (DCHS) characteristics table

Temperature(°C)	Temperature(°F)	Resistance(kΩ)	Temperature(°C)	Temperature(°F)	Resistance(kΩ)
72	162	32.783	102	216	12.566
74	165	30.629	104	219	11.835
76	169	28.635	106	223	11.153
78	172	26.787	108	226	10.515
80	176	25.073	110	230	9.919
82	180	23.482	112	234	9.361
84	183	22.005	114	237	8.840
86	187	20.633	116	241	8.351
88	190	19.358	118	244	7.894
90	194	18.171	120	248	7.465
92	198	17.066	122	252	7.063
94	201	16.037	124	255	6.685
96	205	15.078	126	258	6.331
98	208	14.184	128	262	5.998
100	212	13.350	130	266	5.686

7.8 High pressure transducer characteristics table


Pressure (kPa · G)	Out put (V)	Pressure (kPa · G)	Out put (V)
0	0.50	1100	1.62
100	0.60	1200	1.72
200	0.70	1300	1.83
300	0.81	1400	1.93
400	0.91	1500	2.03
500	1.01	1600	2.13
600	1.11	1700	2.23
700	1.21	1800	2.34
800	1.32	1900	2.44
900	1.42	2000	2.54
1000	1.52	2100	2.64

7.9 Low pressure transducer characteristics table

Pressure (kPa · G)	Out put (V)
– 500	– 1.03
– 400	– 0.72
– 300	– 0.42
– 200	– 0.11
– 100	0.19
0	0.50
100	0.81
200	1.11
300	1.42
400	1.72
500	2.03
600	2.34
700	2.64
800	2.95
900	3.25
1000	3.56

7.10 Piping diagram

●LXE10E



EV :Electronic Expansion Valve	SMV:Suction Modulation Valve	DPR:Discharge pressure regulator
LSV:Liquid Solenoid Valve	HSV:Hot Gas Solenoid Valve	
DSV:Defrost Solenoid Valve	ISV :Injection Solenoid Valve	
ESV:Economizer Solenoid Valve	BSV :Discharge Gas Bypass Solenoid Valve	


7.11 Electric wiring

pilot lamps and monitoring circuit

Four pilot lamps which indicate operating mode are mounted on the controller in the control box.

Pilot lamp	Color	Operating condition
COMP.	Green	The compressor is running
DEFROST	Red	The unit is under defrosting operation
IN RANGE	Orange	The inside temperature is within the proper range (within $\pm 2.0^{\circ}\text{C}$ ($\pm 3.6^{\circ}\text{F}$) of the preset temperature).
DE-HUMID.	Yellow	The unit is set to the dehumidification control operation. (optional)


The receptacle for the pilot lamp remote monitoring is also equipped. The connections are as shown below.




7.12 Fuse protection table

	Protection of:
Fuse 1 (250V, 10A)	<ul style="list-style-type: none"> • High pressure switch (HPS) • Compressor contactor (CC) • Evaporator fan contactor high speed (EFH) • Evaporator fan contactor low speed (EFL) • Condensor fan contactor (CFC) • Compressor terminal protector (CTP) • Phase correction contactor (PCC1, PCC2)
Fuse 2 (250V, 10A)	<ul style="list-style-type: none"> • Gas bypass solenoid valve (BSV) • Defrost solenoid valve (DSV)
Fuse 3 (250V, 10A)	<ul style="list-style-type: none"> • Hot gas solenoid valve (HSV) • Liquid solenoid valve (LSV) • Injection solenoid valve (ISV) • Economizer solenoid valve (ESV)
Fuse 4 (250V, 10A)	<ul style="list-style-type: none"> • Electronic expansion valve (EV) • PT and CT board
Fuse 5 (250V, 10A)	<ul style="list-style-type: none"> • Recorder • LED indication • LCD display
Fuse 6 (250V, 10A)	<ul style="list-style-type: none"> • Remote monitoring receptacle (RM)
Fuse 7 (250V, 5A)	<ul style="list-style-type: none"> • Suction modulating valve (SMV)

7.13 Schematic wiring diagram (Connector type terminal board and rechargeable battery)



7.14 Stereoscopic wiring diagram (Connector type terminal board and rechargeable battery)



Notes for wiring


- Note: (1) — line represents the line in the box. — line represents the external unit or junction cable. — line between terminals represents the jumper wire. - - - line represents the optional specification.
- (2) The terminal numbers and applicable cables in each unit are as shown below.
- | UL1015 AWG | mm ² | Line |
|--------------|-------------------------|-------|
| UL1015 AWG16 | (1.25 mm ²) | — A — |
| UL1015 AWG14 | (2.0 mm ²) | — B — |
| UL1015 AWG12 | (3.5 mm ²) | — C — |
| UL1015 AWG10 | (5.5 mm ²) | — D — |

(3) Line color

BLK: Black, BLU: Blue, GRY: Grey
BRN: Brown, RED: Red, YLW: Yellow
WHT: White, GRN: Green


(4) Sequence chart of this diagram accords with the table.

- (5) When tightening the two round terminals, tighten as shown below. When tightening the two terminals whose wire sizes are different, the larger size wire must be placed under the smaller size one.




- (6) At the two tightening positions of round crimp terminals with M3.5 insulating sleeve (FN type) or tightening positions of round crimp terminal (FN type) with M3.5 insulating sleeve and the round crimp terminals (FN type) with M4 insulating sleeve, tighten with torques ranging from 11.2 to 13.8 kg.cm. (from 1.1 to 1.3 N.m).
- (7) Prevent any contact of the wiring with the TrC coil.
- (8) The strong wiring must be separate from the weak wiring by 25 mm or more.
- (9) Wiring inside the machine should be laid in accordance with GAH010-Z unless otherwise specified.
- (10) The colors in parentheses indicate distinction colors.

7.15 Schematic wiring diagram (Connector type terminal board, temperature recorder and dry battery)



7.16 Stereoscopic wiring diagram (Connector type terminal board, temperature recorder and dry battery)



Notes for wiring

Note: (1) — line represents the line in the box. — line represents the external unit or junction cable. — line between terminals represents the jumper wire. — - — line represents the optional specification.


(2) The terminal numbers and applicable cables in each unit are as shown below.

UL1015 AWG16 (1.25 mm²): _____
 UL1015 AWG14 (2.0 mm²): — A —
 UL1015 AWG12 (3.5 mm²): — B —
 UL1015 AWG10 (5.5 mm²): — C —

(3) Line color


BLK: Black, BLU: Blue, GRY: Grey
BRN: Brown, RED: Red, YLW: Yellow
WHT: White, GRN: Green

(5) When tightening the two round terminals, tighten as shown below. When tightening the two terminals whose wire sizes are different, the larger size wire must be placed under the smaller size one.



- (6) At the two tightening positions of round crimp terminals with M3.5 insulating sleeve (FN type) or tightening positions of round crimp terminal (FN type) with M3.5 insulating sleeve and the round crimp terminals (FN type) with M4 insulating sleeve, tighten with torques ranging from 11.2 to 13.8 kg.cm. (from 1.1 to 1.3 N.m).
- (7) Prevent any contact of the wiring with the TrC coil.
- (8) The strong wiring must be separate from the weak wiring by 25 mm or more.
- (9) Wiring inside the machine should be laid in accordance with GAH010-Z unless otherwise specified.
- (10) The colors in parentheses indicate distinction colors.

7.18 Stereoscopic wiring diagram (Screwed cramp type terminal board, temperature recorder and dry battery)



8. OPTIONAL FUNCTIONS MANUAL

Some models may be equipped with the options shown below.

Applicable options are marked with ○-marks.



Type LXE10E-	TR No.	8.1 Electronic temperature recorder		8.2 Electronic controller								
		8.1.1 Standard type	8.1.2 Rechargeable battery type	8.2.1 Special operation 1	8.2.2 Special operation 2	8.2.3 Special operation 3	8.2.4 Special controller setting	8.2.5 Setting temperature and operation mode (with Partial frozen mode)	8.2.6 Defrost interval	8.2.7 G-SET operation 1	8.2.8 G-SET operation 2	8.2.9 Bulb mode
A4	TR02-02A											
A5 A5A A5B	TR05-04											
A5BR	TR05-23											
A5C	TR05-18A											
A6	TR02-01			○					○			
A7	TR02-09	○	○									
A8	TR02-10										○	
A9	TR05-05										○	
A9A	TR06-14											
A9AR	TR06-15											
A11 A20 A26 A26A	TR05-11	○	○			○				○		
A12 A12A A12B A28	TR05-10							○	○			
A12C A12D A12E	TR05-19								○			
A12F	TR06-15											
A14	TR02-14							○				○
A15 A15A A15AR A15B	TR05-06							○				○
A15BR A15C A15D A15E	TR05-14B											
A17 A17A A35 A35A	TR06-01B							○				
A18	TR03-02	○	○		○					○		
A18A A18B A30	TR05-09A	○	○		○					○		
A19	TR05-15										○	
A21A A21B A21C	TR05-20A											
A23	TR04-04A						○			○		
A23A A23B	TR05-21A						○			○		
A24R A9R	TR05-03											
A26B A26C	TR06-02									○		
A27	TR04-05							○				
A27A A27B	TR06-03											
A29 A29A	TR05-01											
A31 A31A A31B	TR05-02B											
A33	TR06-04											

Type LXE10E-	TR No.	8.2 Electronic controller				8.3 Control box			8.4 USDA transportation	8.5 Trans FRESH	8.6 Special service port	8.7 Pressure gauge
		8.2.10 Dehumidification control	8.2.11 Manual check selection mode	8.2.12 F.PTI specification	8.2.13 Rechargeable battery	8.3.1 Installation of personal computer receptacle and spare fuse in the control box	8.3.2 Cable clamp bracket 1	8.3.3 Cable clamp bracket 2				
A4	TR02-02A											
A5 A5A A5B	TR05-04											
A5BR	TR05-23							○				
A5C	TR05-18A											
A6	TR02-01					○	○					
A7	TR02-09							○				
A8	TR02-10							○				
A9	TR05-05							○		○		
A9A	TR06-14											
A9AR	TR06-15											
A11 A20 A26 A26A	TR05-11	○				○		○	○			
A12 A12A A12B A28	TR05-10			○		○	○	○	○			
A12C A12D A12E	TR05-19			○		○		○				
A12F	TR06-15											
A14	TR02-14	○							○			
A15 A15A A15AR A15B	TR05-06	○							○			
A15BR A15C A15D A15E	TR05-14B											
A17 A17A A35 A35A	TR06-01B				○	○		○				
A18	TR03-02	○	○				○					
A18A A18B A30	TR05-09A	○	○				○			○		
A19	TR05-15							○				
A21A A21B A21C	TR05-20A											
A23	TR04-04A										○	○
A23A A23B	TR05-21A										○	○
A24R A9R	TR05-03											
A26B A26C	TR06-02	○						○	○			
A27	TR04-05	○								○		
A27A A27B	TR06-03	○								○		
A29 A29A	TR05-01											
A31 A31A A31B	TR05-02B	○										
A33	TR06-04	○			○							

8.1 Electronic temperature recorder (Applicable models:LXE10E- A7,A11,A20,A26(A),A18(A,B) and A30)

8.1.1 Standard type

This recorder automatically records the control temperature (either return air temperature or supply air temperature) with the chilled/partial frozen and frozen switching signals from the controller. The faulty sensor detection function and calibration function are integrated for maintenance and inspection.



(1) Specifications

- Model DER9601A
- Power supply AC13V 50/60Hz
- Recording temperature range -30.0 to $+25.0$ °C (-22 to $+77$ °F)
- Chart paper Round type 8-inch pressure-sensitive paper [PARTLOW PSD-217C (REV.A) or equivalent] (31days/rev.)

● Battery

Use	Type	Specification	Standard
Chart drive	R14P (SUM-2)	DC1.5 V U2 (C size) type	JISC8501 IEC60086
Recording pen goes to upper end of the chart	6LR61	DC9V	JISC8511 IEC60086

Battery life

Approx. 1 year (Check with the residual voltage indicator)

● Residual voltage indicator (optional)

Green zone : Operable

Silver zone : Usable for 7 days

Red zone : Replace battery

● Recording pen driving system

Pulse motor drive

● Sensor (Thermistor)

Model	Use
ST9503-4	RSS: For supply air temperature recording
ST9503-2	RRS: For return air temperature recording

Note : Recording accuracy

The accuracy of the recorder and the sensor are shown in the following table.

The adjustment with calibration is applicable only on the recorder.


Recording temperature range	Accuracy °C		
	Recorder	Sensor	Total
25°C to 10°C	± 1.0	± 1.0	± 2.0
10°C to -15°C	± 0.5	± 0.3	± 0.8
-15°C to -29.9°C	± 1.0	± 1.0	± 2.0

(2) Devices and schematic wiring diagram

1) Devices

Device	Location
Temperature recorder board	In the temperature recorder box
Recorder return air sensor (RRS)	Evaporator suction area
Recorder supply air sensor (RSS)	Evaporator discharge area

2) Schematic wiring diagram



(3) Checking (Calibration) of the indicated value on the recorder (optional)

This recorder can be checked for its switching function for recording sensors and temperature indication function regardless of inside temperature, and can be adjusted.


1) Switching function for recording sensors

By operating the set temperature on the controller, the temperature recorder automatically switches the recording sensors, return air sensor (for frozen and partial frozen modes) and supply air sensor (for chilled mode)


Set temperature (°C)	Recording sensor
-30.0 to -3.0	Return air sensor
-2.9 to 25.0	Supply air sensor

① Calibration switch

② Battery check button



2) Calibration function



CAUTION

During the indoor temperature is stable, recording temperature is adjustable by changing the pen position using the calibration switch. Do not move the temperature recording pen manually.

Notes: 1. The pen is adjusted to suit to the PSD-217C (REV.A) recording chart paper or its equivalent.

Do not use the recording charts other than ones mentioned above.

2. Do not change the position of pen during transportation.


3. When the power is supplied, the pen vibrates momentarily and will return to its original position due to the recording characteristics, but this is not a sign of trouble.

(4) Replacement of temperature recorder

① Turn off the circuit breaker.

② Remove the wiring connector and sensors from the back of the temperature recorder.

③ Remove the hinge on the bottom and the speed bolts on the top.




④ Replace the temperature recorder board.

⑤ After replacement, be sure to check the wiring and operation.

8.1.2 Rechargeable battery type

● Temperature record with power supply turned off

When the power supply is turned off, the pen will move to the outer circumference of recording sheet simultaneously.



● Rechargeable battery

The rechargeable battery is equipped on the electronic temperature recorder.

(Application of rechargeable battery)

- ① Drive of chart
- ② Pen swings up when the main power is turned off (+25°C is recorded.)

(Specifications of rechargeable battery)

- Charge type nickel cadmium battery (7.2V, 600mA)
- Model:6N-600AA-2


(Replacement reference)

- As reference, 2 to 4 years have elapsed.
- Replace the battery if the pen does not swing up to +25°C when the breaker is turned off.
- Confirm the life of rechargeable battery and make sure the internal gear rotating properly through the rotation check window when the battery was replaced.

8.2 Electronic controller

8.2.1 Special operation 1(Applicable model : LXE10E-A6)

1.Name and function of each components



- | | |
|---|---|
| ① SUPPLY LED (Lights when "supply air temperature" is indicated.) | ⑦ IN RANGE LED (Lights when the control temperature is in range.) |
| ② RETURN LED (Lights when "return air temperature" is indicated.) | ⑧ DE-HUMID.LED (Lights when the controller is the dehumidification control optional.) |
| ③ ALARM LED (Lights alarm is generated.) | ⑨ Temperature base (Used for the graphic chart indication on the LCD.) |
| ④ R.H.LED (Lights when "relative humidity" is indicated.) | ⑩ Time base (Used for the graphic chart indication on the LCD.) |
| ⑤ COMP.LED (Lights when the compressor is running.) | |
| ⑥ DEFROST LED (Lights when the unit is under the defrosting operation.) | |

Function of operation key


MODE



●MODE Key


Shift from "Current indication mode" to "Display (LED) off." / Automatic pump down mode.

2. Operation procedure flow chart



Display (LED) off/ AUTOMATIC PUMP DOWN OPERATION mode

The controller display (LED) to off and automatic pump down operation collecting refrigerant to the liquid receiver are executed.



Press the **MODE** **[M]** key in current indication mode to go to Display (LED) off / Automatic pump down operation.

※ After the automatic pump down is completed, the pump down status is maintained until the power supply is turned off.

Pressing the **MODE** **[M]** key changes the mode between Display (LED) off and automatic pump down.


The set point can be set by using **[△]** key or **[▽]** key.

Setting item	LED panel	LCD panel	Setting method
<pre> graph TD A[Current indication mode] -- "MODE M" --> B[Display (LED) off] B -- "MODE M" --> C[Automatic pump down operation] C -- "confirm key" --> A </pre> <p>or non-key operation for 5 minutes</p>	—	—	—
	ON, OFF	diSPOFF	Select ON by using or key, and press the key to determine the setting.
	ON, OFF	P down	Select "ON" by using key and key, and press the key to determine the setting.

Note) Refer to the detail of automatic pump down function in the "Section 4.1.3 (2)" of Service manual.

8.2.2 Special operation 2 (Applicable models:LXE10E-A18(A,B) and A30)

1.Name and function of each components



- | | |
|---|---|
| ① SUPPLY LED (Lights when "supply air temperature" is indicated.) | ⑦ IN RANGE LED (Lights when the control temperature is in range.) |
| ② RETURN LED (Lights when "return air temperature" is indicated.) | ⑧ DE-HUMID.LED (Lights when the controller is the dehumidification control optional.) |
| ③ ALARM LED (Lights alarm is generated.) | ⑨ Temperature base (Used for the graphic chart indication on the LCD.) |
| ④ R.H.LED (Lights when "relative humidity" is indicated.) | ⑩ Time base (Used for the graphic chart indication on the LCD.) |
| ⑤ COMP.LED (Lights when the compressor is running.) | |
| ⑥ DEFROST LED (Lights when the unit is under the defrosting operation.) | |

Function of operation key

MODE




●MODE Key

Shift from "Current indication mode" G-SET operation." / Automatic pump down mode / Dehumidification ON-A · OFF setting.


Note: When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.

2 Operation procedure flow chart



3. G-SET operation/Automatic pump down operation mood/Dehumidification ON-A · OFF setting

The energy consumption reducing operation during G-SET operation, automatic pump down operation collecting refrigerant to the liquid receiver and dehumidification ON-A · OFF setting are executed.



Press the **MODE M** key in current indication mode to go to G-SET operation / Automatic pump down operation / Dehumidification ON-A · OFF setting.

※ After the automatic pump down is completed, the pump down status is maintained until the power supply is turned off.

Pressing the **MODE M** key changes the mode between G-SET operation and automatic pump down / Dehumidification ON-A · OFF setting.

The set point can be set by using **△** key or **▽** key.

Note: When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.

Setting item	LED panel	LCD panel	Setting method
<pre> graph TD A[Current indication mode] -- "MODE M" --> B[G-SET operation] B -- "MODE M" --> C[Automatic pump down operation] C -- "MODE M" --> D[Dehumidification ON-A·OFF setting] D -- "MODE M" --> A </pre>	—	—	—
	ON, OFF	diSPOFF	Select "ON" by using or , and press the key to determine the setting.
	ON, OFF	P down	Select "ON" by using key and , and press the key to determine the setting.
	OFF, ON-A	dHu	Select "ON-A" by using key and , and press the key to determine the setting.

Note) Refer to the detail of automatic pump down function in the "Section 4.1.3(2)" of Service manual.



CAUTION

1. To apply the dehumidification control, be sure to set "ON-A".
2. ON/OFF of the reheating coil and DE-HUMID LED lit/unlit are not synchronous.
3. When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.

4. Setting flow chart

This configuration setting flow shall be utilized, when


Case 1) Where USDA cool transportation setting, defrosting interval automatic changing function, or dehumidification control clearing function is required. (Optional function setting)

Case 2) Where an urgent change of container ID to other ID should be made.
(Setting of container ID and calendar)

Case 3) Where a new controller is installed for replacement. (Settings of optional function, basic function, optional conditions, and input data should be made.)

NOTE 1 : All initial settings are pre-set, when the unit is delivered.

2 : In case to complete the setting change, CIRCUIT BREAKER shall be turned off



4.1 Controller initial setting

Optional function mode

<ul style="list-style-type: none"> ●USDA sensor setting ●Dehumidification control on/off setting 	<ul style="list-style-type: none"> ●Defrosting interval automatic changing function on/off setting ●Dehumidification control clearing function on/off setting 	Page 3-26
--	---	-----------

Basic function setting mode

<ul style="list-style-type: none"> ●Controller type ●Compressor unload ●Reheat coil 	<ul style="list-style-type: none"> ●Logging interval ●Data recorder sensor on/off ●Power supply ●Compressor horse power ●Indication (LED section) light off function on/off ●FA-SEN 	Page 3-27 Page 3-28
--	---	------------------------

Optional condition setting mode

<ul style="list-style-type: none"> ●Chartless function setting ●Type of USDA sensor ●°C/°F set 	<ul style="list-style-type: none"> ●H001 ●H002 ●H003 ●H004 ●H005 ●H006 	<ul style="list-style-type: none"> ●d1-- ●d2-- ●d3-- ●d-1- ●d-2- 	Page 3-29 Page 3-30
---	--	---	------------------------

Input data mode

<ul style="list-style-type: none"> ●Container I.D. (No.) ●Controller time 	Page 3-31 Page 3-32
---	------------------------

Personal computer and controller

Controller software download mode


Data logged in a personal computer and controller is exchangeable. For the details, refer to the "Operation manual for personal computer software".	Page 3-32
--	-----------

4.2. Optional function setting mode

Following functions can be set up.

With/Without setting of USDA sensor, With/without setting of cargo temperature, With/Without setting of dehumidification control, ON/OFF setting of defrosting interval automatic changing function, and ON/OFF setting of dehumidification control clearing function


<Key operation to enter/exit>



<Key operation in this mode>

Whenever the **[S]** key is pressed, the display changes.

Turn the power breaker OFF after the setting.



To set the USDA ON/OFF and CARGO TEMPERATURE SENSOR ON/OFF: Select "OFF (not in use)", "3 (3 USDA probes are in use)", or "4 (3 USDA probes and 1 cargo temperature sensor are in use)" on the LED while the LCD displays "USdA".

Whenever the **[△]** or **[▽]** key is pressed, the indication of "OFF" or "3" or "4" is changed.

Press the **[↵]** key to determine the setting.

Note: When two USDA probes are connected, the setting will be determined automatically to "3" (3 USDA probes are in use).

To set the DEHUMIDIFICATION CONTROL:

Select "ON" (conducting dehumidifying with humidity sensor), "ON-A" (conducting dehumidifying without humidity sensor) or "OFF" (conducting no dehumidifying) on the LED while the LCD indicates "dHU".

Whenever the **[△]** or **[▽]** key is pressed, the indication of "ON", "ON-A" or "OFF" is changed.

Press the **[↵]** key to determine the setting.

Note : This setting can be changed by **[M]** key.

ON/OFF setting of defrosting interval automatic changing function

In order to make ON/OFF setting of the defrosting interval automatic changing function, when the "AUT-INT" is displayed on the LCD screen, select ON (Use the defrosting interval automatic changing function) or OFF (Not use the defrosting interval automatic changing function) displayed on the LED screen.

Every time the "ON" or "OFF" key is pressed, the display will change.

To determine the setting, press the Enter key.

For the contents of the defrosting interval automatic changing function, refer to information on page 5-21.

ON/OFF setting of dehumidification control clearing function

In order to make ON/OFF setting of the dehumidification control clearing function, when the "dHU-CAN" is displayed on the LCD screen, select ON (Use the dehumidification control clearing function) or OFF (Not use the dehumidification control clearing function) displayed on the LED screen.

Every time the "ON" or "OFF" key is pressed, the display will change.

To determine the setting, press the Enter key.

For the contents of the dehumidification control clearing function, refer to information on page 5-38.


5. Automatic pump down

An automatic pump down system is applied to the unit to prevent the unit operation from extra decreasing of low pressure due to pump down operation or burning of scroll compressor due to close stop valve.

(1) Controller operation

Press the **MODE** **M** key twice to select the pump down mode, then, the LCD indicates "P down".

Select "ON" by using **▽** key or **△** key, and press the **↵** key to start the automatic pump down operation.



※1: When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.

○ Controller indication





Fig. 2

6. Frozen mode

6.1 Control state transition and common control



6.2 Operation of magnetic contactor and solenoid valve

Component name			Thermostat ON	Pump down	Thermostat OFF
Magnetic contactor	Compressor	CC	ON	ON	OFF
	Evaporator fan. High speed	EFH	OFF	OFF	OFF
	Evaporator fan. Low speed	EFL	ON	ON	ON
	Condenser fan	CF	ON / OFF※1	ON / OFF※1	OFF
Solenoid valve	Liquid solenoid valve	LSV	ON	OFF	OFF
	Economizer solenoid valve	ESV	ON(OFF※3)	ON(OFF※3)	OFF
	Injection solenoid valve	ISV	OFF(ON※2)	OFF(ON※2)	OFF
	Hot-gas solenoid valve	HSV	OFF	OFF	OFF
	Defrost solenoid valve	DSV	OFF	OFF	OFF
	Discharge gas by-pass solenoid valve	BSV	OFF	OFF	OFF
Suction modulating valve		SMV	100%		
Electronic expansion valve		EV	10 to 100%		

Note) ※1: High pressure control

※2: Injection control (Refer to Page 2-28 of Service manual)



※3: Economizer control (Refer to Page 2-29 of Service manual)

6.3 Set point temperature and control sensor

When the set point temperature (referred to as SP hereafter) is $-10.1^{\circ}\text{C}(+13.8^{\circ}\text{F})$ or lower, the compressor is operated ON and OFF, in response to return air temperature.

6.4 Control

- ① When the control temperature reaches $\text{SP}-0.5^{\circ}\text{C}$ (point A), the compressor and condenser fan are turned off after the liquid solenoid valve has been de-energized and the pump down operation has been completed.
- ② When the control temperature exceeds $\text{SP}+0.5^{\circ}\text{C}$, the compressor, liquid solenoid valve and condenser fan are turned on. However, the compressor runs for at least 2 minutes every time once it is turned on. Even if the control temperature becomes $\text{SP}-0.5^{\circ}\text{C}$ or lower (point C) within 2 minutes after the compressor is turned on, the compressor, condenser fan and liquid solenoid valve are not turned off. (2 minutes compressor forced operation)



EV: Elec. Exp. Valve
 LSV: Liquid Solenoid Valve
 DSV: Defrost Solenoid Valve
 ESV: Economizer Solenoid Valve
 DPR: Discharge pressure regulator
 SMV: Suction Modulation Valve

HSV: Hot Gas Solenoid Valve
 ISV: Injection Solenoid Valve
 BSV: Discharge gas Bypass Solenoid Valve
 LPT: Low Pressure Transducer
 HPT: High Pressure Transducer
 HPS: High Pressure Switch

7. Defrosting operation

(1) Defrosting system

A hot-gas defrost system is adopted in the units; i.e. the high temperature and high pressure refrigerant (hot gas) from the compressor is sent to the evaporator and drain pan for defrosting. Since the evaporator is heated directly by the hot gas (refrigerant), defrosting can be performed effectively.

(2) Defrosting initiation

Defrosting is initiated by the timer or the manual defrost key.

However, defrosting is not initiated when frosting on the evaporator can not be detected.

- Evaporator inlet temperature : 5°C or higher (during chilled operation)
- Evaporator outlet temperature : 20°C or higher

①Initiation by timer (Timer is set at the electronic controller, refer to section 3.3 of service manual for its operating method.)

Type of timer	Defrosting interval set	Function
Long timer	3, 6, 9, 12, 24 and 99※ ¹ hours are selectable Optional function setting mode: If the "AUT-INT" is set to ON, the set time may be changed. For details, refer to information in "Defrosting Interval Automatic Changing Function" (on page 8-21).	Regardless of the control temperature, defrosting is initiated according to the selected interval.
Short timer	4 hours※ ²	Defrosting is initiated every 4 hours until the control temperature comes within the in-range after pull-down.
Out-range timer	30 minutes	After the control temperature comes within in-range once, defrosting will be started 30 minutes later if the control temperature rises out of the in-range.

※1. On-demand defrost selection (12 hours for Frozen mode and 6 hours automatic for Chilled mode)

※2. 6 hours when the control temperature is -20°C or below.

②Starting by MANUAL DEFROST key (on the operation panel sheet key)

Press the MANUAL DEFROST key, then press the ENTER/ESC key while indicate "ON" on the LED display. The manual defrosting operation starts.

③Initiation by frost detection

If the suction air temperature does not drop at the speed of 0.2°C/1hr during frozen pull-down operation, defrosting will be initiated because it is judged that frost is formed on the evaporator. However, if the suction temperature is -20°C or lower, defrosting will not be initiated. (activated)

(3) On demand defrost setting

When "99" in long timer is selected, defrosting is activated upon the condition of frost on evaporator coil. This function is only for Frozen setting (SP < -10.1 deg C). and starting with 12 hours. (If this function is selected for chilled setting, defrost initiates every 6 hours automatically.)

Procedure:

Step 1: After defrost, the controller records compressor running time for 1st 1 hour. (T1)

Step 2: When 12 hours passed after defrost, controller records compressor running time for last 1 hour (T2). And the controller check whether the below condition is satisfied.

$$T2 > T1 \times 1.15$$

Step 3: If the above condition is satisfied, defrost is activated.

If above condition is not satisfied, defrost is postponed another one hour.

After counting up 13 hours, then repeat "Step 2".

Defrost will be postponed every one hour until the above condition (Step 2) is satisfied. (Max. 24 hours)

(4)Defrosting Interval Automatic Changing Function

What is the Defrosting Interval Automatic Changing Function?

This is a function to measure the time required for defrosting operation with the "long timer"and, according to the measurement, changes intervals of the defrosting operation. If a lapse of time after turning OFF the power supply is less than 48 hours, the intervals of defrosting operation immediately before turning OFF the power supply and elapsed time after the completion of defrosting operation will be maintained. If a lapse of time after turning OFF the power supply is 48 hours or more, the intervals of defrosting operation will be reset to the default value of 6 hours and the elapsed time after the completion of defrosting operation will be reset to zero, respectively.

*** Caution**

If the defrosting operation is performed according to any timer other than the long timer (e.g. short timer or out-range timer), the defrosting operation counter will be reset to zero.

Conditions to use the Defrosting Interval Automatic Changing Function:

In order to use the defrosting interval automatic changing function, the following conditions should be both satisfied.

- The defrosting interval automatic changing function is set to "ON" while in optional function setting mode.
For details of the optional function setting, refer to information on page 5-15.
- The set temperature falls within the range of $-2.0^{\circ}\text{C} \leq +6.0^{\circ}\text{C}$.

Details of Defrosting Interval Automatic Changing Function

To make the interval shorter:

If defrosting operation for a period of 40 minutes or more is performed consecutively two times or defrosting operation for a period of 60 minutes or more is performed once, make the defrosting operation interval shorter by 1 step with the "long timer".

Example:

- 6-hour interval before change → 3-hour interval after change
- 12-hour interval before change → 9-hour interval after change

To make the interval longer:

If defrosting operation for a period of 20 minutes or less is performed consecutively two times, make the defrosting operation interval longer by 1 step with the "long timer".

Example:

- 3-hour interval before change → 6-hour interval after change
- 9-hour interval before change → 12-hour interval after change

Resetting of Contents of Defrosting Interval Automatic Changing Function


If a lapse of time after turning OFF the power supply is 48 hours or more, the intervals of defrosting operation will be reset to the default value of 6 hours and the elapsed time after the completion of defrosting operation will be reset to zero, respectively.

Procedure for counting a period of time during when the power supply is kept OFF

The period of time during when the power supply is kept OFF is counted in increments of 30 minutes. Example: When a lapse of time after the completion of defrosting operation is 5 hours and 29 minutes and the interval of defrosting operation is set to 6 hours, if the power supply is turned OFF once and ON again after a lapse of 47 hours and 59 minutes, counting of a period of time will be restarted by taking the lapse of time as 5 hours (discarding the time less than 30 minutes) to start defrosting operation 1 hour after the power supply is turned ON.

8.2.3 Special operation 3 (Applicable models: LXE10E-A11, A20 and A26(A))

1. Name and function of each components



- ① SUPPLY LED (Lights when "supply air temperature" is indicated.)
 - ② RETURN LED (Lights when "return air temperature" is indicated.)
 - ③ ALARM LED (Lights alarm is generated.)
 - ④ R.H. LED (Lights when "relative humidity" is indicated.)
 - ⑤ COMP. LED (Lights when the compressor is running.)
 - ⑥ DEFROST LED (Lights when the unit is under the defrosting operation.)
 - ⑦ IN RANGE LED (Lights when the control temperature is in range.)
 - ⑧ DE-HUMID. LED (Lights when the controller is the dehumidification control optional.)
 - ⑨ Temperature base (Used for the graphic chart indication on the LCD.)
 - ⑩ Time base (Used for the graphic chart indication on the LCD.)
- ※: Dehumidification control is available on A26 and A26A only.

Function of operation key

MODE




● MODE Key

Shift from "Current indication mode" G-SET operation." / Automatic pump down mode / Dehumidification ON-A · OFF setting.

Note: When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.


2. Operation procedure flow chart



3. G-SET operation/Automatic pump down operation mood/Dehumidification ON-A · OFF setting

The energy consumption reducing operation during G-SET operation, automatic pump down operation collecting refrigerant to the liquid receiver and dehumidification ON-A · OFF setting are executed.

※ Dehumidification control is available on A26 and A26A only.



Press the **MODE M** key in current indication mode to go to G-SET operation / Automatic pump down operation / Dehumidification ON-A · OFF setting.

※ After the automatic pump down is completed, the pump down status is maintained until the power supply is turned off.

Pressing the **MODE M** key changes the mode between G-SET operation and automatic pump down / Dehumidification ON-A · OFF setting.

The set point can be set by using **△** key or **▽** key.

Note: When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.

Setting item	LED panel	LCD panel	Setting method
<pre> graph TD A[Current indication mode] -- "MODE M" --> B[G-SET operation] B -- "MODE M" --> C[Automatic pump down operation] C -- "MODE M" --> D[Dehumidification ON-A·OFF setting] D -- "MODE M" --> A </pre>	—	—	—
	ON, OFF	diSPOFF	Select "ON" by using or , and press the key to determine the setting.
	ON, OFF	P down	Select "ON" by using key and , and press the key to determine the setting.
	OFF, ON-A	dHu	Select "ON-A" by using key and , and press the key to determine the setting.

Note) Refer to the detail of automatic pump down function in the "Section 4.1.3" of Service manual.



CAUTION

1. To apply the dehumidification control, be sure to set "ON-A".
2. ON/OFF of the reheating coil and DE-HUMID LED lit/unlit are not synchronous.
3. When the dehumidification ON-A · OFF is set to ON, G-Set operating mode will be skipped.

8.2.4 Special controller setting (Applicable models:LXE10E-A23(A,B))

1.Setting flow chart

This configuration setting flow shall be utilized, when

CASE 1) USDA transportation setting is required (※10 Optional Function Setting on page 3-29)


CASE 2) Container ID shall to be subjected to change from another container for emergency use.

(※13 Container ID & Time Setting)

CASE 3) Controller is replaced to new one. (All setting in ※10-13 (page 3-42)shall be set.)

NOTE 1 : All initial settings are pre-setted, when the unit is delivered.

2 : In case to complete the setting change, CIRCUIT BREAKER shall be turned off.



Controller initial setting

※10. Optional function mode

- USDA sensor setting
- Dehumidification control on/off setting

Page 3-26

※11. Basic function setting mode

- | | |
|--------------------|---|
| ●Controller type | ●Logging interval |
| ●Compressor unload | ●Data recorder sensor on/off |
| ●Reheat coil | ●Power supply |
| | ●Compressor horse power |
| | ●Indication (LED section) light off function on/off |
| | ●Ventilator opening detector function setting |

Page 3-27
Page 3-28

※12. Optional condition setting mode

- | | | |
|-----------------------------|-------|-------|
| ●Chartless function setting | ●H001 | ●d1-- |
| ●Type of USDA sensor | ●H002 | ●d2-- |
| ●°C/°F set | ●H003 | ●d3-- |
| | ●H004 | ●d-1- |
| | ●H005 | ●d-2- |
| | ●H006 | |

Page 3-29
to
Page 3-31

※13. Input data mode

- IContainer I.D. (No.)
- IController time

Page 3-31
Page 3-32

Personal computer and controller


※14. Controller software download mode

Data logged in a personal computer and controller is exchangeable.
For the details, refer to the "Operation manual for personal computer software".

Page 3-32

2. Basic function setting mode


<Key operation to enter/exit>



<Key operation in this mode>

Whenever the **[S]** key is pressed, the display changes.

Turn the power breaker OFF after the setting.



Select "A", "b", "c" or "d" on the LED while the LCD displays "dECOS-3".

Whenever the **[△]** or **[▽]** key is pressed, the indication of "A" or "b" or "c" is changed.

Press the **[↵]** key to determine the setting.

"A" represents "DECOS-III a", "b" represents "DECOS-III b" and "c" represents "DECOS-III c".

The unit is comes with the "DECOS-III c" additionally.

Select "C", and press **[↵]** key to determine the setting.

To set the logging interval:

Select "15", "30" or "60" on the LED while the LCD displays "LOG INT".

The unit is in minutes.


Whenever the **[△]** or **[▽]** key is pressed, the indication of "15" or "30" or "60" is changed.

Press the **[↵]** key to determine the setting.

To set the data recorder sensor ON/OFF:

Select "ON" (in use) or "OFF" (not in use) on the LED while the LCD displays "REC SEN".

Whenever the **[△]** or **[▽]** key is pressed, the indication of "ON" or "OFF" is changed. Press the **[↵]** key to determine the setting.



To set the power input:

Select "Sing" or "dUAL" on the LED when the LCD displays "OC-SET" .

Whenever the or key is pressed, the indication of "Sing" or "dUAL" is changed. Press the key to determine the setting.

For the unit, select "Sing", and press key to determine the setting.

To set the horse power setting:

Select "5" or "10" on the LED when the LCD displays "HP" (Horse power).

Whenever the or key is pressed, the indication of "5" or "10" is changed. Press the key to determine the setting.

To set the "panel (LED) lighting off" function ON/OFF:

Select "ON" (provided) or "OFF" (not provided) on the LED when the LCD displays "dISP" .

Whenever the or key is pressed, the indication of "ON" or "OFF" is changed. Press the key to determine the setting.

Note: When the 0/CHART key is pressed twice when the "panel (LED) lighting off" function is ON, the lights on the LED panel are turned off.

To set the compressor unloading system:

Select "33 (provided)" or "100 (not provided)" on the LED when the LCD displays "COMP".

Whenever the or key is pressed, the indication of "33" or "100" is changed.

Note: This "33" setting is applicable for LXE10D type only.

To set the dehumidification coil ON/OFF:

Select "ON (provided)" or "OFF (not provided)" on the LED when the LCD displays "REHEAT".

Whenever the or key is pressed, the indication of "ON" or "OFF" is changed. Press the key to determine the setting

Select "H (Upper)", L (Lower)" or "OFF (not provided)" on the LED when the LCD displays "FA SEN".

Whenever the or key is pressed, the indication of "H", "L" or "OFF" is changed. Press the key to determine the setting.

8.2.5 Setting temperature and operation mode

(Applicable models:LXE10E-A11,A12(A,B),A14,A15(A,B),A17(A),A27,A28 and A35(A)(with Partial frozen mode))

	Operating temperature		
Operation mode	Chilled mode	Partial frozen mode	Frozen mode
Operation procedure DECOS III c	Set the operating temperature to the range of +30 to -2.9°C (+86 to +26.8°F).	Set the operating temperature to the range of -3.0 to -10.0°C (+26.6 to +14°F).	Set the operating temperature to the range of -10.1 to -30.0°C (+13.8 to -22°F).
Operation procedure DECOS III d	Set the operating temperature to the range of +30 to -3.0°C (+86 to +26.6°F).	Set the operating temperature to the range of -3.1 to -10.0°C (+26.4 to +14°F).	Set the operating temperature to the range of -10.1 to -30.0°C (+13.8 to -22°F).
Functions	Used to perform chilled operation, which proportionally controls the temperature inside by means of the sensor of discharge air temperature.	Used to perform partial frozen operation, which proportionally controls the temperature inside by means of the sensor of suction air temperature.	Used to perform frozen operation, which turns the compressor ON or OFF and proportionally controls the temperature inside by means of the sensor of suction air temperature.
	The evaporation fan performs High-operation.		The evaporation fan performs Low-operation.

8.2.6 Defrost interval (Applicable models:LXE10E-A6,A12(AtoE) andA28)

Unlike standard units, this unit makes selection of the long-period setting timer or the short-period setting timer in accordance with a lapse of time after the unit starts up.





● Commencement of defrost operation








	Within 72 hours after the unit starts up.	From 72 hours onward after the unit starts up.
Commencement of defrost operation	The defrost operation is commenced in accordance with a shorter period of time set though either the short-period setting timer (4 hours) or the long-period setting timer.	The defrost operation is commenced in accordance with a period of time set though the long-period setting timer.

8.2.7 G-SET operation 1

(Applicable models:LXE10E-A11,A20,A26(AtoC),A18(A,B),A30 and A35(A,B))




Generator setting operation

- ① Press the MODE  key.
- ② Select "11", "12", "13", "14", "15" (kVA) or "OFF" indicated on the LED display using the  key or the  key, and press the  key to determine the setting, then the energy saving operation starts so that the energy consumption is saved to be the selected value (kVA) or lower.
- ※ If "OFF" is pressed in the procedure ② above, the energy saving operation will be cancelled.
- ※ If the power supply is turned off when the setting mode is set to exception of 12(kVA), the setting is returned to 12(kVA) automatically.
- ※ Even though the value is expressed in kVA, this is actually a value in kW.

Setting item	LED panel	LCD panel	Setting method
	—	—	—
	Energy saving set point OFF, 11, 12, 13, 14, 15 unit: kVA Note) Even though the value is expressed in kVA, this is actually a value in kW.	G-SET	Select the energy saving set point by using  or  key, and press the  key to determine the setting.
	ON, OFF	P down	Select "ON" by using  key and  key, and press the  key to determine the setting.

8.2.8 G-SET operation 2 (Applicable models:LXE10E-A8,A9 and A19)

Generator setting operation

- ① Press the G-SET key.
- ② Using  and , select "11", "12", "13", "14", "15" (KVA) or "OFF", and determine it with  key. The energy consumption reducing operation will be applied under the selected value.
- ※ To reset Generator setting operation, set OFF in the above operation step ②.
- ※ When Generator setting operation is set, it will not be reset even if the power supply is turned off. (The setting is held.)

8.2.9 Valve mode

(Applicable models: LXE10E-A14 and A15(A,AR,B))

*** Reheat coil and humidity sensor (optional) are required.**

The valve mode shown below is used for transportation of bulbs. To execute the valve mode, setup of the controller is required. (See the next page)

In the valve mode operation, "b" is displayed in the first segment of the LED display.

Items shown below can be set up.


1) Dehumidification: On/Off

If it is set to "ON", the dehumidification range can be set up from 95% to 60%. (Default: 95%)



2) Evaporator fan speed: Alternate operation (alternate operation between High and Low every hour)


High speed, low speed

3) Defrost start temperature: From +4°C to +18°C, (Default: 5°C)



4. MODE OPERATION

Press the  key (or  key) in current indication mode to go to MODE operation.



In mode operation, the following settings/operations are available.

1. Generator setting

Total power consumption can be reduced to desired Max setting for the specific generators set or power facilities.

The selections are "off (No limit)", "15" "14" "13" "12" "11" KVA.

2. Automatic pump down

Pump down can be executed automatically.

(Refer to "Automatic pump down" in 4.1.3)

3. LED display Light-OFF(OPTION)

All LED (includes LED lamp) can be switched off.

In order to execute this function, initial setting (Refer to initial setting in section 3.8.3) shall be required to change "on" position in advance.

4. Valve mode setup

In this mode, the valve mode operation can be executed. (See "Valve mode" in P.5-33.)

If the valve mode is set to "On", the initial setup can be changed as shown below.

① Dehumidification: on/off (default)

If "on" is chosen, the inside humidity can be changed from 95% (default) to 60%.

Default: 95%

② Evaporator fan speed: (H/L) alternate operation (default)/High/Low

③ Defrost start temperature (RS): From +4°C to +18°C, default: 5°C

8.2.10 Dehumidification control


(Applicable models: LXE10E-A11, A20, A26(AtoC), A14, A15(A, AR, B), A18(A, B), A27(A, B), A30, A31(A, B) and A33)

1. Summary

※If reheat coil (Optional) is equipped:


The unit have dehumidification control by a reheat coil, which is under the evaporator coil.

In dehumidification, the Reheat Solenoid Valve (RSV) opens to give high pressurized refrigerant to reheat coil. The "DEHUMID" LED lamp will light up.




2. Names of components

2.1 Outside



① Reheat coil solenoid valve (RSV)

2.2 Inside



① Reheat coil

3. Dehumidification control setting

This unit features the dehumidification function. Therefore, it is necessary to set whether the dehumidification control is to be executed or not according to the cargo to be transferred.

You can set whether the dehumidification control is to be executed or not by operating the display panel of controller.

3.1 Description of setting

Whether the dehumidification control is to be executed or not is switched over according to the setting of dehumidification control parameter "dHu" under the "7. G-SET operation / Automatic pump down operation mode / Dehumidification ON-A·OFF setting"

Dehumidification control	Setting of dehumidification control "dHu"	DE-HUMID LED	Remarks
To execute	ON-A (Applied)	ON	Case of the unit without the humidity sensor Note) If the following conditions are both satisfied, the dehumidification control will automatically be set to "OFF" (dehumidification control clearing function). <ul style="list-style-type: none">• The "dHU-CAN" is set to ON.• 48 hours or more lapsed after the main unit power supply turned OFF.
Not to execute	off (Not applied)	OFF	

Note) The dehumidification control clearing function is a function to automatically change the setting of dehumidification control to OFF if the main unit power supply turns OFF for a period of 48 hours or more. The ON/OFF setting of the dehumidification control clearing function "dHU-CAN" is made while in optional function setting mode. For details of setting procedure, refer to information (on page 3-26). The setting of dehumidification control "dHU" can also be made while in optional function setting mode.



CAUTION


1. ON/OFF of the reheating coil and DE-HUMID LED lit/unlit are not synchronous.
2. To apply the dehumidification control, be sure to set "ON-A".

8.2.11 Manual check selection mode (Applicable models:LXE10E-A18(A,B) and A30)

1. Setting flow chart

The LED indicate the values of following items.

Compressor operating time, Evaporator fan motor high-speed running current, Evaporator fan motor low-speed running current, Condenser fan motor running current, Battery life, Horse power, Elapsed time after trip start, Evaporator fan motor running time, Condenser fan motor running time, Controller software version and sensor calibration.



To indicate the compressor operating time:

Press the key while the LCD indicates "CC ×10H".

The operating time is [the value indicated on the LED] ×10 hours.

Pushing the key for 3 seconds sets compressor operating time to 0 (hour).

To indicate the current value of evaporator fan motor high-speed operation:

Press the key while the LCD indicates "EFH A", then the LED indicates the current value. (Unit: Ampere)

To indicate the current value of evaporator fan motor low-speed operation:

Press the key while the LCD indicates "EFL A", then the LED indicates the current value. (Unit: Ampere)

To indicate the current value of condenser fan motor running current:

Press the key while the LCD indicates "CF A", then the LED indicates the current value. (Unit: Ampere)

To indicate the elapsed time after trip start:

Press the key while the LCD indicates "TS H", then the LED indicates the elapsed time. (Unit: Hours).

When the key is depressed for 3 seconds while the elapsed time is indicated, the TRIP START is set, and the elapsed time display is reset to "0" (hour).

To indicate the evaporator fan motor-1 operating time:

Press the key while the LCD indicates "EF1 ×10H".

The operating time is [the value indicated on the LED] ×10 hours.

When the key is depressed for 3 seconds while the evaporator fan motor-1 operating time is indicated, the evaporator fan motor-1 operating time is reset to "0" (hour).

("EF1" stands for the right hand side fan motor seeing from the inside of the container.)

To indicate the evaporator fan motor-2 operating time:

Press the key while the LCD indicates "EF2 ×10H".

The operating time is [the value indicated on the LED] ×10 hours.

If the key is depressed for 3 seconds while the evaporator fan motor-2 operating time is indicated, the evaporator fan motor-2 operating time display is reset to "0" (hour).

"EF2" stands for the left hand side fan motor seeing from the inside of the container.

To indicate the condenser fan motor operating time:

Press the key while the LCD indicates "CF ×10H".

The operating time is [the value indicated on the LED] ×10 hours.

If the key is depressed for 3 seconds while the condenser fan motor operating time display is indicated, the condenser fan motor operating time display is reset to "0" (hour).

To indicate the controller software version:

Press the key while the LCD indicates "SOFTVER".

The value on the LED is the software version.

To calibrate the temperature sensor SS,RS,DSS or DRS ;


Press the key while the LCD indicates "CAL".

(Refer to the next page "2.1 sensor calibration" for more detail.)

8.2.12 F.PTI specification (Applicable models:LXE10E-A12(AtoE) and A28)


In order to perform F.PTI operation, this unit is designed by adding the following ① to ④ functions to the standard specification, which are enclosed with a dotted rectangular as shown below.

① Entry of set temperature while in F.PTI mode



② Display of set temperature and pull-down period while in F.PTI mode

Scrolling sensor display mode with the UP or DOWN key will display the temperature and period after DRS.




③List of detail on display and alarms of F.PTI step

Step	Item	Alarm display	
P50	Check the pull-down period to reach 0°C	J501	Outside outdoor temperature condition
		J502	Pull-down period -exceeded-
P60	Check the chilled operation for controllability.		
P70	Check the defrost operation.	J701	Outside commencement condition of defrost operation
		J702	Defrost operative period -exceeded-
P80	Check the pull-down period from 0°C to -18°C ■When SP = -18°C■	J801	Pull-down period -exceeded- (when the temperature does not reach -18°C within 3 hours)
	Check the pull-down period from 0°C to the set temperature (in the range of -18°C to -30°C.) ■When SP < -18°C■	J801	Pull-down period -exceeded- (when the temperature does not reach SP within 24 hours) ※Except for defrost operation
P90	Check the frozen operation for controllability.		

④Display after F.PTI

When F.PTI normally terminates, "FPE" ⇔ "Time" will be alternately displayed on the LCD at intervals of 3 seconds. (T ○○H○○)



⑤Defrost operation while in pull-down mode

Defrost operation by means of the short-period timer (4 hours or 6 hours) is not performed.

However, if the suction air temperature does not fall below 0.2°C/hour, the defrost operation will be initiated.

8.2.13 Rechargeable battery (Applicable models:LXE10E-A17(A),A35(A),A33)

The controller can use Rechargeable battery.It is not possible to exchange the type of battery afterwards.

The battery is installed to the lid of the controller.

The battery is positioned on CPU & I/O box in controller box.

Rechargeable: DAIKIN original rechargeable battery

1. Function

This battery is used without main power supply for the following functions.

1) Display wake up (Refer to chapter 3.3.2) page 3-11.

Setting/Display the following items on the LCD display.

<Display>

Temperature on the return air sensor

Temperature on the supply air sensor

<Setting change>

Inside temperature, defrosting interval, dehumidifying set (Optional), Unit ON/OFF

2) USDA data log

USDA sensors data log every 1 hour

Note) When the Dry battery is equipped,it must be replaced for a new every PTI, when USDA is used.

3) Trip data log

Trip data; Setting point, Supply air, Return air, Humidity and time is logged every 1 hour after power off
untill battery run out. (Min.3 days)

2. Battery check

Dry battery: Press key. to confirm the Basttery mode workable, when the power is disconnected.

Rechargeable battery: Press "Battery check meter"

Green: Operatable


Red: Recharge battery

No lighting: Recharge or replace battery

8.3 Control box (Applicable models:LXE10E-A6,A11,A20,A26(A), A12(AtoE),A28,A17(A) and A35(A))

8.3.1 Installation of personal computer receptacle and spare fuse in the control box


● Inside of the control box



- ① Personal computer receptacle
- ② Fuse holder/Spare fuse


8.3.2 Cable clamp bracket 1 (Applicable models:LXE10E-A6,A12(A,B),A28, A18(A,B) and A30)

When it is operated on the trailer or railway chassis, be sure to fasten the power cable with cable clamp.



8.3.3 Cable clamp bracket 2 (Applicable models: LXE10E-A5(BR), A7, A8, A9, A11, A20, A26(A), A12(A to E), A28, A17(A), A35(A), A19, and A26(B, C))

When it is operated on the trailer or railway chassis, be sure to fasten the power cable with cable clamp.



8.4 USDA transportation(Applicable models:LXE10E-A11,A20, A26(A),A12(A,B),A28,A14,A15(A,AR,B) and A26(B,C))

If USDA receptacles and sensors (Optional) are provided to the unit, the unit can take USDA transportation. (Refer to arrangement of main component in 2.2.2.)

8.4.1 Type of USDA sensor/receptacle

Two types of sensors can be installed, according to the type of receptacles.

User should confirm the type of receptacles and select proper sensor in below table.

According to the model, the quantity of receptacle is different. (3 or 4)

Type	Receptacle	Sensor
1	T3107003	ST9702-1
2	HD10-3-96P	NTC type probe

*3 receptacles : USDA 1, USDA 2, USDA 3

4 receptacles : USDA 1, USDA 2, USDA 3, CTS (Cargo temperature sensor)

8.4.2 Initial setting

User should confirm initial setting of controller as below.

- 1) USDA transportation ; Initial setting mode at page 3-29.
Quantity of receptacles should be set
- 2) Type of USDA sensor
Type of USDA sensor should be set.

8.4.3 USDA sensor calibration

USDA requires sensor calibration every transportation and report each offset figure. Free-supply downloading software enable to assist this. Please refer to "Operation manual for Daikin Container Communication Software".


8.4.4 USDA transportation requirement

Cargo and refrigeration unit shall be required pre-cooling before cargo loading. As to position of USDA sensors and operation, please refer to the guidance of USDA.


8.4.5 USDA report required by USDA local officer

Free supply downloading software enables you to make document easily, which USDA local officer requires. In detail, please refer to "Operation manual for Daikin Container Communication Software".

●USDA receptacle



●USDA sensor




8.5 TransFRESH (Applicable models:LXE10E-A9,A18(A,B),A30 and A27(A,B))


Attachment for the TransFRESH CA devices are provided to control the internal atmosphere (quantity of O₂ and CO₂).

Use the CA devices according to the Operation Manual supplied by TransFRESH. The controller and sensor included in the CA devices are installed by the TransFRESH's agents before each transportation.

●An example of installation of CA devices, outside.



●An example of installation of CA devices, inside



① TransFRESH ASS'Y A4&A5 CABLES W/MOUNTING BOX

8.6 Special service port (Applicable models:LXE10E-A23(A,B))


8.6.1 Collection of refrigerant

- ①When release the refrigerant from the refrigerant system, be sure to use a refrigerant recovery unit to protect the ozone layer around the earth from depletion.
- ②Observe strictly all the environmental laws relating with to the country where the repair service is conducted.

8.6.2 Attaching and removing of manifold gauge

(1) Attaching the gauge manifold

Remove the service port cap using 2 spanner and attach the charging hose to service port, then turn the part ① by hand to tighten.




CAUTION FOR USAGE OF SERVICE PORT CAP

- WHEN THE SERVICE PORT CAPS HAVE TO BE REMOVED OR TIGHTENED, BE SURE TO USE 2 SPANNERS.
- TO TIGHTEN THE SERVICE PORT CAPS, USE BELOW MENTIONED TORQUE TO PREVENT GAS LEAKAGE.

TORQUE VALUE : $12.7\text{N} \cdot \text{m} \pm 10\%$

DON'T PUT THE SPANNER ONTO THIS SEAT!!






CAUTION


1. Use the pressure indicating function of the controller to check the working pressure as much as possible instead of using the gauge manifold in order to prevent foreign particles or moisture from mixing into the refrigerant system.
2. Do not use any of the pressure gauge, gauge manifold, charge hose and charging cylinder which have been used for CFC12 in order to prevent refrigerant or refrigerant oil of a different kind from mixing.

●Caution on the service work

- ①Be sure not to bend the refrigerant pipe when turning the hose joint.
- ②The remaining pressure in the charge hose may cause installation failure. In this case, try it again after relieving the pressure in the hose.




Structure of gauge manifold



(2) Removal of gauge manifold

Remove the gauge manifold with turning the joint ① by hand.




CAUTION

Be sure to attach the cap to the service port after the removal of the manifold.

8.7 Pressure gauge (Applicable models:LXE10E-A23(A,B))

TYPE : GV55-DO2

Low pressure gauge is fitted in this model.



When the flare nut of pressure gauge piping is loosened for replacing pressure gauge, "LOCTITE" and "Sylicone sealant" should be applied by following precedure to prevent refrigerant leakage caused by freeze of moisture.

(LOCTITE : Threadlocking material)

CAUTIONS FOR REPAIR LOW PRESSURE GAUGE PIPING


- APPLY "LOCTITE" & "SILICONE SEALANT" LIKE SHOWN IN "DRAWING A & B" TO PREVENT GAS LEAKAGE CAUSED BY FREEZE OF MOISTURE,

(LOCTITE : THREADLOCKING MATERIAL)




The tightening torque value is as follows:

POSITION	TORQUE VALUE
a&b	15.7N・m ±10%
b&c	17.5N・m ±10%

- BE SURE TO USE 2 SPANNERS,



Be sure to clamp the pressure gauge piping to suction piping using "Tie wrap" at the following part.



MEMO

DAIKIN INDUSTRIES, LTD.

Head Office. Umeda Center Bldg., 4-12, Nakazaki-Nishi 2-chome, Kita-ku, Osaka, 530-8323 Japan.

Tel: 06-6373-4338

Fax: 06-6373-7297

Tokyo Office. JR Shinagawa East Bldg., 10F 18-1, Konan 2-chome, Minato-ku Tokyo, 108-0075 Japan.

Tel: 03-6716-0420

Fax: 03-6716-0230